




Home » wizarpos » wizarPOS Q3 Portable Payment Terminal User Manual 📆

Contents [hide]

- 1 wizarPOS Q3 Portable Payment Terminal
- 2 Packing List
- 3 Front View
- 4 Left/ Right View
- 5 Operating Instructions
- 6 Environment
- 7 Specification
- 8 FCC Regulations
- 9 Safety Warning
- 10 Trouble Shooting
- 11 wizarPOS Repair Records
- 12 Documents / Resources
 - 12.1 References

wizarPOS


wizarPOS Q3 Portable Payment Terminal



Packing List


Thank you for choosing our product!

We sincerely hope that wiarPOS will enable smart payments and enhance the convenience of your daily business. Before powering up the device, please check the terminal and accessories as follows:




- USBCable
- SV 2AAdaptor
- Please contact your product provider if anything is missing.


Front View




- Camera
- SIM Card Slot+ TF/SIM Card Slot
- PIN on Glass/ Contactless on Glass


Left/ Right View






- USBType-C
- SIM Card Slot+ TF/SIM Card Slot
- Speaker
- PowerKey
- Volume Key






- Scanner(Optional)
- IC Card Reader



- Camera
- Hand Strap Mount



Magstripe Reader (Optional)

Operating Instructions

Power on/off

- Power on: Press the power botton for 3 seconds to turn on the terminial
- Power off: Press the power botton for 3 seconds. Click power off and select ok in the pop-up window to shutdown the terminal.

Access network After powering on the termial, please connect to Wi-Fi or 4G to access network services.

WLAN Setting:

- Swipe down from the top of the screen to access the notification panel. Click the Wi-Fi button to turn on or off the internet. Hold on the button to get into the Wi-Fi setting.
- You can also click Settings and choose WLAN to get into Wi-Fi settings. Activate the
 Wi-Fi function, select the network that has been automatically detected, and enter the

password. You can also tap on 'Add Network', input the network name, and then enter the password to connect to a Wi-Fi network. Swipe up from the screen to access the 3-button nevigation.

• Click the circle to return to the home page. You can repeat this process multiple times for any additional networks available, including 4G and Mobile Phone Hot Spots.

Settings all done

Once you have completed the above settings, please contact yourservice provider for assistance with application downloads and technical support.

Terminal self-diagnostic

To verify the functionality of the equipment, utilize the terminal's self-check capabilities. Click Settings> Self-check and choose the functionality or parts that you want to test.

Environment

Card Transactions

Contactless Transactions: This terminal uses the contactless on screen transaction mode. Tap a contactless enabled card or smartphone on the terminal screen.

Chip Card Transactions: Insert the card with the chip facing up (down) fully into the chip card slot, and remove it after the reading is completed.

Magnetic Stripe Transactions: With the card's magnetic stripe facing downwards towards the screen, swipe the card through the magnetic stripe reader at a constant speed, in any direction.



Specification

Specification	tailed Description	
Software Platform	Secure Android 14	
Processor	Quad-Core@ 2.0GHz	
Memory	2GB RAM+ 32GB Flash, 4GB RAM+ 32GB Flash (Option al)	
	5" multi-touchcolorLCDpanel(720×160□)	
Display	ContactlessOnScreen	
Camera	Front-facing:2MPFForScanner Rear:SMPAF	
	PDF 417, QR Code, Data Matrix, EAN-8, EAN-13,	
Scanner (Optional)	Codell,Code39,Code128	
	P[I PTS 6.x, SREO, EMV LI & L2, EMVCL LI, TQM,	
	PayPass, PayWave, ExpressPay, □-PAS, Anatel,	
Certaification	InteracFlashL2,Rupay,MIR,Jspeedy,RoHs,FCC,CE	
	NFC contactless: ISO 14443 Type A & B, MIFARE, Sony	
Card Readers	Felica Chipcardreader:IS07816 Magstripereader(Optional):I507811,Trackl/2/3,bi-direction	
Slots	SIM xI + TF xI or SIM x2	
Connectivity	GSM, WCOMA, FOO-LTE, TDD-LTE, Wi-Fi, BT 5.0, USB 3.0, e-SIM (optional), GPS, GLONASS	
Audio	Built-in microphone and speaker	

Dimensions	78 x 166 x 16.6 mm (3.07 x 6.54 x0.65 inches)	
Environmental	Dperatingtemperature:-10°C-50°C(14°F-122°F) Storage t emperature:-20°C-70°C (-4°F-158°F) Relativehumidity(n on-condense}:5%-95%	
Accessories(Optional)	Hand Strap	
Battery (Optional)	BV / 5000mAh	
Charging	5V2A adapter, USB charging	

All features and specifications are subject to change without notice. Contact the wizarPOS website for more details.

www.wizarpos.com

FCC Regulations

FCC Regulations

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/fVtechnician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Safety Warning

- 1. WizarPOS provides after-sales service in accordance with applicable laws and regulations. Please review the warranty terms outlined below.
- 2. Warranty Period: The terminal and charger are covered by a one-year warranty. During this period, if the product experiences a failure not caused by user negligence, WizarPOS will offer free repair or replacement services. For assistance, it is recommended to first contact your local distributor, and provide a completed warranty card with accurate information.
- 3. The warranty does not cover the following situations: unauthorized maintenance of the terminal, modifications to the terminal's operating system, installation of third-party applications causing malfunction, damage due to improper use (such as dropping, crushing, impact, immersion, fire, etc.), missing or inaccurate warranty information, expired warranty period, or any other activities that violate legal regulations.
- 4. Follow installation instructions carefully and use only the specified power adapter. Replacing it with other adapters is prohibited. Ensuret hat the power socket meets the required voltage specifications. It is recommended to use a socket with a fuse and ensure proper grounding.
- 5. To clean the terminal, use a soft, lint-free cloth-avoid using chemicals and sharp objects.
- 6. Keep the terminal away from liquids to prevent short circuits or damage caused by

- splashes, and avoid inserting foreign objects into any ports. The terminal and battery should not be exposed to direct sunlight, high temperatures, smoke, dust, or humidity.
- 7. If the terminal malfunctions, contact certified POS maintenance professionals for repair. Unauthorized personnel should not attempt repairs.
- 8. Do not modify the terminal without authorization. Modifying a financial terminal is illegal. Users assume the risks associated with installing third party applications, which may cause the system to operate at reduced speeds.
- 9. In case of abnormal odors, overheating, or smoke, immediately disconnect the power supply.
- 10. Do not place the battery in fire, disassemble it, drop it, or apply excessive pressure. If the battery is damaged, immediately discontinue use and replace it with a new one. The battery charging time should not exceed 24 hours. If the battery is not used for an extended period, charge it every six months. For optimal performance, replace the battery after two years of continuous use. gsgs:
- 11. The disposal of batteries, equipment, and accessories must comply with local regulations. These items cannot be discarded as household waste. Improper disposal of batteries may lead to hazardous situations such as explosions.

Trouble Shooting

ouble	Trouble shooting	
Cannot connect the mobile network	 Check whether the function of data" is open. Check whether the APN is correct. Check whether the data service of SIM is activated. 	

Display unstable	♦ Thedisplay may be interfered by instability voltage when c harging, please reconnect the plug.
No response	◆ Restart the APP or operation system.
Operation very slow	♦ Please exit APPs which are not necessary.

wizarPOS Repair Records

Repair content

For more information, please log on to the company's official website http://www.wizarpos.com

Documents / Resources



wizarPOS Q3 Portable Payment Terminal [pdf] User Manual

250321, 250328, Q3 Portable Payment Terminal, Portable Payment Terminal, Payment Terminal

References

•	User	Manual

- wizarpos
- 250321, 250328, Payment Terminal, Portable Payment Terminal, Q3 Portable Payment Terminal, Wizarpos

Leave a comment

Your email address will not be published. Required fields are marked*

Comment*

Name

Email

Website

 $\hfill \square$ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.