


RCA

SATELLITE RECEIVER



USER'S GUIDE

SAFETY INFORMATION

WARNING

To reduce risk of fire or shock hazard, do not expose this receiver to rain or moisture.

WARNING

RISK OF ELECTRIC SHOCK
DO NOT OPEN

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.



This symbol indicates important instructions accompanying the product.

Cautions

Do not stack electronic components or other objects on top of the receiver. The slots on top of the receiver must be left uncovered to allow proper airflow to the unit. Blocking the airflow to the unit could impair performance or damage your receiver and other components.

Do not stack the receiver on top of a "hot component" such as an audio power amplifier.

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

The RF remote control complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) The RF remote control may not cause harmful interference and; 2) The RF remote control must accept any interference received, including interference that may cause undesired operation.

Note to Cable TV Installer:

This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Note to Satellite Dish Installer:

This reminder is provided to call your attention to Article 810 and in particular article 810-15 of the National Electrical Code which covers proper installation and grounding of television receiving equipment as well as to article 820-40 of the National Electrical Code which specifies that the satellite dish cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

IMPORTANT NOTICE:

This device incorporates an anticopy process technology that is protected by U.S. patents and other intellectual property rights. The anticopy process is licensed for non-commercial, home use only. Reverse engineering or disassembly is prohibited.

Care and Cleaning:

Use a soft cloth or dusting attachment of your vacuum cleaner to dust your receiver. Remove dust from the ventilation holes on the top and bottom.

Plastic surfaces are easily scratched and can be marred by alcohol and various solvents. Avoid excessive use of oil-based furniture polishes since the materials used in the cabinet will accumulate more dust. A non-abrasive, anti-static cleaner/polisher is recommended.

Table of Contents

First Things First	3
What is the Satellite System?	4
What's in the Box	5
Using This Manual	6
The Point and Select Method	7
Connecting Your Receiver to Your TV	8
Things to Know Before Connecting Components	8
Jacks and Cables	9
Connecting the VCR Controller	14
Ordering Programming	16
Program Guides	17
Anatomy of a Program Guide	18
Anatomy of The Channel Banner	19
Using the GUIDE Button	20
Getting Around in the Guides	20
Tuning to a Program	21
The Other Program Guides	21
Sorting the Guides	23
The Menu System	29
Using the Menu System	30
Exit and Help	30
Menu Descriptions	31
The Program Guide	32
Anatomy of a Program Guide	32
The Mailbox	33
How to tell when you have mail	33
Checking your mail	33
Pay-Per-View Programs	34
Purchasing and Previewing	34
Tuning to a PPV Program	34
Using the Program Guide for PPV Programs	35
Using the Attractions Guide	36
Using the Purchases Menu	37
Reviewing and Canceling an Upcoming Purchase	37
Spending Limits	38
Timers Feature	39
Profiles	41
Creating a Profile Channel List	41
Setting the Ratings Limit	42
Viewing Hours	43
Setting Up Spending Limits	43

Table of Contents

Locking a User's Profile	44
Locking the System	44
Choosing Your Profile	45
Options	46
Look and Feel	47
System Options	47
Audio Language	49
Dolby Digital	49
Alternate Data	49
The Dish Pointing Menu Screen	50
Using the On-Screen Signal Meter	51
Home Control	52
Fetch Menu	54
Customize the Fetch Menu	54
Reference	55
Parts of the System	56
World View	56
Home View	57
Controls and Buttons	58
Front Panel Controls	58
Back Panel Controls	59
Remote Control Buttons	60
Programming the Remote Control	61
Programming the Remote to Control Your TV	62
Programming the Remote to Control Your VCR	62
Programming the Remote to Control Other Devices	63
Using the Remote Buttons to Control a Device	63
Remote Codes	64
Glossary	66
Troubleshooting	68
Running the System Test	68
Appendix A: Warranty Information	69
Appendix B: FCC Regulations	72
Appendix C: Accessories	73
Index	75

StarSight-Licensed: The manufacture and sale of the television schedule feature of this product was licensed under one or more of the following patents of StarSight Telecast, Inc.; U.S. Patent Nos. 4,706,121; 4,977,455; 5,151,789; 5,335,277; and 5,353,121.

First Things First

Read the First Two Chapters

The first two chapters of the manual introduce you to your satellite system, and show you how to use the on-screen guides and menus.

In *First Things First*, you'll learn:

- how to use this manual
- how to use the menu system and guides
- different ways to connect the receiver to your TV
- how to connect the VCR controller
- how to order programming

Program Guides details the items and features associated with the different guides.

The Rest Of The Manual

The rest of the book includes menu information, reference information such as remote codes, a glossary, and an index.

1 First Things First



2 Program Guides



3 The Menu System



4 Reference



5 Appendices

First Things First

What is the Satellite System?

You've purchased the satellite system, so you already know a lot of the great things it offers. You know that the system uses the latest satellite technology to deliver television programming to your home. And you know that the transmissions are digital, so the quality of the picture and audio rivals that of laser discs and CDs. You know the dish is small—18 inches wide—and that it often can be installed in a matter of hours. (See the System Installer Guide for specific information.)

Those are the some of the things you probably know about the system. But what about the things you don't know? For instance...


- The system works like your TV. Pick up the remote and push the SAT1 button. Press the Channel Up/Down buttons to scan through the channels. Press the number keys to go directly to a channel.
- There is an on-screen program guide. The program guide is like a TV listing in the newspaper. It is designed to help you select regular programs and pay-per-view events. You can also sort the guide to list only specific types of programs. You can select Sports, for example, and your guide will show current and upcoming sports programs only. Or Movies. Or News.
- There is the on-screen Menu System that allows you to customize your system. You can set up your system, build channel lists, preview coming attractions, set spending limits, and receive mail from your program providers.
- There are three types of On-line Help to assist you in learning how to use the system: Context-Sensitive Help (at the bottom of most menu screens), *Help* buttons, and the *System Info* menu.

First Things First

What's in the Box

The following items come with your receiver:


- Receiver (with access card inserted)
- Remote Control
- VCR Controller



Installing Batteries In the Remote Control

Follow these steps whenever you need to install or change the batteries in your remote.

1. Remove the cover from the battery compartment.
2. Insert batteries as shown in the battery compartment, matching the + and - end of each battery.
3. Replace the cover.



Programming the Remote

Depending on your equipment you may need to program the remote to control other devices. Check out "Programming the Remote" in the Reference section.

First Things First

Using This Manual

There are a couple of conventions used in this manual that might help you read it.

- Words that appear in ALL CAPS indicate the name of a button.
- The names of on-screen menu options are shown in *italics*.

Important Note about This User's Manual

This manual assumes that your system has been installed, meaning:

1. The satellite dish antenna has been installed, correctly pointed at the satellite, and connected to your receiver.
2. The receiver is connected to your television and to a telephone line.
3. The access card is installed in your receiver.

Your access card has been matched to your receiver, and should already be installed when you take the receiver out of the packing box. The access card should only be taken out of the receiver when you are issued a new card by your programming providers.

4. The remote control has batteries and can be programmed to control both your receiver and your TV (if your TV is remote-controllable).

If your system has not been installed, refer to the satellite dish Installer's Guide for information regarding proper installation. Then, refer to the next section, *Connecting Your Receiver to Your TV*. See your dealer for specific information regarding professional installation or the purchase of a Self-Installer's Kit.

First Things First

The Point and Select Method

Point and Select is the two-step method you use to navigate through the menu system and program guides. Once you know how to point and select, you can explore the menus to learn more about how your system works.

1. Point

You point by pressing the arrow keys on the remote or front panel. Pressing the arrow keys moves the on-screen highlight to different items in the program guide and the menu screens. Pressing an arrow once moves the highlight one space in the direction of the arrow.


For example, to point down (that is, to move the highlight toward the bottom of the screen), press the down arrow. To point right, press the right arrow.

2. Select

Once you have pointed to an item on the screen, select it by pressing the MENU•SELECT button on the remote or front panel. Selecting an item tells the menu system to go ahead and make the change you have indicated.

For example, the instructions in the User's Manual might tell you to Point to the *Exit* button and press MENU•SELECT.

Once you've got the hang of the Point and Select rule, you can use any part of the system.



Don't worry about getting stuck inside a menu. Pressing the CLEAR button on the remote takes you out of the menu system and back to the program you were watching.

First Things First

Connecting Your Receiver to Your TV

During the satellite dish installation, the receiver may have been connected to your TV with just a coaxial cable for the system test. Depending on what components you have, another connection may provide better picture and audio quality. The following sections provide cable and connection information to help you decide what connection is best for you.

Things to Know Before Connecting Components

Protect Your Components from Power Surges

- Connect all components before plugging any power cords into the wall outlet.
- Always turn off the receiver, TV and other components before you connect or disconnect any cables.

Position Cables Correctly to Avoid Audio Hum or Interference

- Insert all cable plugs firmly into their jacks.
- Place the audio/video cables to the sides of the TV's back panel instead of straight down the middle after you connect your components.
- Try not to coil any twin-lead cables and keep them away from the audio/video cables as much as possible.
- Make sure all antennas and cables are properly grounded. Refer to the Safety Tips sheet packed with your unit.

Protect Your Components from Overheating

- Do not block ventilation holes in any of the components. Arrange the components so that air can circulate freely.
- Do not stack components.
- Allow adequate ventilation when placing your components in a stand.
- Place an amplifier or receiver on the top shelf of the stand so heated air rising from it will not flow around other components.


First Things First

Jacks and Cables

S-Video Jack and Cable

The S-Video jack provides the best picture quality for your system.


This jack is available on many TVs and is used in conjunction with audio cables to connect the receiver to your TV. Remember also to connect the left and right audio cables because the S-Video jack carries only the picture signal, not the sound.



Audio/Video Jacks and Cables (RCA-type)

The audio/video jacks provide very good picture and stereo sound quality, and should be used if your TV has no S-Video jack.


These jacks are used for most audio/video connections between components. The receiver audio/video jacks are color coded (yellow for video, red for right audio, and white for left audio). If your TV has only one input for audio (mono), connect it to the right (red) audio jack on the receiver.



RF Jacks and Coaxial Cables (F-type)


The RF jacks provide good picture and mono sound quality, and are to be used if audio/video connections are not available for your TV.

These jacks are required for antenna or cable-TV connections. The RF jacks on the receiver are labeled IN FROM ANT and OUT TO TV. The coaxial cable supplied with your system is used to connect the RF jacks between the receiver and your TV's antenna input.




VCR Controller Jack and Cable

The VCR controller cable plugs into a jack on the receiver's back panel. The other end of the cable affixes to your VCR's remote sensor.



Dolby Digital Optical Output Jack and Cable*

Provides up to 6 independent soundtrack channels through the optical output jack. When connected to an optional, compatible 6-channel amplifier/receiver and speakers, this connection provides Dolby Digital Surround Sound (when available).



*(Dolby) and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

First Things First

Connection A

Best Picture and Sound Quality

To use this connection you must have:

- TV with separate RF, audio/video, and S-Video inputs (jacks)
- VCR with RF and audio/video inputs
- Coaxial, audio/video, and S-Video cables

To connect TV, VCR and antenna or cable box:

1. Connect coaxial cables as shown.
2. Connect audio/video cables as shown.
3. Connect S-Video cable as shown.

To receive programming:

1. Tune TV to receive the S-Video output from the receiver.
2. Tune receiver to desired channel.

To receive off-air programming (no cable box):

1. Turn off VCR and receiver.
2. Tune TV to desired channel.

To receive off-air programming (with cable box):


1. Turn off VCR and receiver.
2. Tune TV to cable box output channel (usually CH2, CH3, or CH4).
3. Tune cable box to desired channel.

To record programming:

1. Tune TV to receive S-Video output from receiver.
2. Tune receiver to desired channel.
3. Set your VCR to record on line input.

To view VCR programming:

1. Tune TV to VCR output channel (usually CH3 or CH4).



When connected to an optional, compatible Dolby Digital audio receiver and speakers, and a Dolby Digital audio signal is available, this receiver can provide exceptional sound quality. See the Dolby Digital information on page 49.

CAUTION

Do not stack electronic components or other objects on top of the receiver. See Safety Information, inside front cover.

First Things First

Connection B

Very Good Picture and Sound Quality

To use this connection you must have:

- TV with separate RF and audio/video inputs (jacks)
- VCR with RF and audio/video inputs
- Coaxial and audio/video cables

To connect TV, VCR and antenna or cable box:

1. Connect coaxial cables as shown.
2. Connect audio/video cables as shown.

To receive programming:

1. Tune TV to receive line output from receiver (often called Input 1).
2. Tune receiver to desired channel.

To receive off-air programming (no cable box):

1. Turn off VCR and receiver.
2. Tune TV to desired channel.

To receive off-air programming (with cable box):


1. Turn off VCR and receiver.
2. Tune TV to cable box output channel (usually CH2, CH3, or CH4).
3. Tune cable box to desired channel.

To record programming:

1. Tune TV to record line output from receiver (Input1).
2. Tune receiver to desired channel.
3. Set your VCR to record on line input.

To view VCR programming:

1. Tune TV to VCR output channel (usually CH3 or CH4).



CAUTION

Do not stack electronic components or other objects on top of the receiver. See Safety Information, inside front cover.

First Things First

Connection C

Good Picture and Sound Quality

To use this connection you must have:

- TV with RF input (jack)
- VCR with RF and audio/video inputs
- Coaxial and audio/video cables

To connect TV, VCR, and antenna or cable box:

1. Connect coaxial cables and audio/video cables as shown.

To receive programming:

- Tune TV to channel 3 or 4 (depending on how you set the CH3/CH4 switch on the back of the receiver).

To receive off-air programming (no cable box):

1. Turn off VCR and receiver.
2. Tune TV to desired channel.

To receive cable programming (with cable box):


1. Turn off VCR and receiver.
2. Tune TV to cable box output channel (usually CH2, CH3, or CH4).
3. Tune cable box to desired channel.

To record programming:

1. Tune TV to the channel on which you receive the signal.
2. Tune receiver to desired channel.
3. Set VCR to record on line input.

To view VCR programming:

1. Tune TV to VCR output channel (usually CH3 or CH4).
2. Turn receiver off.



CAUTION

Do not stack electronic components or other objects on top of the receiver. See Safety Information, inside front cover.

First Things First

Connection D

Good Picture and Sound Quality

To use this connection you must have:

- TV with RF input
- Coaxial cables

To connect TV and antenna or cable box:

1. Connect coaxial cables as shown.

To receive programming:


- Tune TV to channel 3 or 4 (depending on how you set the CH3/CH4 switch on the back of the receiver.

To receive off-air programming (no cable box):

1. Turn off receiver.
2. Tune TV to desired channel.

To receive cable programming (with cable box):

1. Turn off receiver.
2. Tune TV to cable box output channel (usually CH2, CH3, or CH4).
3. Tune cable box to desired channel.



CAUTION


Do not stack electronic components or other objects on top of the receiver. See Safety Information, inside front cover.

First Things First

Connecting the VCR Controller

In order for the satellite receiver and VCR to communicate, you need to attach the VCR Controller to the back of the receiver.

1. Plug the VCR Controller into the VCR CONTROL jack on the back of the receiver.
2. Affix the other end to the remote sensor on your VCR.



Locating the VCR's Infrared Remote Control Sensor

The VCR Controller must be affixed directly over the infrared remote sensor on your VCR.


Some VCRs label the infrared remote sensor, and others do not. If your VCR is labeled, affix the VCR controller directly over the sensor.

Using the VCR Remote to Locate the Remote Sensor

For VCRs that do not label the remote sensor, you need to use the VCR's remote to locate the sensor before affixing the VCR controller.

1. Hold the remote control so that it is touching the front of the VCR.
2. Slowly move the remote over the front of the VCR while pressing the remote power button on and off.
3. When your VCR turns off or on, you have located the sensor.

To test the VCR controller, use a piece of clear tape to temporarily attach the VCR controller to the spot where you think the sensor is located, and then follow the steps described under "Selecting a VCR Type."




First Things First

Selecting a VCR Type

You need to tell the satellite receiver which VCR brand you are using.

1. Press MENU•SELECT on the remote to bring up the Main menu.
2. Point to *Options* and press MENU•SELECT.
3. Point to *System Options* and press MENU•SELECT.
4. Point to *Set VCR Type* and press MENU•SELECT.



The Set VCR Type screen lets you enter a code for your VCR.

5. Use the arrows or digit keys to input the correct code for your VCR brand. The VCR codes are located in the “Reference” section of this book.
 6. Follow the on-screen instructions to ensure that you are using the correct code. If the VCR automatically stops, then you know that the receiver and the VCR are communicating.
- Some VCR brands may not be capable of being controlled by the receiver.

First Things First

Interactive Setup

If you self-installed your satellite dish antenna, you may have already used the interactive setup to find the dish pointing coordinates, acquire and fine-tune the signal, and run a system test.

If you need to run the interactive setup again, select *Options* from the Main menu, then select *Interactive Setup*.

If you just want to check your dish pointing coordinates, or run the signal strength meter, select *Dish Pointing* from the Main menu.

Ordering Programming

After you have installed your system, you should contact the service providers, DIRECTV and USSB to receive programming.

Programming with DIRECTV: Call 1-800-347-3288

Programming with USSB: Call 1-800-204-USSB

When you order programming, you need to know your Access Card number. To get the number, select *Options* from the Main menu, then *System Options*, and then select *System Test*.

Wait for the system to run all of its tests. The Access Card number is displayed at the end of the system test.

Write the Access Card number in the space below for easy reference:

Program Guides

What is a Program Guide?

A program guide is an on-screen programming schedule. There are several types of guides, each presenting the schedule in a different format.

Using the program guide is easy as long as you remember the Point and Select rule. Point to items on the screen by pressing the arrow keys on the remote or front panel. Then, press MENU•SELECT to tune to that program.

1 First Things First



2 Program Guides



3 The Menu System



4 Reference




5 Appendices

Program Guides

Anatomy of a Program Guide

The following diagram shows you the kind of information you will see in the program guides.



Bringing Up the Program Guides


You can access the program guides by pressing MENU•SELECT on the remote and selecting *Program Guide*, or by using the GUIDE button on the remote.



Program Guides

Anatomy of The Channel Banner

Some of the items you select in the guides can also be selected in the channel banner.



The channel banner appears whenever you tune to a channel, exit a guide, or press INFO on the remote. Use the arrow buttons and MENU•SELECT to choose an item.

On-screen icons represent frequently used menu items. Some icons also change appearance to show the item's status.

Green Unlock icon The system is unlocked. Spending, viewing and other limits can be accessed and changed.

Yellow Unlock icon A password has been entered to override family or profile limits. No limits can be accessed or changed.

Red Lock icon No limits can be accessed or changed. A password is required to override limits or access the system.

Highlighted Scout (binoculars) icon A Scout has found program information.

Highlighted Mail icon indicates a message in your mailbox.

Home Control or Data Port icons The icon changes appearance depending on how the Low Speed Data port is used.

Program Guides

Using the GUIDE Button

Each press of the GUIDE button takes you to an alternate type of program guide.

The Detail Guide



The Detail Guide shows five channels in a time-and-channel format, with program information for the highlighted program.

The Grid Guide

The Grid Guide shows seven channels in a time-and-channel format.

The SurfGuide

The SurfGuide displays a half-hour format. Press the right arrow button to extend the SurfGuide to a two-hour format.



Getting Around in the Guides

This section describes how to change channels and move around the program guide.

Point to Channels with the number keys (0-9)

You can point quickly to any channel in the program guide by entering the channel number with the number keys (0-9). For example, to point to channel 228, press the numbers 2-2-8 on the remote. To point to channel 530, press 5-3-0.

Scrolling Channel By Channel

The programs that you see on the TV screen make up one section—or page—of the total program guide. You can scroll to other sections using the arrows: point to other times with the left and right arrows; point to other channels with the up and down arrows.

Scrolling Page By Page

If you want to scroll up or down through the program guide faster, press the Channel Up/Down buttons on the remote control. The highlight scrolls a page at a time.



By default, the Detail Guide appears when you press GUIDE on the remote. You can change the default guide from the Detail Guide to the Grid Guide or SurfGuide.


Select *Options* from the Main menu. Select *Look and Feel*, then set the *Default Guide*.

Program Guides

Tuning to a Program

To tune directly to a current program listed in the guide, point to the program and press MENU•SELECT.

To see information about a program in the guide, press INFO.



The Program Details screen appears and gives you several options.

Then, you can select:

- *View Channel* to tune to that channel
- *Channel Guide* to see a program lineup for that channel
- *Record Program* to set a timer to record the program
- *Buy Program* to purchase the program
- *Buy and Record* to purchase the program and set up a timer to record the program. (Some *Buy and Record* programs may have a different purchase price.)
- *Other Times* to see what other times the program is available. The program title is automatically entered and sorted in the AlphaSort control panel.

The options available to you may vary according to the type of program you select.

The Other Program Guides

Besides the Detail Guide, Grid Guide, and SurfGuide, there are a few more guides: the Channel Guide, the Logo Guide and the Attractions Guide.

You can access these guides by selecting the *Other Guides* button at the bottom of the Detail Guide and Grid Guide.




Other Guides button

Program Guides

The Channel Guide

Displays a channel's programming schedule in a channel-by-channel format.



The Logo Guide

Displays channel logos for the current user's profile.



The Attractions Guide

Displays a list of channels that show coming attractions and special events information.



You can point to any program and tune to that channel, get more information, or set a timer to record.

Just press the MENU•SELECT, INFO, or RECORD buttons

Exiting A Program Guide

There are three ways to exit a guide:

- Point to a channel and press MENU•SELECT.
- Point to *Exit* and press MENU•SELECT.
- Press CLEAR or GO BACK on the remote.

Program Guides

Sorting the Guides

Sorting the guide is a way of organizing the guide to show only the types of programs that interest you. There are several on-screen buttons that sort the guide in different ways.




The *Sorting* buttons appear at the bottom of the *Grid Guide* and *Detail Guide*.

Topics

The *Topics* button sorts the guide according to the current user's preferences. Select the *Topics* button to sort the guide.

The *Topics* button changes to the *Topics Themes* button. Press the *Topics Themes* button to edit the current user's themes preferences. These preferences are saved in each user's profile.



Checkmark the themes that interest you.

Select the categories, and checkmark the themes you would like to appear when you select the *Topics* button in the guides. Programming that fits the description of checkmarked themes will appear in the guide when you sort by the *Topics* button.



Topics button



Topics Themes button

Program Guides

Movies

Select the *Movies* button to list movies only. After selecting *Movies*, the *Movies* button changes to a *Movies Themes* button.

Select the *Movies Themes* button to sort the guide to list specific types of movies, such as comedies or musicals.



Select a *Movies Themes* that interests you.



Movies button




Movies Themes button

Sports

Select the *Sports* button to list sporting events only. After selecting *Sports*, the *Sports* button changes to a *Sports Themes* button.

Select the *Sports Themes* button to sort the guide to list specific types of sports, such as basketball or soccer.



Select a *Sports Theme* that interests you.



Sports button



Sports Themes button

All

The *All* button resets the guide to show all available topics, channels and listings for the current Profile.



All button

Program Guides


AlphaSort

AlphaSort lists in alphabetical order all the program titles in the current guide. Select the *AlphaSort* button to search for specific program titles that are in the current program guide. Use the arrow button to highlight a character, then press MENU•SELECT.

For example, to search for the program, *Auto Racing*, the first letter you should enter is "A". (Words like "The", "A" and "An" appear at the end of a title.) All titles that begin with "A" appear in the *AlphaSort* list. Next, enter the letter "U". All titles beginning with "AU" appear in the list.



AlphaSort button



AlphaSort searches for specific titles in the guide.

Continue entering the specific title's letters until it appears in the *AlphaSort* list. If you enter the wrong letter, select either *Backspace* or *Clear All*.

Use the arrow buttons to highlight the title you are looking for. Press the MENU•SELECT button to select it, the INFO button to see more information, or the RECORD button to set up a timer recording. Only titles that are in the current program guide can be found by *AlphaSort*.

Program Guides

Scout

The *Scout* button lets you assign “Scouts” to search the guide for very specific program information, such as actor’s names or program descriptions. Select the *Scout* button to view the available scouts.

Point to an available *Scout*, and select it. Select the *Enter Text* button to set up the information the *Scout* will look for in the program guide. Use the on-screen keyboard to enter the desired search parameters.

For example, if you are interested in National Basketball Association events, enter a common term you might see in program information, like “NBA”.




Scout button



Select *Enter Text* to set up a *Scout*.

If “NBA” appears within a program title or program description, the program will be included in the *Scout Results* program list.

The *Scouts* will search for information when the receiver is off. (This may take up to 30 minutes for a full guide search.) You can check a *Scout’s* results by selecting a *Scout*.



Scouts look for specific program information.

Use the arrow buttons to highlight the title you are looking for. Press the MENU•SELECT button to select it, press INFO to see more information, or RECORD to set up a timer recording.



A checkmark next to the Scout means it is in use.

A highlighted binocular icon means the Scout has found something.

Program Guides

Other Guides

The *Other Guides* button lets you sort the guide by different variables, such as future times, user profile channel lists, and channel groups. You can then choose a guide format to view the program information.



Other Guides button

Select the *Other Guides* button. You can select multiple sort parameters. For example, you could sort the guide by pay-per-view movies that are available at a future time.

Select *Guide Data* and use the arrow and MENU•SELECT buttons to choose the *Guide Data* group.



Guide Data lets you see what's on in the future.

Then, select *PPV* in the *Channel Groups* category.



Channel Groups is another way to sort types of programming.

Select *Exit*, or press the GO BACK button on the remote to return to the previous guide. You can also choose another guide format from the category list.

Program Guides

The other buttons

Exit

Exits the guide and returns you to normal viewing on the current channel. Press MENU•SELECT to continue.



Exit button

Help

Brings up additional information about the guide. Press MENU•SELECT to continue.



Help button

Down Arrow

The arrow button allows you to scroll down through other channels in the guide. Point to the down arrow, and then press MENU•SELECT to scroll down through the program guide.



Arrow button

The Main menu

Brings up the Main menu. Press MENU•SELECT to continue.



Main menu button

The Menu System

What's a Menu?

The system menu is a list of choices, just like a menu in a restaurant. And, just as a restaurant menu is divided into sections such as appetizers, entrees, and desserts, the on-screen menus are also separated into sections to help you find the information you need.

Don't Forget Point and Select

As with all of the on-screen displays, you use Point and Select to navigate.

1 First Things First



2 Program Guides



3 The Menu System



4 Reference



5 Appendices

Use the MENU•SELECT button to bring up the Main menu, and then use Point and Select to choose a menu option.

The Menu System

Using the Menu System

To bring up the Main menu, press MENU•SELECT on the remote.



Use point and select to choose an item from the Main menu.

To use the menu system, you need to know the Point and Select rule. Use the arrows on the remote to point to an item on the screen, and then press MENU•SELECT to select it.

Exit and Help

There are *Exit* and *Help* buttons at the top of most screens. Point to *Exit* and press MENU•SELECT to leave that screen. Point to *Help* to see more information about that screen.

Exiting a Screen

There are three ways to exit a menu:

- Point to *Exit* and press MENU•SELECT.
- Press the CLEAR button on the remote control. The on-screen displays clear from the screen and you return to TV viewing.
- Press the GO BACK button on the remote. You return to the previous on-screen display or normal programming.

Using Help

All menus have a *Help* button. For example, selecting the *Help* button from the Main menu shows you information about using the Main menu screen.

The rest of the *Help* buttons in the menu system bring up helpful information explaining one aspect of that menu.

If the Main menu doesn't appear when you press MENU•SELECT, the remote might not be in satellite mode. Try pressing the SAT1 button on the remote, and then MENU•SELECT.

Context-Sensitive Help

Most of the screens contain information to help you decide what to do next. If you get stuck, look for the help text.

The Menu System

Menu Descriptions

This section briefly describes each of the available Main menu options. More information about each menu and its features is included later in this chapter.

Program Guide

Shows the on-screen programming schedules.

Mailbox

Use to read mail messages from your program providers.

Purchases

Use to review or cancel upcoming purchases, and to review past purchases.

Timers

Allows you to schedule the satellite system to tune to a specific channel at a specific time, and to record that channel.

Profiles

Allows you to set ratings limits, spending limits, and viewing hours, as well as create favorite channel lists.

Options

Allows you to find out more about the satellite receiver and remote, change how your system looks, run the system test and install a new access card.

Dish Pointing

Use to find your dish pointing coordinates, and to access the on-screen signal strength meter.

Home Control

With the proper equipment, this feature lets you control certain devices and appliances in your house.

Don't Be Afraid to Explore

Once you've learned the basics, feel free to poke around the menu system because exploring is the best way to learn. The context-sensitive help at the bottom of the screen provides instructions for getting through any particular menu or control panel. Remember, press CLEAR at any time to leave the menu system and return to regular system viewing.



Don't Forget about the CLEAR button

Press the CLEAR button on the remote to remove the on-screen menus and return to normal viewing.

The Menu System


The Program Guide

Selecting *Program Guide* brings up your default program guide: the Detail Guide, the Grid Guide or SurfGuide.

1 Program Guide...

Anatomy of a Program Guide

The following diagram shows you the kind of information you will see in the Detail Guide and Grid Guide.



Bringing Up the Program Guides

Besides selecting *Program Guide* in the Main menu, you can press the GUIDE button on the remote.

Want More Information?

Read the chapter "Program Guides" earlier in this book for all the details.

The Menu System

The Mail box

2 Mailbox...

The mailbox shows you messages that are sent—or “mailed”—from your program providers. For example, you may receive a message calling your attention to a new service.

How to tell when you have mail

There are two ways to tell if you have mail, depending on whether the receiver is turned on or off.

- If the receiver is turned on, the mail icon in the channel banner is highlighted.
- If the receiver is turned off, the power light on the front panel of the receiver flashes.

Checking your mail

Select *Mailbox* on the Main menu or channel banner to view your mail.

1. Point to a message and press MENU•SELECT. The message is opened for you to read.



Mail provides the latest information from program providers.

2. Press MENU•SELECT again to close the letter.

After you read a message and want to erase it, point to *Erase Message* and press MENU•SELECT. When you exit the display screen, messages not erased are saved in memory.

The Menu System

Pay-Per-View Programs

Pay-per-view programs (PPV) are programs that you purchase—like a movie ticket—on an event-by-event basis. For instance, there might be a specific channel that runs nothing but previews for movies. After previewing the movie, you can purchase it or find out more details about it. PPV programs can also be found in the program guide.


Purchasing and Previewing

There are several ways to purchase and preview PPV movies and events:

- Tune to a PPV program's channel. Program providers may offer on-screen purchase instructions, usually as the PPV program begins.
- Select a PPV program from the program guide.
- Preview a coming attraction by selecting a channel from the Attractions Guide.

Tuning to a PPV Program

When you use the channel buttons or digits on the remote to tune to a Pay-Per-View channel, you need to press the INFO button to bring up the *Program Details* screen in order to purchase a program.



Use the program guide to get to the *Program Details* screen.

Follow the on-screen instructions to purchase the selected program.


3 Purchases...

You may need to enter your four-digit password to order a PPV program if it costs more than the spending limit you set up in the Profiles menu.

The Menu System

Using the Program Guide for PPV Programs

When you use the program guide to select a PPV program, the *Program Details* screen gives you a few more options.



The Program Details screen gives you several options.

You can select:

- *View Channel* to tune to that channel
- *Channel Guide* to see a program lineup for that channel
- *Record Program* to set a timer to record the program
- *Buy Program* to purchase the program
- *Buy and Record* to purchase the program and set up a timer to record the program. (Some *Buy and Record* programs may have a different purchase price.)
- *Other Times* to see what other times the program is available. The program title is automatically entered and sorted in the AlphaSort control panel.

The options available to you may vary according to the type of program you select.

3 Purchases...

Buy and Record Option

Buy and Record is a convenient way to buy a PPV and set up a timer recording in one step.

However, your program provider may offer PPV programs that are coded so that you cannot record them.

You need to connect your phone line to your satellite receiver to be able to order PPV programs using the on-screen menus.

The Menu System

Using the Attractions Guide

Your program providers may offer future programming events not currently listed in your Program guide. These events are called “coming attractions,” and can be previewed in the Attractions Guide.

1. Press the GUIDE button until the Detail Guide or Grid Guide appears on-screen.
2. Use the down arrow button to move the highlight to the bottom of the screen.
3. Point to and select the *Other Guides* button.
4. Point to and select the *Attractions Guide*.



The Other Guides menu provides several guide formats.

5. Point to a channel and select it.



The Attractions Guide is accessed through the Other Guides menu.


3 Purchases...

The Menu System

Using the Purchases Menu

The Purchases menu allows you to review upcoming and past purchases.

3 Purchases...




The Purchases menu shows you upcoming or past purchases, and spending limits.

The list of purchases may be longer than one screen; use the down arrow keys to see more items. The display also shows the title, channel, date, time, and cost of each program.

- Note that the Past Purchases list might be modified after each billing cycle and still show purchases for which you have already paid.

Reviewing and Canceling an Upcoming Purchase

Use Point and Select to choose an upcoming purchase from the *Future Purchases* screen. You can review the program description, as well as cancel an upcoming purchase.



The Purchase Edit screen lets you cancel an upcoming purchase.

The Menu System

Spending Limits

Use the *Spending Limit* option to indicate a per-event spending limit for pay-per-view programs.

1. Point to *Spending Limit*, and press MENU•SELECT.



You can set a per-event spending limit for each Profile.

2. Use the digits on the remote or use the arrow keys to enter a single-program spending limit.

After a spending limit is set *and* the system is locked, you must enter a password to purchase a pay-per-view program that costs more than your spending limit allows.

3 Purchases...

Spending limits are in effect only when the system is locked.

The Menu System

Timers Feature

The Timers feature allows you to preset your system to automatically tune to a particular channel at a predetermined time.

To use the Timers feature, select *Timers* from the Main menu to bring up the Timers screen. Select a Timer (1-8) and then use the arrow keys to complete the on-screen sentence. When the sentence is complete, select *Run Timer*.



Complete the on-screen sentence to set up a timer.

Setting Up Timer Recordings

The Timers feature allows you to set up timer recordings when you connect the VCR Controller to your satellite receiver, and tell the receiver what type of VCR you are using.

Recording with Timer

If you choose *Record* instead of *Watch* when setting the Timer (and have set up your VCR as previously discussed), the Timer will toggle on your VCR, then start and stop recording a program.

To record with timers:

- Your VCR must be preset to the satellite output channel (RF or Line).
- Your VCR must be OFF at the time the program is to start recording.

4 Timers...

On-screen icons are an easy way to understand the timers.



indicates the timer is set.



indicates the timer is set for a PPV.



indicates a timer conflict.


When recording a PPV program, don't forget to purchase the program as well as set up the timer. Select *Buy and Record* to do both.

The Menu System

Schedule a Timer with the RECORD Button

You can schedule a recording directly from the guide.

1. With a program highlighted, press the RECORD button on the remote. The *Program Details* appears on-screen.



2. To schedule a timer to record, select:
 - *Record Program* to set a timer to record the program
 - *Buy and Record* to purchase the program and set up a timer to record the program. (Some *Buy and Record* programs may have a different purchase price.)

The options available to you may vary according to the type of program you select.

4 Timers...

Editing or Canceling a Timer

From the Timers screen, select the Timer you want to edit or cancel, and then do the following:

- Use the arrows keys to edit the Timer, then select *Run Timer*.
- Select *Clear Timer* to cancel the timer.
- To record the program on a daily or weekly edit that program's timer.

The Menu System

Profiles

When you select *Profiles* from the Main menu, the first screen you see is the *User Profiles* control panel. In addition to the Family profile, you can create as many as four different profiles that can be easily accessed by using the WHO button on the remote control.

You can personalize how the profile looks on-screen by entering a name and selecting a picture.



You can personalize each profile.

You can also edit the user profiles. Select a profile from the *Edit Users* control panel. By moving down the options you can create or edit the user's channel list, set a ratings limit, viewing hours, per-event spending limits and assign a profile password.

Creating a profile Channel List

1. Point to and select *Edit Users*, then choose a user.
2. Point to a channel list option and press MENU•SELECT.



To start, you can add or delete all channels.

3. Use the arrow keys to point to a channel, and press MENU•SELECT to remove (or replace) the check mark. Checkmarked items appear in the channel list.

5 Profiles...

You need to lock the system in order for rating limits, channel limits, viewing hours, and spending limits to go into effect. After you lock the system, you need to enter the system password to edit the limits. See "Locking the System" for details.

The Menu System

Add or Delete All Channels

You might be able to save time when creating a channel list by using the *Add All Chans* option or the *Delete All Chans* option to either add all channels or delete all channels before removing or adding individual channels.

Also, program providers may make additional channels available. To prevent new channels from appearing in a profile channel list, choose *Delete All Chans* and checkmark only the channels you want to appear in the list.

5 Profiles...

Setting the Ratings Limit

The Ratings Limit menu enables you to set a maximum viewing limit for rated movies (based on the MPAA ratings system), as long as the program provider has transmitted the proper code.

- Note that the ratings limit cannot be enforced if a program has not been rated, if rating information for that program is not transmitted by the program provider, or if the system has not been locked.
1. Point to *Set Rating Limit* and press MENU•SELECT.



Use the arrow keys to move the selector up and down.

2. Use the up and down arrows to move the rating selector to the highest rating you want to be able to view. In the preceding illustration, movies that are rated up to and including a "PG-13" rating can be viewed.

After the *Rating Limit* is set and the system is locked, you must enter the system password to watch programs with a rating higher than your limit.


The Menu System

Viewing Hours

5 Profiles...

Use the *Viewing Hours* option to limit the total amount of time, as well as the viewing hours a user can watch programming.

1. Point to *Viewing Hours*, and press MENU•SELECT.




You can limit viewing seven days a week.

2. Use the digits on the remote or point to the + or – and press MENU•SELECT to complete the on-screen sentence. Choose how many hours can be viewed each day (0-24 hours) and when programming can be viewed. Be sure to lock the system for these limits to take effect.

Setting Up Spending Limits

Select the *Spending Limit* option to indicate a per-event spending limit for pay-per-view programs.

1. Point to *Spending Limit*, and press MENU•SELECT.



You can set a per-event spending limit for each profile.

2. Use the digits on the remote or use the arrow keys to enter a single-program spending limit.

After a *Spending Limit* is set and the system is locked, you must enter the system password to purchase a pay-per-view program that costs more than your *Spending Limit* allows.

The Menu System

Locking a User's Profile

Each user can be assigned a personal password to lock his or her profile. When a password is assigned, the user must enter the password before he or she can view programs using that profile. Profile passwords do not allow access to, or editing of the profile limits. You must enter the system password to edit profile limits.

1. Point to *Lock User* and press MENU•SELECT.



Each user can have a password.

2. Use the arrow or digit keys to select each number of the password.

Locking the System

You can lock the system in order to put into effect the ratings, spending, viewing, and channel limits you have set up. When you lock the system, no one can modify any of these settings without first entering the four-digit system password.

1. Point to *Lock System* and press MENU•SELECT.



Locking the system protects the limits you set up.

2. Use the arrows or the digit keys to enter a four-digit system password.
3. Enter the password a second time to confirm it.

5 Profiles...

After the system has been locked, you must enter the correct password in order to access the *Edit Users* control panel.

Don't Forget Your Password

If you forget a USER password, you need to unlock the system and then assign a new user password.

If you forget the SYSTEM password, contact your program provider's authorization center.

The Menu System

Unlocking the System

When the system is unlocked, the channel, spending, viewing, and ratings limits, that you have set are no longer in effect.

1. Point to *Unlock System* and press MENU•SELECT.
2. Point to *Yes* and press MENU•SELECT to confirm that you want to unlock the system.

Session Unlock

If your system is locked and you attempt to access a channel or program that is blocked by one or more limits, you are asked to enter the four-digit system password to override the system lock.

If you enter the password to override the rating or spending limit, all limits are unlocked until you turn off the receiver. When you turn on the receiver again, the system will be locked, and the Family profile channel list will be selected. You can also re-lock the system by selecting the lock icon in the channel banner.

Choosing Your Profile

Each time that you turn on the receiver, the Family profile is selected by default. To select a different Profile:

1. Press the WHO button to scroll through the profiles.



The WHO button toggles through the profiles.

2. When your profile appears, enter your four-digit personal password to activate your profile.
 - If the profile is not password protected, you can just press MENU•SELECT to activate it.

The channel, spending, ratings and viewing limits will reflect the chosen profile only when the system is locked.

5 Profiles...



The Lock/Unlock icons in the channel banner provide an easy way to lock or unlock the system. Just point and select to change the lock status.

Green Unlock icon The system is unlocked. Spending, viewing and other limits can be accessed and changed.

Yellow Unlock icon A password has been entered to override family or profile limits. No limits can be accessed or changed.

Red Lock icon No limits can be accessed or changed. A password is required to override limits or access the system.

The Menu System

Options

The Options menu lets you set up personal preferences for the look and feel of the system as well as how some of the features work.

A grey arrow-shaped button with a circular icon containing a gear symbol on the left and the text "Options..." on the right.

The Options menu lets you change how the system works.

The following sections explain your options when changing your personal preferences. Follow the on-screen instructions to make changes to the system.

Interactive Setup

If you self-installed your satellite dish antenna, you may have already used the interactive setup to find the dish pointing coordinates, acquire and fine-tune the signal, and run a system test.

If you just want to check your dish pointing coordinates, or run the signal strength meter, select *Dish Pointing* from the Main menu.

System Info

Select *System Info* from the Options menu to choose from a list of on-line Help topics. Point and select to find out about the specific parts of the system, then use the right arrow key to continue through each of the Help screens or press MENU•SELECT to return to the Help menu.

Program Guide shows a screen-by-screen overview of the Program guide features.

Menu System shows a screen-by-screen overview of the system menus.

The Menu System

Remote Control shows an on-screen display of the remote control. Point to the different remote buttons to see a brief description of the highlighted button.

Front Panel shows an on-screen display of the satellite receiver front panel. Point to the different front panel features to see a brief description of the highlighted feature.

Back Panel shows an on-screen display of the satellite receiver back panel. Point to the different back panel features to see a brief description of the highlighted feature.

Glossary shows a list of common satellite system and TV terms. Point to a glossary item to see a brief description.

A grey arrow-shaped button pointing to the right. On the left side of the arrow is a small circular icon containing a gear. To the right of the icon, the text "Options..." is written in a light grey font.

Look and Feel

Default Guide lets you choose which guide appears first when you press the GUIDE button on the remote. The choices are Grid Guide, Detail Guide and SurfGuide.

Color Scheme lets you pick which color appears in the guides and menu system.

Translucency lets you choose the translucency of the menu displays. Slide the indicator bar to make the screens more opaque or less opaque.

Animation lets you turn animation on or off. Animation appears on-screen only when music channels are selected.

System Options

System Test The System Test display screen is accessed through the *Options* menu, and allows you to initiate diagnostic procedures on the system. You should use this feature to get your Access Card number, or when your receiver doesn't seem to be working correctly. There are four separate tests: signal, tuning, phone connection, and access card.

A message screen appears, telling you whether the system passed each test. If your system fails a test, run the system test several times before concluding that there is a problem. Occasional fluctuations in the phone line or satellite signal can give temporary false readings.

The Menu System

New Access Card Periodically, your program provider may issue you a replacement access card. The New Access Card Setup display screen allows you to transfer the information from the old card onto the new one.

Follow the display screen prompts to initialize your new card. Once you have transferred the information to the new card, your old card becomes invalid.

Because your specific account information is stored in the access card, power failures should have no effect on your system.

Set VCR Type To use the VCR controller feature, you need to tell the satellite receiver which VCR brand you are using.

1. Use the arrows or digit keys to input the correct code for your VCR brand. The VCR codes are located in the Reference section.
2. Follow the on-screen instructions to ensure that you are using the correct code. If the VCR automatically stops tape play, then you know that the receiver and the VCR are communicating.
 - Some VCR brands may not be capable of being controlled by the receiver.

Remote Setup Choose which remote button, SAT1 or SAT2, will control the receiver.

RF Remote Setup The remote can control the receiver using both IR (Infrared) signals and RF (radio frequency) signals. IR signals require line of sight to the receiver's front panel remote sensor. RF signals can control the receiver from other parts of your house—even through walls.

Occasionally, due to interference or other RF devices, you may need to change the remote and receiver RF code. To change the code:

Follow the on-screen instructions to change the remote RF code.

Picture Size The Picture size display screen allows you to choose between a standard TV screen and a Cinema option. A standard TV screen has an aspect ratio of 4:3; the Cinema option has an aspect ratio of 16:9.

Data Port Let's you choose whether the low speed data port is used for low speed data or communicating with the Home Control Base accessory. See the Home Control section in this book for more information.

A grey arrow-shaped button pointing to the right, containing a small circular icon with a right-pointing arrow and the text "Options...".

Options...

The Menu System

Audio Language

When you select *Audio Language* from the *Options* menu, the Audio Language display screen comes up.

Point to the audio language or audio type you want and press MENU•SELECT. The system will then automatically set the audio program to the selected audio program type when that type is available.

There are two ways to change the audio:

- Press ALT AUD on the remote to temporarily change the Audio program while tuned to the current channel.
- Point to *Audio Language* from the *Options* menu and press MENU•SELECT to set the default *Audio Language*.

Dolby Digital

Dolby Digital (when available) provides 6 independent soundtrack channels through the optical output jack. When connected to an optional, compatible 6-channel amplifier/receiver and speakers, this connection provides Dolby Digital Surround Sound.

When you select Dolby Digital from the Options menu select:

- Yes, to send a Dolby Digital audio signal (when available) through the Digital Audio Output jack on the back of the receiver to an optional, compatible 6-channel amplifier receiver.

Depending on your audio equipment, you can then choose *Dolby Digital* output, *PCM* (pulse mode modulation), or *Autoselect*. *Autoselect* is recommended for most situations.

- No, which provides a digital audio stream in PCM format.

Another method of changing the digital audio format is to press the ALT AUD button on the remote. Pressing this button cycles through any available language and audio types.


Alternate Data

Selects from among the available data on the current channel.

Options...

Important Digital Audio Information

The digital audio output jack is designed for connection to a digital audio receiver or decoder. The diagram below shows one example of the satellite receiver connected to a digital audio receiver. Check your equipment's user manuals for additional connection information.



Older digital equipment may not be compatible with the Dolby Digital bitstream. Such a connection can create a high level of noise that may be harmful to your ears, and could damage headphones or speakers.

If this problem occurs, try changing the digital output from *Dolby Digital* to *PCM*.

The Menu System

The Dish Pointing Menu Screen

7 Dish Pointing...

Follow these steps to obtain your dish pointing coordinates:


1. Turn on your television and satellite receiver.
2. Tune your television to the satellite receiver's output channel.
3. Press MENU•SELECT on the remote or front panel to bring up the Main menu.
4. Use the arrows to highlight the "Dish Pointing" option, and then press MENU•SELECT to access the dish pointing screen.

NOTE: The menu screen that you see may be slightly different from the one pictured here.




5. Use the arrows on the remote or the front panel to highlight "Zip Code" and then press MENU•SELECT.
6. Enter the zip code for the dish installation location.
7. Record the elevation and azimuth numbers below.

Elevation _____ Azimuth _____



Elevation is the up/down angle that the dish is pointed.



Azimuth is side to side direction that the dish is pointed.

You only need to use one of the available methods to find your dish pointing coordinates. If you know the zip code for the locality where the dish is being installed, use that.


The Menu System

Using the On-Screen Signal Meter

The signal strength meter is used to determine whether or not you are receiving the satellite signal, and it also indicates the strength of the satellite signal.

Follow these steps to bring up the on-screen signal meter:

1. Turn on your television and satellite receiver.
2. Tune your television to the satellite receiver's output channel.
3. Press MENU•SELECT on the remote or front panel to bring up the Main menu.
4. Use the arrows to highlight the "Dish Pointing" option, and then press MENU•SELECT to access the dish pointing screen.
5. Use the arrows on the remote or the front panel to highlight "Signal Meter" and then press MENU•SELECT.



If the dish is pointed to the correct azimuth and elevation, the signal meter will show you the current signal strength (and you should hear a continuous tone).

If you are not receiving a signal, you need to incrementally adjust the azimuth setting on the dish. After you receive a signal, you will want to continue to adjust the azimuth to try to get the best possible signal.

Important

Changing transponders is not the same as fine-tuning the dish. Although the signal strength may appear to change, this may be due to different types of interference. To fine-tune the dish, consult the Satellite Installation Guide and follow the instructions on adjusting the dish elevation and azimuth.

7 Dish Pointing...

Peak Signal

The "Peak Signal" indicates the highest signal strength you have obtained, which is not necessarily the highest possible signal.

While the maximum signal strength is 100, the signal strength you achieve will probably be less. Although there is no difference in picture quality between a signal strength of 60 and 85, the higher the signal, the less likely you are to experience negative effects in degraded conditions such as rain or snow (called "rain fade").

The Menu System

Home Control

Home Control lets you remotely control several lamps and appliances through your satellite receiver.


Home Control setup

The Home Control Data Interface connects to the LOW SPEED DATA port on the back of the receiver. Once connected, you must tell the receiver to use this port for Home Control.

1. Press MENU•SELECT to bring up the Main menu.
2. Point to and select *Options*.
3. Point to and select *System Options*.
4. Point to and select *Data Port* and choose *Home Control* as the default setting

Device Setup

1. From the Main menu select *Home Control*.



Home Control can control several devices.


2. Select a device you would like to control.
3. Complete the on-screen sentence using the arrow buttons and MENU•SELECT. Press MENU•SELECT to scroll through the lists of appliances and locations.



Keep track of devices by assigning a label.

Home Control...

To control devices, you must connect a Home Control Data Interface to the receiver and a remote module to the device you want to control. The Home Control Data Interface connects to the LOW SPEED DATA port on the back of the receiver.



LOW SPEED DATA PORT

Once connected, you must tell the receiver to use this port for Home Control.

These devices are available as accessories sold through your satellite dealer or the accessories order form at the back of this book.

The Menu System

- Use the arrow buttons and MENU•SELECT to select the house and module codes that match the device's remote module and label the module. Select *Save Setup* to complete the setup.



Device Control

Once the device is set up, there are two ways to control it; with the menu system, or with a timer. Select a device from the Home Control menu screen. You can then; turn it on, turn it off, or adjust the brightness for lamp modules.

Select *Edit Setup* to change a device.



Control the device from the menu.

To schedule a timer:

- Select *Set Timer*.
- Schedule a timer by completing the on-screen sentence.



Complete the on-screen sentence to schedule a timer.

- Use the arrows and MENU•SELECT to enter an *on* and *off* time.
- Point to and select *Run Timer*.

Clear Timer removes all the timer information.

Suspend turns off the timer, but saves the timer information.

On-screen icons are an easy way to understand the timers.



indicates the timer is set.




indicates the timer is suspended.

You can schedule several timers to control the same device at different times.

The Menu System

Fetch Menu

The Fetch menu is a list of favorite menu items that you define. Press the FETCH button on the remote. The Fetch menu appears. You can select up to eight menu items to appear in this menu.



The Fetch menu is a convenient way to call up frequently used menu items.

Customize the Fetch Menu

To add an item to the Fetch menu, you must first point to an item in the menu system. Not all menu items can be added to the Fetch menu.

For example, you can add the *System Info* menu item to the Fetch menu.

1. Press MENU•SELECT to bring up the Main menu.
2. Point to and select *Options*
3. Point to *System Info*, but do not select it. Instead, press FETCH on the remote. The Fetch menu appears.
4. Use the arrow up and down arrow buttons to point to where the new Fetch item should appear.
5. Press MENU•SELECT to confirm the selection.

These menu items can be placed in the Fetch menu.

- The Guides
- Edit Users
- Signal Meter
- Audio Language
- System Options
- System Test
- New Access Card
- Set VCR Type
- Remote Setup
- Picture Size
- RF Remote Setup
- Dolby Digital
- Interactive Setup
- System Info
- Translucency
- Default Guide
- Color Scheme

Reference

How It All Works

Although the system is simple to use, there are a number of parts in the system. Don't be overwhelmed. This section explains how these different parts work together to bring a picture to your screen.

What's It For?

This section also describes the controls located on the front and back of the receiver.

What Else Can it Do?

Your remote is capable of controlling other devices as well. This section tells you how to program the remote to control TVs, VCRs, Laserdisc players, and other equipment.

1 First Things First



2 Program Guides



3 The Menu System



4 Reference




5 Appendices

Reference

Parts of the System

One way to understand the system is to look at the different parts of the system—from the studio down to the satellite receiver and remote control in your living room.



World View

These parts make up the system “big picture.”

Uplink Center Transmits programming up to the satellite.

Satellite Relays the programming signals back to your satellite dish. The satellite is parked above the equator, in geostationary orbit 22,300 miles above the earth.


Satellite Dish Antenna Receives the satellite signals. Because the satellite is so powerful, the dish can be as small as 18 inches.

Program Provider Authorization Center Processes billing statements. Your system is linked to the Service Center through the phone jack on the back of your satellite receiver.

Reference

Home View

These parts are inside of or attached to your house.



Satellite Dish Antenna Picks up the satellite's coded program information and relays it to your receiver. (Your satellite dish may be installed in different locations on or around your house. The satellite dish antenna must, however, be pointed in a southern direction toward the satellite.)

Satellite Receiver Receives the TV program information and sends it to your TV or VCR.

Telephone Jack Connects to the phone jack on the back of the receiver. The receiver uses a toll-free number once a month to update your access card. This update only takes a few seconds and ensures that you will have continuous service. The system automatically hangs up if you pick up the phone when the receiver is calling out.

Television If your television is remote controllable, you can program the Universal TV Remote to change channels and volume.


Universal Remote (included with your system) Controls the system as well as most remote controllable TVs, VCRs, and other devices. Point the remote at the device you want to control.

Access Card (installed in receiver) Must be inserted for you to use the system! Provides system security and authorization of satellite services. Do not remove the card except when issued a new card as a replacement for the original.

Reference

Controls and Buttons

This part of the Reference sections discusses the controls and buttons located on the receiver and the remote control.



The Access Card door slides open so that you can replace the card when necessary.

Front Panel Controls

ON/OFF Turns the receiver's power on or off.

INFO Brings up the on-screen channel banner.


ANTENNA Switches the source of the video signal from satellite signals to an off-air antenna or cable signal.

ARROWS Press the navigation arrows to move the on-screen highlight up, down, left, or right. Using the arrows to highlight a menu item is also called "pointing." The up and down arrows also change channels.

MENU•SELECT Brings up the Main menu. If you are already in the menu system, press MENU•SELECT to select a highlighted choice.

ACCESS CARD Identifies you to your program providers. The system requires a valid access card.

Reference



Back Panel Controls

OUT TO TV Use to connect the receiver to your TV. However, if your TV has audio/video jacks, you should use those jacks to get better picture and sound quality.

IN FROM ANT Use to connect an off-air antenna or cable TV signal to the system.

CH3/CH4 SWITCH If a coaxial cable is used to connect the receiver to your TV, you must set the CH3/CH4 SWITCH. For example, to see the satellite signal on TV channel 3, set the switch to 3.

S-VIDEO Provides the best picture quality. If your TV has S-VIDEO capability, use this jack along with the audio/video jacks to connect the receiver to your TV.

VIDEO Provides better picture quality than the OUT TO TV jack. If your TV has audio/video capability, use this jack to connect the receiver to your TV. You must also connect the AUDIO jacks.

AUDIO (R and L) Provide better sound quality than the OUT TO TV jack. If your TV has audio/video capability, use these jacks to connect the receiver to your TV. You must also connect the VIDEO jack.

Digital Audio Output Provides up to 6 independent soundtrack channels (when available) through the optical output jack, when connected to an optional, compatible amplifier/receiver and speakers.

AUX RF ANT IN Use to connect an optional RF antenna for RF remote signals. Connecting an antenna extends the remote's range.

VCR CONTROL Allows the receiver to control your VCR.

SATELLITE IN Use to connect the receiver to the satellite dish antenna.

LOW SPEED DATA PORT This port allows you to connect the system to accessories, such as the Home Control base module.

PHONE JACK Use to connect a phone line to the receiver. The system requires a phone line connection to periodically call out to program providers.

Reference

Remote Control Buttons

POWER Turns the device you are controlling on or off.

TV Tells the remote to control the TV.

VCR Tells the remote to control the VCR.

AUX Tells the remote to control an alternative device connected to your TV.

SAT1/SAT2 Lets you control two satellite receivers. Turns on the receiver and tells the remote to control system functions. SAT1 is the default. Choose SAT2 in the *System Options* control panel.

GUIDE Brings up the on-screen program guide. Press the GUIDE button several times to toggle through the different types of guides.

FETCH Brings up the Fetch menu. Use the arrows and MENU•SELECT to point and select a menu item.

WHO Press the WHO button one or more times to toggle through your user profiles.

CLEAR Removes the on screen displays and return to normal viewing.

MENU•SELECT Brings up the Main menu. If you are already in the menu system, press MENU•SELECT to select a highlighted choice.

ARROWS Use the navigation arrows to move the on-screen highlight up, down, left, or right. Using the arrows to highlight a menu item is also called "pointing."


INFO Brings up the on-screen channel banner. Press again to get program details.

ALT AUD (Alternate Audio) Use to toggle through the available languages or audio types for a program.

MUTE Turns off the sound. Press again to restore the sound.

GO BACK Moves you back and forth between your last two selected channels. In the menu system, returns you to the previous screen.

CHAN UP/DOWN Use to scan up and down through the channels in the current channel list. If you are in the program guide or menu system, use the CHAN UP/DOWN buttons to page up and down a screen at a time.



Reference

VOL UP/DOWN Adjusts the audio volume.

DIGIT KEYS (0 - 9) Use the digit keys to tune directly to a channel. If you are in the menu system, use the digit keys to enter numbers for the time, date, channel and passwords.

INPUT In TV and VCR mode, press the INPUT button one or more times to toggle through the available video inputs.

ANT Lets you switch the source of the video signal from satellite signals to an off-air antenna or cable signal.

TRANSPORT Buttons (REVERSE, PLAY, FORWARD, RECORD, STOP, PAUSE) Use when controlling an auxiliary device, such as a VCR or Laserdisc player. Note that the RECORD button is used to schedule a timer recording when using a program guide.

Programming the Remote Control

The remote can be programmed to control most brands of remote controllable TVs, VCRs, and cable boxes. The remote is programmed to control most RCA, GE and ProScan TVs and VCRs. The remote needs to be programmed to control other manufacturers' brands.

Using the Remote to Control a Second Satellite Receiver

The remote can control two satellite receivers. From the Main menu, select *Options*, then *System Options*, then *Remote Setup*. Choose which button, SAT1 or SAT2, will control the receiver.

Changing the RF Remote Code

The remote can control the receiver using both IR (Infrared) signals and RF (radio frequency) signals. IR signals require line of sight to the receiver's front panel remote sensor. RF signals can control the receiver from other parts of your house—even through walls.

Occasionally, due to interference or other RF devices, you may need to change the remote and receiver RF code. Change the code in the *System Options* menu.

Reference

Programming the Remote to Control Your TV

To determine whether your remote needs to be programmed, turn the TV on, point the remote at the TV, and press the TV button. Then press CHAN UP or DOWN to see whether the TV responds to the remote commands.

Follow these steps to program your remote to control your TV.

1. Turn on the TV.
2. Look up your brand and code number(s) on the TV Code list on the following pages.
3. Press and hold the TV button.
4. Enter the code from the code list.
5. Release the TV button and press OFF•ON or CHAN UP/DOWN to see if the TV responds to the remote commands. If it doesn't, try the next code listed for your brand.
6. Repeat these steps until the TV responds to the remote commands.

This remote may not operate all models of the brands that are shown. Use the codes shown in this manual, or on the sheet packed with your remote.

After you program the remote to control your TV, record your TV code here for easy reference.

000

Programming the Remote to Control Your VCR

To determine whether your remote needs to be programmed, turn the VCR on, point the remote at the VCR, and press the VCR button. Then press POWER or CHAN UP or DOWN to see if the VCR responds to the remote commands.

Follow these steps to program your remote to control your VCR:

1. Turn on the VCR.
2. Look up your VCR brand and its code number on the code list on the following pages.
3. Press and hold the VCR button.
4. Enter the code from the code list.
5. Release the device button and press POWER or CHAN UP/DOWN to see if the VCR responds to the remote commands.
6. Repeat these steps using the next code listed for your brand until the VCR responds to the remote commands.

This remote may not operate all models of the brands that are shown. Use the codes shown in this manual, or on the sheet packed with your remote.

After you program the remote to control your VCR, record your VCR code here for easy reference.

000

Reference


Programming the Remote to Control Other Devices

The AUX button is a device button that can be programmed to control a second VCR, a cable box, or a laserdisc player.

1. Turn on the device to be programmed.
2. Look up your brand and its code number on code list on the following pages.
3. Press and hold the AUX button.
4. Enter the three-digit code from the code list.
6. Release the AUX button and press POWER or CHAN UP/DOWN to see if the device responds to the remote commands.
7. Repeat these steps using the next code listed for your brand until the device responds to the remote commands.

This remote may not operate all models of the brands that are shown. Use the codes shown in this manual, or on the sheet packed with your remote.

After you program the remote to control a device, record your AUX code here for easy reference.



Using the Remote Buttons to Control a Device

Once the remote has been programmed with the correct codes, you are ready to use it to control your devices.

To operate the device:

1. Press the device button (TV, SAT1, SAT2, VCR, or AUX) to set the remote to control the device.
2. Press POWER to turn the device off or on.
3. Use the remote buttons that apply to that device.

Reference

Remote Codes

TV Codes

A-Mark	102	Kawasho	002, 011, 027	Sampo	011, 027
Admiral	005, 114	Kenwood	006, 011, 014, 027	Samsung	006, 011, 014, 015, 019, 027, 036, 037, 077, 110
Akai	002, 103	Kloss Novabeam	035, 043	Sanyo	017, 021, 039, 056, 057, 058
Amtron	064	KTV	078	Scott	028, 037, 064
Anam	104, 105	Loewe	013	Sears	000, 006, 011, 014, 017, 018, 021, 023, 027, 039, 040, 041, 051, 071, 083, 095
Anam National	038, 106	Luxman	011, 027	Sharp	011, 020, 025, 027, 037, 052, 053, 059, 060, 108
AOC	011, 019, 027, 088, 107	LXI	000, 013, 018, 021, 023, 054	Signature	005, 094, 108
Bell & Howell	005, 013	Magnavox	006, 007, 010, 011, 013, 016, 027, 033, 035, 043, 049, 066, 087, 089	Sony	002
Candle	011, 027, 033	Marants	013	Soundesign	011, 027, 033
Citizen	011, 027, 033, 064	Marantz	011, 013, 027, 069	Sylvania	006, 007, 010, 011, 013, 016, 027, 033, 035, 043, 049, 066, 087, 089
Colortyme	011, 027, 084	Memorex	005	Symphonic	064, 076, 115
Concerto	011, 027	MGA	006, 011, 014, 019, 022, 027, 041, 056, 061, 068	Tatung	038
Contec/Cony .	036, 037, 040, 042, 064	Mitsubishi	006, 011, 014, 019, 022, 027, 041, 055, 056, 061, 068, 108, 117	Technics	012
Craig	064	MTC	011, 019, 027	Techwood	011, 027
Curtis Mathes	000, 011, 015, 027, 037	Multivision	081	Teknika	011, 019, 027, 033, 036, 037, 040, 066
CXC	064	NAD	018, 023	Telecaption	090
Daewoo	011, 019, 027, 112, 116	NEC	011, 014, 019, 027, 038, 084	TMK	011, 027
Daytron	011, 027	Panasonic	012, 013, 038, 086, 111	Toshiba	018, 021, 023, 040, 071, 077, 085, 090
Dimensia	000	Penney .	000, 008, 011, 019, 027, 040, 068, 077, 086, 088	Universal	008, 009
Electrohome	006, 011, 014, 027, 038, 061, 068	Philco ...	006, 007, 010, 011, 013, 016, 019, 027, 033, 035, 037, 038, 043, 087, 089	Victor	051
Emerson	011, 026, 027, 028, 029, 030, 031, 032, 037, 042, 053, 064, 065, 067, 075, 076, 078, 079, 094, 095, 096	Philips	002, 006, 007, 010, 011, 013, 016, 033, 035, 037, 038, 043, 066, 073	Vidtech	019, 027
Envision	011, 027	Pioneer .	011, 027, 045, 062, 093, 113	Wards	000, 005, 006, 007, 008, 009, 010, 011, 013, 019, 025, 027, 028, 035, 043, 059, 066, 076, 082, 089
Fisher	017, 021, 039, 041	Portland	011, 019, 027, 037	Yamaha	006, 014, 019, 027
Funai	064	ProScan	000	Zenith	001, 099, 114
GE	000, 008, 009, 011, 012, 027, 038, 068, 086, 089, 091, 116	Proton	011, 027, 037, 072, 118		
Goldstar	003, 004, 006, 011, 019, 027, 037, 050	Quasar	012, 038, 092, 111		
Hallmark	011, 027	Radio Shack	000, 021, 025, 036, 037, 059, 064, 078		
Hitachi	009, 011, 027, 036, 037, 040, 047, 048, 063, 080, 094, 097, 098	RCA	000, 006, 011, 019, 027, 034, 038, 044, 046, 088, 100, 101, 109		
Infinity	013	Realistic	021		
JBL	013				
Jensen	011, 027				
JVC	012, 024, 036, 037, 040, 048, 051, 074				

Laserdisc/DVD Player Codes

RCA	033, 037
RCA (DVD Player)	078
Pioneer	033, 033
ProScan	033, 037

Reference

VCR Codes

Admiral	006, 079	JVC	002, 014, 016, 030, 046, 074	Samsung	007, 013, 022, 032, 042
Aiwa	015	Kenwood	002, 014, 016, 030, 044, 046	Sansui	016, 071
Akai	003, 017, 022, 023, 063, 066	KLH	073	Sanyo	002, 012
Audio Dynamics	014, 016	Lloyd	015	Scott	004, 013, 041, 049, 068
Bell & Howell	002	Logik	031	Sears	002, 005, 009, 012, 018, 019, 035, 043, 048
Broksonic	010	Magnavox	008, 029, 053, 056	Sharp	006, 024, 027, 039, 045
Candle	007, 009, 013, 044, 045, 046, 052	Marantz	002, 008, 014, 016, 029, 030, 044, 046, 061	Shintom	017, 026, 031, 055
Canon	008, 053	Marta	009	Signature	015
Capehart	001	MEI	008	Sony	017, 026, 038
Citizen	007, 009, 013, 044, 045, 046, 052	Memorex	008, 009, 012, 015	Sylvania	008, 015, 029, 053, 056
Colortyme	014	MGA	004, 027	Symphonic	015
Craig	007, 012	Midland	032	Tandy	002, 015
Curtis Mathes	000, 007, 008, 014, 015, 044, 046, 053, 064, 067	Minolta	005, 035	Tashiko	009
Daewoo	013, 045, 052, 076	Mitsubishi	004, 005, 027, 035, 040	Tatung	030
dbx	014, 016	Montgomery Ward	006	Teac	015, 030, 069
Dimensia	000	MTC	007, 015	Technics	008
Dynatech	015	Multitech	007, 015, 031, 032	Teknika	008, 009, 015, 021
Electrohome	027	NEC	002, 014, 016, 030, 044, 046, 059, 061, 064	Toshiba	005, 013, 019, 048, 049
Emerson	008, 009, 010, 013, 015, 020, 023, 027, 034, 041, 042, 047, 049, 057, 062, 065, 067, 068, 070	Panasonic	008, 053, 075, 077	Totevision	007, 009
Fisher	002, 012, 018, 019, 043, 048, 058	Pentax	005, 035, 044	TMK	067
Funai	015	Pentex Research +	046	Unitech	007
GE	000, 007, 008, 032, 037, 053	Philco	008, 029, 053, 056	Vector Research	014, 016, 044
Goldstar	009, 014, 046, 060	Philips	008, 029	Victor	016
Harman Kardon	014	Pioneer	005, 016, 050	Video Concepts	014, 016, 044
Hitachi	005, 015, 035, 036	Portland	044, 045, 052	Videosonic	007
Instant Replay	008	ProScan	000	Wards... ..	005, 006, 007, 008, 009, 012, 013, 015, 025, 027, 031, 035
JCL	008	Quartz	002	Yamaha	002, 014, 016, 030, 046
JC Penney	002, 005, 007, 008, 014, 016, 030, 035, 051, 053	Quasar	008, 053	Zenith	011, 017, 026, 072, 079
		RCA	000, 005, 007, 008, 028, 035, 037, 054, 069		
		Radio Shack/Realistic ..	002, 006, 008, 009, 012, 015, 019, 027, 043, 053		

Cable Box/Satellite Receiver Codes

ABC	022, 046, 053, 054	NSC	009	Sprucer	027
Anvision	007, 008	Oak	001, 016, 038	Starcom	046
Cablestar	007, 008	Oak Sigma	016	Stargate 2000	058
Diamond	056	Panasonic	003, 027, 039, 061	Sylvania	011, 059
Eagle	007, 008	Philips	007, 008, 019, 021, 026, 028, 029, 032, 033, 040, 041	Teknika	006
Eastern Int.	002	Pioneer	018, 020, 044	Texscan	010, 011, 059
General Instrument	046	RCA	000, 027	Tocom	017, 021, 049, 050, 055
GI 400	004, 005, 015, 023, 024, 025, 030, 036	RCA (Satellite Receiver)	066	Unika	031, 032, 041
Hamlin	003, 012, 013, 034, 048	Randtek	007, 008	Universal	051, 052, 060
Hitachi	037, 043, 046	Regal	003, 012, 013	Viewstar	007, 008, 019, 021, 026, 028, 029, 032, 033, 040, 041
Jerrold	004, 005, 015, 023, 024, 025, 030, 036, 045, 046, 047, 062, 065	Regency	002, 033	Warner Amex	044
Macom	037, 043	Samsung	044	Zenith	014, 042, 057, 061
Magnavox	007, 008, 019, 021, 026, 028, 029, 032, 033, 040, 041	Sci. Atlanta	003, 022, 035, 063, 064		
		Signature	046		
		Sony (Satellite Receiver)	095		

Reference

Glossary

The following is a list of terms used in this manual. There is also a glossary contained within the *System Info* menu of your system.

Access Card

Identifies you to the system service providers and is required for your system to work. Do not remove the access card except when a new card has been issued to replace the original.

Attractions

Previews of special programs broadcast by your program provider.

Audio Language

Refers to the different audio channels that may be broadcast in conjunction with a video program. A foreign language translation is an example.

Azimuth

Refers to the left-to-right positioning of your satellite dish antenna. When you enter your zip code (or latitude and longitude), the display screen provides the number corresponding to an azimuth setting for your location.

Channel Banner

Displays program information and menu items displayed as icons when you tune to a channel, exit a guide or press INFO on the remote. Point to and select the icons to access the menu items.

Channel List

Allows you to select which channels can be viewed when the system is locked.

Dish Pointing

The dish antenna must be pointing directly to the satellites to receive the satellite signal. Obtain dish pointing coordinates and check signal strength in the *Dish Pointing* menu screen.

Satellite Receiver

Receives, processes, and converts the digitally compressed satellite signals into audio and video.

Elevation

Refers to the up and down positioning of your satellite dish antenna. When you enter your zip code (or latitude and longitude), the display screen provides the number corresponding to the elevation setting for your location.

Home Control

Home Control lets you remotely control several lamps and appliances through your receiver. To control these devices, you must connect a Home Control base module to the receiver and a remote module to the device you want to control.

Limits

The Ratings Limit allows you to control program viewing of rated programs by ratings level. The Spending Limit controls spending on a cost-per-program basis. The Viewing Limit controls *when* and *how many hours* a user can view programming. The Channel List allows you to select which channels can be viewed when the system is locked.

Locks

The means of restricting access to certain features of the system. The lock is controlled by a 4-digit password. The closed or open lock icon in the channel marker indicates whether your system is locked or unlocked.

Reference

Mailbox

Stores incoming electronic messages sent to you by your program providers. The Mailbox is accessed through the on-screen menu system.

Main Menu

The first list of choices in the system on-screen menus. Press the MENU button on the remote or front panel to bring up the Main menu.

Past Purchases

Detailed list of the programs that you have already purchased and viewed.

Point and Select

The method of using the remote control (or front panel) buttons to navigate to and make choices among the different parts of the on-screen displays.

Profiles

Allows you to create lists and limits for individual users, as well as set up limits for the whole system.

Program Guide

Lists the programs and services available from your program providers.

Ratings Limit

Provides a means of restricting viewing of rated programs, based on program rating information. The operation of this feature depends upon the availability and accuracy of data supplied from and broadcast by the program provider.

Signal Meter

An on-screen display that indicates the relative strength of the satellite signal and sounds a test tone to help you lock in on the satellite signal. The signal meter is used when you adjust your satellite dish antenna.

Spending Limit

Provides a means of restricting viewing, based on cost-per-program limit.

System Test

Provides a diagnostics check that can be used to determine that the main components of the satellite system—signal, tuning, phone, and access card—are connected and working properly.

TV/SAT Buttons

Remote control buttons that toggles the input signal to your TV from the antenna or cable signals to the satellite signal. Similar in function to that of TV/VCR buttons on some VCRs and remote controls.

Themes

Provides a way to simplify the Program Guide and make it easier to find programs of special interest to you.

Topics

Use the Topics screen to sort the guide to show only programs of a particular topic, such as Movies or Sports.

Upcoming Purchases

Detailed list of the programs you have purchased but have not yet been broadcast.

Reference

Troubleshooting

The System Test allows you to run a basic diagnostics check on your satellite system. If you are experiencing any trouble with your system, run the system test.

Make sure that

- All connections—jacks, cables, etc. are correctly in place. See the section, *Connecting Your Receiver*, for more information.
- There are batteries in the remote, and that they are working correctly.
- The access card is installed in the receiver.

Running the System Test

Follow these steps to run the diagnostics system test on your system.

1. Turn on your TV and the receiver.
2. Press SAT to put remote in satellite system mode, then press MENU•SELECT to bring up the Main menu.
3. Point to and select *Options*.
4. Point to and select *System Options*.
5. Point to and select *System Test*.
6. If your system does not pass the system test, check any of these potential trouble areas: cabling, pointing the satellite dish, phone connection, and access card.
7. If you continue to have problems, call 1-800-679-4776.

Appendix A: Warranty Information

Repair Help

Thomson Consumer Electronics offers hardware repair service should you encounter any problems with your system. Many problems can be diagnosed over the phone, or if necessary, a replacement unit can be shipped to you. Please have your system model, serial number and date of purchase ready when you call. If your unit is out of warranty, we will quote the cost of an exchange unit to you. Refer to RCA Satellite System Limited Warranty for the repair service phone number.

Returning Equipment to Thomson for Repair or Exchange

If we are unable to resolve your problem over the phone we will gladly service your unit or exchange it for a new or refurbished unit. Refer to the limited warranty included in the booklet to learn about your specific rights and responsibilities. *Always consult Thomson and get a Return Authorization number before returning anything.* Obtain a Return Authorization (RA) number from the telephone representative before returning your equipment to avoid delays, accounting errors, or even loss of your unit.

Important Information to Customers Who Ship Defective Equipment to Thomson Consumer Electronics

The Thomson representative who authorizes the return of your equipment will give you an RA number over the phone. The representative will also provide you with instructions on where and how to return your unit. Write the number in large, clear characters on the outside of the box. *To avoid confusion and misunderstandings, shipments without an RA number clearly visible on the outside of the box will be returned to you at your expense.*

Include a brief note describing the problem and any conversations you have had with Thomson personnel about the problem. Include your name, address and model/serial number of your unit. These numbers are located on the back of your receiver. If your system is within the warranty period, please provide a copy of the bill of sale to verify purchase date. Use the original box and packing material to protect the equipment from damage in shipment. *For your protection, insure all shipments for full replacement value and use a reliable shipper.* Thomson assumes no responsibility for warranty shipments from the customer to the factory if not shipped in the manner prescribed by Thomson.

RCA SATELLITE SYSTEM LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- 90 days - Unit exchange, which includes parts and labor.
- 91 days to 1 year - Unit exchange, which includes parts only; you pay the labor.
- The warranty for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.

What we will do:

- During the initial 90 days:
Exchange the defective portion of your satellite receiver with a new or, at our option, refurbished unit.
- After the 90 days and within one year:
Exchange the defective portion of your satellite receiver with a new or, at our option, refurbished unit. We will charge you a flat exchange cost to replace a defective receiver. This charge covers the labor cost for its repair.

Appendix A: Warranty Information

How you get service:

- Call 1-800-679-4776 and have your unit's date of purchase and model/serial number ready. The model/serial number information is on the back of your receiver.
- A representative will troubleshoot your problem over the phone.
- If the representative determines that you should receive a replacement receiver you will be provided with a Return Authorization (RA) number and the location of a nearby exchange point if one exists. No returns will be accepted without the RA number.
- If the representative determines that your antenna/dish is defective they will arrange for its repair or replacement.

Option I:

1. Provide your Discover, Mastercard or Visa account number and expiration date to your phone representative. This is for security purposes only and your account will not be charged at this time.
2. We will send you a replacement unit.
3. If you return the unit to us within 14 days from the date you were provided a RA number, only items not covered by warranty will be charged to your account. If your unit is not received within 14 days, the suggested retail value of the receiver will be charged to your credit card. This amount will be credited, less a \$10 handling fee, if the unit is subsequently received.
4. Ship your defective unit back to us using the replacement unit's carton. Shipping instructions will be included on the carton along with your RA number which will allow you to easily ship the unit back to us. Make sure you insure your shipment in case of damage or loss. Include with the shipment:
 - Evidence of purchase date such as a bill of sale.
 - A brief note describing your receiver problem.
 - Your name, address and phone number.

Option II:

1. We will send a replacement unit to our exchange point.
2. The exchange location will notify you of its arrival.
3. Take your unit and evidence of purchase date, such as a bill of sale, to the exchange location and you will be provided the new or refurbished unit. Please retain all accessories such as the remote control hand unit.
4. If the repairs are covered by your warranty, you will not be billed. Thomson assumes no responsibility of warranty shipments from the customer to the factory if not shipped in the manner prescribed by Thomson.

To receive a replacement receiver after we have received your unit:

- Write the RA number on the outside of the carton used to return the unit. Make sure you insure your shipment in case of damage or loss.
- Carefully pack the unit using the original box and packing material if possible. Please retain all accessories that were included with your unit such as the remote control hand unit.
- Include with the shipment:
 1. Evidence of purchase date such as a bill of sale.
 2. A brief note describing your receiver problem.
 3. Your name, address and phone number.
- The representative will advise the address to mail a cashier's check or money order for payment if there are any out of warranty labor or parts charges, and you elect not to use your credit card.
- After we receive your product, a new or refurbished unit will be shipped to you.

Appendix A: Warranty Information

What your warranty *does not* cover:

- Acts of God, such as but not limited to lightning damage.
- Adjustment of customer controls.
- Damage from misuse or neglect.
- A unit that has been modified or incorporated into other products or is used for institutional or other commercial purposes.
- Batteries.
- Units purchased, serviced or operated outside the U.S.A. and Alaska.
- For units intended for use in Alaska, this warranty does not cover installation or the dish antenna. It covers only the satellite receiver.
- Loss of programming.
- Installation.
- Shipping damage if the unit was not packed and shipped in the manner prescribed by Thomson.
- Storage fees may be charged by the exchange point if you fail to pickup the replacement unit in a timely manner.

Product Registration:

- Please complete and mail the Product Registration Card packed with your product. It will make it easier to contact you should it ever be necessary. The return of the card is not required for a warranty coverage.

How state law relates to warranty:

- This warranty gives you specific legal rights and you may have other rights that vary from state to state.

If you purchased your product outside the United States:

- This warranty does not apply. See your dealer for warranty information.

Appendix B: FCC Regulations

FCC Registration Information

Your system equipment is registered with the Federal Communications Commission and is in compliance with parts 15B and 68, FCC Rules and Regulations.

1. Notification to the Local Telephone Company.

On the bottom of this equipment is a label indicating among other information, the FCC Registration number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful to determine the number of devices you may connect to your telephone line and still have all these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Notes: This equipment may not be used on coin service provided by the telephone company.

Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.

Notice must be given to the telephone company upon permanent disconnection of your system equipment from your line.

2. Rights of the Telephone Company.

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance (2) afford you the opportunity to correct the situation and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations of procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Radio Interference


This equipment has been type tested and found to comply with the limits for a Class B Digital Device in accordance with the specifications in Part 15 of FCC Rules. These rules are designed to provide reasonable protection against radio and television interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception (which you can determine by turning the equipment off and on), try to correct the interference by one or more of the following measures.


- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Change the position of the satellite receiver with respect to the radio or television equipment that is receiving interference.
- Move the satellite receiver away from the equipment that is receiving interference.
- Plug the satellite receiver into a different wall outlet so that the satellite receiver and the equipment receiving interference are on different branch circuits.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.


Appendix C: Accessories




RG-6 Coaxial Burial Cable with weatherproof "F" connectors



Self-Installer's Kit contains cable and hardware to install the dish and connect the system.



Remote Control replaces a lost remote. Or, order a second remote for convenience.



HCDSS10 Home Control Kit contains a Data Interface that connects to the receiver, and a lamp module.



HC10LM Lamp module lets you control incandescent lamps. Use to dim/brighten and turn lamps on/off.



HC20AM or HC30AM Appliance modules turn small appliances, like coffee pots, popcorn makers, or stereo, on or off. Also controls non-incandescent lamps Choose 2 prong (HC20AM) or 3 prong (HC30AM).



Detach Here

Accessory Order Form for Satellite Systems

Description	Part No.	Price	Qty	Total
<i>RG-6 Coaxial Cable</i>				
12 feet	D912	\$12.95		
25 feet	D925	\$15.95		
50 feet	D950	\$21.95		
75 feet	D975	\$29.95		
100 feet	D901	\$35.95		
S-Video Cable 12 feet	D913	\$12.95		
Weatherproof "F" Connector (2)	D905	\$ 5.30		
TVRO Bullet Amplifier	D903	\$24.95		
Self-Installer's Kit	DKIT96	\$69.95		
Remote Control	232578	\$40.45		
Home Control Kit	HCDSS10	\$59.95		
Lamp Module	HC10LM	\$14.95		
2-Prong Appliance Module	HC20AM	\$16.95		
3-Prong Appliance Module	HC30AM	\$16.95		

Prices are subject to change without notice.

Total Merchandise \$ _____

Sales Tax \$ _____

We are required by law to collect the appropriate sales tax for each individual state, country, and locality to which the merchandise is being sent.

Shipping, Handling, and Insurance \$ 5.00

Total Amount Enclosed \$ _____

Use VISA, MasterCard, or Discover preferably.
Money order or check must be in U.S. currency only.
No COD or CASH.

All accessories are subject to availability.

Please complete other side also

Appendix C: Accessories

Charge your order on your VISA, MasterCard, or Discover Card by filling in below

USE YOUR CREDIT CARD

IMPORTANT: Copy complete account number from your VISA card



My card expires:

IMPORTANT: Copy complete account number from your MasterCard



Copy Number above your name on MasterCard My card expires:

IMPORTANT: Copy complete account number from your Discover Card



My card expires:

AUTHORIZED SIGNATURE
 (Credit card order will not be processed without signature)
 Prices are subject to change without notice.

Print or type your name and address clearly.



A complete and correct order will save you days of waiting.

Name: _____

Street: _____

_____ Apt: _____

City: _____

State: _____ Zip: _____

Please make sure that both sides of this form have been filled out completely.

- Allow 4 weeks for delivery.
- All accessories are subject to availability.
- Prices are subject to change

United States and Canada Orders

To place your order by phone, have your Visa, MasterCard or Discover Card ready and call the toll-free number listed below between 8AM and 10PM (EST) Monday through Friday or between 9AM and 5PM (EST) Saturday.

Use this number only to place on order for accessory items listed on this order form.

1-800-338-0376

To place your order by mail, detach and mail the completed order form with credit card information, money order or check in US currency (made payable to Thomson Consumer Electronics, Inc.) to the following address:

Video Accessories
 PO Box 8419
 Ronks, PA 17573

Index

A

- Access card 57
 - number 16
- Accessories 73
- All button 24
- AlphaSort button 25
- Alternative data 49
- Attractions Guide 22, 36
- Audio Language 49

B

- Back panel controls 59
- Batteries
 - installing in the remote 5
- Buttons 60

C

- Cancelling purchases 37
- Channel banner
 - anatomy 19
 - icons 19
- Channel Guide 22
- Channel lists 41
 - add channels 42
 - delete channels 42
- Codes 64
- Connections 8
 - audio/video quality 10, 11, 12, 13
 - jacks and cables 9
 - VCR Controller 14

D

- Data port 19
- Default guide 20
- Detail Guide 20
- DIRECTV programming 16
- Dish Pointing 50
 - azimuth 50
 - elevation 50
 - menu 31
- Dolby Digital 49

E

- Exiting
 - menus 30, 31
 - program guides 22, 28

F

- Fetch
 - customizing 54
 - items 54
- Front panel controls 58

G

- Glossary 66
- Grid Guide 20
- GUIDE button 20
- Guides. *See Program guides*

H

- Help 4, 28
- Home Control 52
 - accessories 73
 - icon 19
 - menu 31
 - setup 52
 - timers 53

I

- Icons 19, 39, 45, 53
- Interactive setup 16, 46

L

- Locking
 - a profile 44
 - the system 19, 41, 44
- Logo Guide 22
- Look and feel 47

M

- Mailbox
 - checking your mail 33
 - deleting mail 33
 - icon 19
- Main menu 28, 29, 33
- Menu system 4
 - exit 30
 - help 4, 30
 - icons 39, 45, 53
 - navigation 7
- Menus
 - Dish Pointing 31, 50
 - Home Control 31, 52
 - Mailbox 31, 33
 - Options 31, 46
 - Profiles 31, 41
 - Program Guide 31
 - Purchases 31
 - Timers 31, 39
- Movies button 24

O

- Options menu 31, 46
- Other Guides
 - Attractions Guide 36
 - button 21, 27

P

- Passwords 44
- Pay-per-view programs 34
 - tuning to 34
- Profiles
 - channel lists 41
 - choosing 45
 - locking 44
 - menu 31, 41
 - ratings limits 42
 - spending limits 43
 - unlocking 45
 - viewing hours 43

Index

- Program guides 4, 17, 21
 - anatomy 18, 32
 - Attractions Guide 22
 - buttons 21
 - Channel Guide 22
 - default 20
 - Detail Guide 20
 - exiting 22, 28
 - Grid Guide 20
 - help 28
 - Logo Guide 22
 - scrolling 20
 - sorting 23
 - SurfGuide 20
 - tuning to a program 21
 - Programming the Remote 61
 - to control a TV 62
 - to control a VCR 62
 - to control other devices 63
 - Purchases 34
 - cancelling 37
 - menu 31, 37
 - previewing 34
 - reviewing 37
 - spending limits 38
 - R
 - Ratings limit 42
 - RECORD button 40
 - Receiver
 - back panel 59
 - connecting 6
 - front panel 58
 - Recording
 - with timers 39
 - Remote control
 - batteries 5
 - buttons 60
 - codes 64
 - programming 5, 61, 62
 - using the 63
 - Reviewing purchases 37
 - S
 - Satellite System
 - back panel 59
 - front panel 58
 - system 4, 56
 - system test 68
 - troubleshooting 68
 - Scout 26
 - button 26
 - results 26
 - Scrolling 20
 - Set VCR type 15
 - Signal meter 51
 - peak signal 51
 - Sorting
 - program guides 23
 - Sorting by
 - All button 24
 - AlphaSort button 25
 - Movies button 24
 - Other Guides button 27
 - Scout button 26
 - Sports button 24
 - Topics button 23
 - Spending limits 38, 43
 - Sports button 24
 - SurfGuide 20
 - System Info 46
 - System lock 44
 - System options 47
 - System test 68
 - System unlock 45
- T
 - Timer feature
 - editing or cancelling 40
 - setting up 39, 40
 - Timers
 - Home Control 53
 - icons 39, 53
 - Timers menu 31, 39
 - Topics button 23
 - Transponders 51
 - Troubleshooting 68
 - Tuning to a program 21
- U
 - Unlocking
 - a profile 45
 - the system 19, 45
 - USB programming 16
- V
 - VCR Controller 9, 14
 - Viewing hours limit 43
- W
 - Warranty information 69

If your system needs service, please contact your dealer or the nearest Servicenter from the yellow pages. Please do not send any products to the Indianapolis address listed in this manual or on the carton. This will only add delays in service for your product.

 **THOMSON CONSUMER ELECTRONICS**

10330 North Meridian Street
Indianapolis, IN 46290

©1998 Thomson Consumer Electronics, Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
Printed in USA
TOCOM 1533586A

The following materials were used
in printing this publication:



85%

THIS PAPER CONTAINS 85% RECYCLED MATERIAL.

THIS PAPER IS WHITENED BY A TOTALLY
CHLORINE-FREE PROCESS.

