


Zennio ZVITXLX4 PC-ABS Capacitive Push Button User Manual

Home » Zennio » Zennio ZVITXLX4 PC-ABS Capacitive Push Button User Manual



Zennio ZVITXLX4 PC-ABS Capacitive Push Button User Manual







Contents

- 1 INTRODUCTION
 - 1.1 TECLA XL
 - **1.2 INSTALLATION**
 - 1.3 START-UP AND POWER LOSS
- **2 CONFIGURATION**
 - 2.1 GENERAL
 - 2.2 BUTTONS
 - 2.3 THERMOSTAT
- **3 ANNEX I. COMMUNICATION**

OBJECTS

- **4 CUSTOMER SUPPORT**
- 5 Documents / Resources
 - 5.1 References
- **6 Related Posts**

INTRODUCTION

TECLA XL

Tecla XL is a KNX multifunction capacitive touch switch from Zennio with proximity sensor, luminosity sensor and backlighted buttons.

They are offered at a reduced weight, with four, six, eight or ten capacitive touch buttons (according to the user's needs) with LED backlight to confirm the press of the buttons as well as showing states.

Tecla XL is a fully customisable solution for the control of rooms where user control of air conditioning systems, lighting, blinds, scenes, etc. is required.


The versatility offered by the functionality of buttons is complemented by an internal **temperature sensor** and a **thermostat** function, as well as an elegant design with fully **customisable** backlit icons.

The most outstanding features of Tecla XL are:

- Fully customisable backlit icons.
- 4 / 6 / 8 / 10 touch buttons, which can operate as individual or pair controls:
- Horizontally or vertically-oriented configuration.
- Light indicator (LED) for every button.
- Buzzer for an audible acknowledgement of user actions (with the possibility of disabling it either by parameter or by object).
- Possibility of locking / unlocking the touch panel through binary orders or scenes.
- **Welcome Back object** (binary or scene) which is sent to the KNX bus when a pulsation is detected after a certain period (configurable) of inactivity.
- Built-in temperature sensor.
- Ambient luminosity sensor for brightness automatic adjustment.
- · Proximity sensor for quick start.
- Thermostat function.
- Heartbeat or periodical "still-alive" notification.

INSTALLATION

Figure 1 shows the connection outline of Tecla XL:



- 1. KNX connector
- 2. Fixing clips.

- 3. Temperature probe.
- 4. Programming LED.
- 5. Programming Button.
- 6. Touch area.
- 7. Proximity and Luminosity.

Tecla XL is connected to the KNX bus through the built-in terminal (1). An external DC power supply is not needed.

A short press on the programming button (5) will make the device enter the programming mode. The programming LED (4) will then light in red. On the contrary, if this button is held while the device gets connected to the bus, the device will enter the safe mode. In such case, the programming LED will blink in red colour.

For detailed information about the technical features of Tecla XL, as well as on security and installation procedures, please refer to the device Datasheet, bundled within the device packaging and also available at www.zennio.com.

START-UP AND POWER LOSS

After download or device reset it is necessary to **wait for about 2 minutes without performing any action** in order to make it possible a proper calibration of:

- · Proximity sensor.
- · Luminosity sensor.
- · Button presses.

For a correct calibration of the proximity and brightness sensors it is recommended not to remain too close or place anything less than 50cm approximately and do not hit with direct light to the device during this time.

CONFIGURATION

After importing the corresponding database in ETS and adding the device into the topology of the project, the configuration process begins by entering the Parameters tab of the device.


GENERAL

In order to allow the device to perform the desired functions, a number of options must be parameterized, either related to its general behaviour or to advanced features.

CONFIGURATION

In the "Configuration" tab, the general settings are displayed.

ETS PARAMETERISATION




The following parameters are shown:

Device Orientation [Vertical (Rotated) / **Horizontal (Rotated)**] 1 : enables horizontal or vertical orientation to be assigned to the device, for easy identification of the push-buttons during configuration process (ETS will show a figure with the final distribution of the push-buttons). To prevent inconsistency in the configuration, please note the following criterium


Vertical (rotado):

Temperature probe hole on the right side and the sensors on the middle.



Horizontal (normal):

Temperature probe hole on the left of the bottom side and sensors on the middle.



- **Buttons** [enabled]: read-only parameter to make it evident that the "Buttons" tab is always enabled in the tab tree on the left. See section 2.2 for details.
- Thermostat [disabled/enabled]: enables or disables the "Thermostat" tab in the tree on the left. See section 2.3 for details.
- Heartbeat (Periodic Alive Notification) [disabled/enabled]: incorporates a one-bit object to the project ("[Heartbeat] Object to Send '1'") that will be sent periodically with value "1" to notify that the device is still working (still alive).



Note: the first sending after download or bus failure takes place with a delay of up to 255 seconds, to prevent bus overload. The following sendings march the period set.

- 1 The default values of each parameter will be highlighted in blue in this document, as follows: [default/rest of options].
- Device Recovery Objects (Send 0 and 1) [disabled/enabled]: this parameter lets the integrator activate two new communication objects ("[Heartbeat] Device Recovery"), which will be sent to the KNX bus with values "0" and "1" whenever the device begins operation (for example, after a bus power failure). It is possible to parameterise a certain delay [0...255][s] to this sending.



Note: After download or bus failure, the sending takes place with a delay of up to 6,35 seconds plus the parameterised delay, to prevent bus overload.

- Internal Temperature Sensor [disabled/enabled]: enables or disables the "Temperature Sensor" tab in the tree on the left. See section 2.1.2 for details.
 - **Sounds** [Default / Custom]: sets whether the sound functions (button beeps, alarm and doorbell) should work according to the pre-defined configuration or to a user-defined configuration. See section 2.1.4 for details.
- Ambient luminosity sensor [disabled/enabled]: enables setting the ambient luminosity sensor. When the

sensor is enabled, a new tab for its configuration is shown. See section 2.1.5 for details.

- **Proximity Sensor** [disabled/enabled]: enables the proximity sensor. This functionality permits "waking up" the device when detecting presence, see section 2.1.6.
- Time to Consider Inactivity [1...30...255][s/min/h]: allows setting a time after which, if no pulsation or proximity detection has occurred, the LEDs turn off (or acquire the brightness level configured, see section 2.1.3).
- Advanced Configuration [disabled/enabled]: enables or disables the "Advanced" tab in the tree on the left.
 See section 2.1.7 for details.

TEMPERATURE SENSOR

The internal temperature probe can monitor the ambient temperature of the room, thus making the device capable of reporting it to the KNX bus and of triggering certain actions when the temperature reaches specific values.

Please refer to the specific manual "**Temperature Probe**" (available in the product section at the Zennio homepage, <u>www.zennio.com</u>) for detailed information about the functionality and the configuration of the related parameters.

BACKLIGHT

Capacitive touch switches are able to manage the brightness of the LED according to two operating modes: normal mode and night mode.

Please refer to the specific manual "**Brightness**" (available in the product section at the Zennio website, www.zennio.com) for detailed information about the functionality and the configuration of the related parameters

SOUNDS

For detailed information about the functionality and the configuration of the related parameters, please refer to the specific manual "Capacitive Touch Switches" available in the Tecla XL product section at the Zennio homepage, www.zennio.com.

AMBIENT LUMINOSITY SENSOR

Capacitive touch switches incorporate a luminosity sensor to receive and monitor ambient brightness measurement.

Please refer to the specific manual "**Luminosity and Proximity Sensor**" (available in the product section at the Zennio homepage, <u>www.zennio.com</u>) for detailed information about the functionality and the configuration of the related parameters.

PROXIMITY SENSOR

Please refer to the specific manual "Proximity and Luminosity Sensor" (available in the product section at the Zennio homepage, www.zennio.com) for detailed information about the functionality and the configuration of the related parameters.

ADVANCED CONFIGURATION

For detailed information about the functionality and the configuration of the related parameters, please refer to the

specific manual "Capacitive Touch Switches" available in the Tecla XL product section at the Zennio homepage, www.zennio.com.

BUTTONS

For detailed information about the functionality and the configuration of the related parameters, please refer to the specific manual "Capacitive Touch Switches" available in the Tecla XL product section at the Zennio homepage, www.zennio.com

THERMOSTAT

Capacitive touch switches implement one Zennio thermostat which can be enabled and fully customised.

Please refer to the specific manual "**Zennio Thermostat**" (available in the product section at the Zennio website, www.zennio.com) for detailed information about the functionality and the configuration of the related parameters.

ANNEX I. COMMUNICATION OBJECTS

• "Functional range" shows the values that, with independence of any other values permitted by the bus according to the object size, may be of any use or have a particular meaning because of the specifications or restrictions from both the KNX standard or the application program itself.

Note:

• The objects shown in this table are from model Tecla XL X10. Please note that certain objects will not be available in models with less push buttons.

Number Size I/O Flags Data type (DPT) Functional Range Name Function

Number	Siz e	I/ O	Flags	Data type (DP T)	Functional R ange	Name	Function
1	1 B		C T -	DPT_Trigger	0/1	[Heartbeat] Object to Send '1'	Sending of '1' Peri odically
2	1 B		C T-	DPT_Trigger	0/1	[Heartbeat] Device Recovery	Send 0
3	1 B		C T-	DPT_Trigger	0/1	[Heartbeat] Device Recovery	Send 1

4	1 B yte	I	C - W	DPT_SceneNu mber	0 – 63	[General] Scene: Receive	0 – 63 (Run Scene 1-64)
5	1 B yte		C T-	DPT_SceneCo ntrol	0-63; 128-191	[General] Scene: S end	0 – 63/128 – 191 (Run/Save Scene 1 -64)
6	1 B	I	C - W	DPT_Enable	0/1	[General] Touch Locking	0 = Unlock; 1 = Lock
0	1 B	I	C - W	DPT_Enable	0/1	[General] Touch Locking	0 = Lock; 1 = Unlock
7	1 B		C T -	DPT_Switch	0/1	[General] Welcom e Back Object	Switch Object Sent on Wake Up
8	1 B	I	C - W	DPT_Enable	0/1	[General] Sounds – Disabling Button Sound	0 = Disable Sound; 1 = Enable Sound
O .	1 B	I	C - W	DPT_Enable	0/1	[General] Sounds – Disabling Button Sound	0 = Enable Sound; 1 = Disable Sound
	1 B	1	C - W	DPT_Ack	0/1	[General] Sounds – Doorbell	1 = Play a Doorbell Sound; 0 = Nothin g
9	1 B	I	C - W	DPT_Ack	0/1	[General] Sounds – Doorbell	0 = Play a Doorbell Sound; 1 = Nothin g
		<u> </u>	<u> </u>	I	l	I	

	1 B it	I	C - W	DPT_Alarm	0/1	[General] Sounds – Alarm	1 = Play Alarm Inte rmittent Sounds; 0 = Stop Alarm Soun ds
10	1 B	I	C - W	DPT_Alarm	0/1	[General] Sounds – Alarm	0 = Play Alarm Inte rmittent Sounds; 1 = Stop Alarm Soun ds
11, 12, 13, 14, 1 5	1 B	I	C - W	DPT_Switch	0/1	[General] Welcom e Back Object – A dditional Condition	Additional Condition Object x
16	1 B	I	C - W	DPT_Enable	0/1	[General] Proximit y Sensor	0 = Disable; 1 = En able
17	1 B	I	C - W	DPT_Start	0/1	[General] External Proximity Detectio n	1 = Detection
18	1 B		C T -	DPT_Start	0/1	[General] Proximit y Detection	Send 1 when Proxi mity is Detected
19	1 B		C T-	DPT_Bool	0/1	[General] Luminosi ty (1-Bit)	0 = Over Threshold; 1 = Under Threshold
	1 B		C T-	DPT_Bool	0/1	[General] Luminosi ty (1-Bit)	0 = Under Threshold; 1 = Over Threshold
20	1 B yte	0	C R -	DPT_Scaling	0% – 100%	[General] Luminosi ty (Percentage)	0% 100%

21	2 B yte s	0	C R -	DPT_Value_L ux		[General] Luminosi ty (Lux)	0 Lux 670760 L ux
22	1 B	ı	C - W	DPT_DayNight	0/1	[General] Backlight Mode	0 = Night Mode; 1 = Normal Mode
	1 B	I	C – W – –	DPT_DayNight	0/1	[General] Backlight Mode	0 = Normal Mode; 1 = Night Mode
23	1 B yte	I	C – W – –	DPT_Scaling	0% – 100%	[General] Display – Brightness	0% 100%
24	1 B yte	1	C - W	DPT_Scaling	0% – 100%	[General] Display – Contrast	0% 100%
25, 31, 37, 43, 4 9, 55, 61, 67, 73 , 79	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Ix] Switch	Send Selected Value on Short Press
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Ix] Hold & Rel ease	Send Selected Values on Hold and Release Presses
	1 B	1	C – W T –	DPT_Switch	0/1	[Btn][lx] Two Objec ts – Short Press	Send Selected Value on Short Press
	1 B		C T-	DPT_Switch	0/1	[Btn][Ix] Light – On /Off	(Short Press) Swit ch Between On an d Off

	1 B		C - - T -	DPT_Step	0/1	[Btn][Ix] Shutter – Stop/Step	(Short Press) 0 = S top Shutter/Step U p; 1 = Stop Shutter /Step Down
	1 B		C T -	DPT_Trigger	0/1	[Btn][Ix] Shutter – Stop	(End Pressing) Sto p Shutter
25, 31, 37, 43, 4 9	1 B		C T -	DPT_Switch	0/1	[Btn][Ix] Light – On	(Short Press) Send On
	1 B		C T -	DPT_Switch	0/1	[Btn][Ix] Light – Off	(Short Press) Send Off
25, 31, 37, 43, 4 9, 55, 61, 67, 73, 79	1 B		C T-	DPT_Step	0/1	[Btn][Ix] Shutter – Stop/Step	(Short Press) Stop Shutter/Step Up
	1 B		C T-	DPT_Step	0/1	[Btn][Ix] Shutter – Stop/Step	(Short Press) Stop Shutter/Step Down
26, 32, 38, 44, 5 0, 56, 62, 68, 74 , 80	4B it	1	C – W T –	DPT_Control_ Dimming	0x0 (Stop) 0x1 (Dec. by 100%) 0x7 (Dec. by 1%) 0x8 (S top) 0xD (Inc. by 100%) 0 xF (Inc. by 1%)	[Btn][Ix] Light – Di mming	Long Press) Switc h Between Dimmin g Up and Down
27, 33, 39, 45, 5 1, 57, 63, 69, 75 , 81	1 B		C T-	DPT_UpDown	0/1	[Btn][Ix] Shutter – Move	(Long Press) 0 = U p; 1 = Down

	1 B		C T-	DPT_UpDown	0/1	[Btn][Ix] Shutter – Move	(Start Pressing) S witch Between Up and Down
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][lx] Two Objec ts – Long Press	Send Selected Value on Long Press
	1 B		C T -	DPT_UpDown	0/1	[Btn][Ix] Shutter – Move	(Long Press) Up
	1 B		C T -	DPT_UpDown	0/1	[Btn][Ix] Shutter – Move	(Long Press) Down
	1 B		C T -	DPT_UpDown	0/1	[Btn][lx] Shutter – Move	(Start Pressing) Up
	1 B it		C T-	DPT_UpDown	0/1	[Btn][lx] Shutter – Move	(Start Pressing) Do wn
28, 34, 40, 46, 5 2, 58, 64, 70, 76 , 82	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Ix] LED On/O	0 = Off; 1 = On
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][lx] LED On/O	0 = On; 1 = Off
29, 35, 41, 47, 5 3, 59, 65, 71, 77 , 83	1 B yte	I	C – W T –	DPT_Scaling	0% – 100%	[Btn][lx] Scaling	Send Selected Per centage Value on Short Press

	_		1		I	
1 B yte	I	C – W T –	DPT_Value_1 _Ucount	0 – 255	[Btn][Ix] Counter – 1-Byte Unsigned	Send Selected Value on Short Press
1 B yte	I	C – W T –	DPT_Value_1 _Count	-128 – 127	[Btn][Ix] Counter – 1-Byte Signed	Send Selected Value on Short Press
2 B yte s	I	C – W T –	DPT_Value_2 _Ucount	0 – 65535	[Btn][Ix] Counter – 2-Byte Unsigned	Send Selected Value on Short Press
2 B yte s	I	C – W T –	DPT_Value_2 _Count	-32768 – 3276 7	[Btn][Ix] Counter – 2-Byte Signed	Send Selected Value on Short Press
2 B yte s	I	C – W T –	9.xxx	-671088.64 – 670433.28	[Btn][Ix] Float	Send Selected Value on Short Press
1 B yte	I	C – W T –	DPT_Value_1 _Ucount	0 – 255	[Btn][Ix] Two Objec ts – Short Press (1 -Byte)	Send Selected 1-B yte Value on Short Press
1 B yte	I	C – W T –	DPT_Scaling	0% – 100%	[Btn][Ix] Shutter – Position	0 – 100 %
1 B yte	I	C – W T –	DPT_Scaling	0% – 100%	[Btn][Ix] Light – Di mming (Status)	0 – 100 %
1 B yte	I	C – W T –	1.xxx	0/1	[Btn][Ix] Room Stat e	0 = Normal; 1 = Ma ke-up Room; 2 = D o not Disturb

30, 36, 42, 48, 5 4, 60, 66, 72, 78 , 84	1 B yte	I	C – W T –	DPT_Value_1 _Ucount	0 – 255	[Btn][Ix] Two Objec ts – Long Press (1- Byte)	Send Selected 1-B yte Value on Long Press
85, 91, 97, 103, 109	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Switch	Left = 0; Right = 1
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Short Press	Left = 1; Right = 0
	1 B	1	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Short Press	Left = 0; Right = 1
	1 B		C T-	DPT_Switch	0/1	[Btn][Px] Light – O n/Off	(Short Press) Left = Off; Right = On
	1 B		C T-	DPT_Step	0/1	[Btn][Px] Shutter – Stop/Step	(Short Press) Left = Stop/Step Down; Right = Stop/Step Up
	1 B		C T-	DPT_Trigger	0/1	[Btn][Px] Shutter – Stop	(End Pressing) Lef t = Stop-Down; Rig ht = Stop-Up
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Switch	Left = 1; Right = 0
	1 B		C T -	DPT_Switch	0/1	[Btn][Px] Light – O n/Off	(Short Press) Left = On; Right = Off

						1
1 B it		C T-	DPT_Step	0/1	[Btn][Px] Shutter – Stop/Step	(Short Press) Left = Stop/Step Up; Ri ght = Stop/Step Do wn
1 B it		C T-	DPT_Trigger	0/1	[Btn][Px] Shutter – Stop	(End Pressing) Lef t = Stop-Up; Right = Stop-Down
1 B it	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Switch	Lower = 0; Upper = 1
1 B it	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Switch	Lower = 1; Upper = 0
1 B it		C T-	DPT_Switch	0/1	[Btn][Px] Light – O n/Off	(Short Press) Lower = Off; Upper = On
1 B it		C T-	DPT_Switch	0/1	[Btn][Px] Light – O n/Off	(Short Press) Lower = On; Upper = Off
1 B it		C T-	DPT_Step	0/1	[Btn][Px] Shutter – Stop/Step	(Short Press) Lower = Stop/Step Down; Upper = Sto p/Step Up
1 B it		C T-	DPT_Step	0/1	[Btn][Px] Shutter – Stop/Step	(Short Press) Lower = Stop/Step Up; Upper = Stop/ Step Down

	1 B		C T-	DPT_Trigger	0/1	[Btn][Px] Shutter – Stop	(End Pressing) Lo wer = Stop- Down; Upper = Stop-Up
	1 B		C T-	DPT_Trigger	0/1	[Btn][Px] Shutter – Stop	(End Pressing) Lo wer = Stop-Up; Up per = Stop-Down
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Short Press	Lower = 0; Upper = 1
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Short Press	Lower = 1; Upper = 0
86, 92, 98, 104, 110	4 B	I	C – W T –	DPT_Control_ Dimming	0x0 (Stop) 0x1 (Dec. by 1 00%) 0x7 (De c. by 1%) 0x8 (Stop) 0xD (Inc. by 1 00%) 0xF (Inc. by 1%)	[Btn][Px] Light – Di mming	(Long Press) Left = Darker; Right = Bri ghter
	4 B	I	C – W T –	DPT_Control_ Dimming	0x0 (Stop) 0x1 (Dec. by 100%) 0x7 (Dec. by 1%) 0x8 (Stop) 0xD (Inc. by 100%) 0xF (In c. by 1%)	[Btn][Px] Light – Di mming	(Long Press) Left = Brighter; Right = D arker

				1	1	1	
	4B it		C – W T –	DPT_Control_ Dimming	0x0 (Stop) 0x1 (Dec. by 1 00%) 0x7 (Dec. by 1 %) 0x8 (Stop) 0xD (Inc. by 1 00%) 0xF (Inc. by 1 %)	[Btn][Px] Light – Di mming	(Long Press) Lowe r = Darker; Upper = Brighter
	4 B	I	C – W T –	DPT_Control_ Dimming	0x0 (Stop) 0x1 (Dec. by 100%) 0x7 (Dec. by 1%) 0x8 (Stop) 0xD (Inc. by 100%) 0xF (I nc. by 1%)	[Btn][Px] Light – Di mming	(Long Press) Lowe r = Brighter; Upper = Darker
87, 93, 99, 105, 111	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Long Press	Left = 0; Right = 1
	1 B	1	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Long Press	Left = 1; Right = 0
	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Long Press) Left = Down; Right = Up
	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Start Pressing) Le ft = Down; Right = Up
	1 B		C T -	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Long Press) Left = Up; Right = Down

	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Start Pressing) Le ft = Up; Right = Down
	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Long Press) Lowe r = Down; Upper = Up
	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Long Press) Lowe r = Up; Upper = Do wn
	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Start Pressing) Lo wer = Down; Uppe r = Up
	1 B		C T-	DPT_UpDown	0/1	[Btn][Px] Shutter – Move	(Start Pressing) Lo wer = Up; Upper = Down
	1 B it	ı	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Long Press	Lower = 0; Upper = 1
	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] Two Obje cts – Long Press	Lower = 1; Upper = 0
88, 94, 100, 106, 112	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] LED On/ Off	0 = On; 1 = Off

	1 B	I	C – W T –	DPT_Switch	0/1	[Btn][Px] LED On/ Off	0 = Off; 1 = On
89, 95, 101, 107, 113	1 B yte	I	C – W T –	DPT_Scaling	0% – 100%	[Btn][Px] Light – Di mming (Status)	0 – 100 %
115	1 B yte	I	C - W	DPT_SceneCo ntrol	0-63; 128-191	[Thermostat] Scen e Input	Scene Value
116	2 B yte s	I	C – W T U	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Temperature Source 1	External Sensor Te mperature
117	2 B yte s	I	C – W T U	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Temperature Source 2	External Sensor Te mperature
118	2 B yte s	0	CR- T-	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Effective Tem perature	Effective Control T emperature
119	1 B yte	I	C - W	DPT_HVACM ode	1=Comfort 2= Standby 3=Ec onomy 4=Buil ding Protectio n	[Tx] Special Mode	1-Byte HVAC Mod e
120	1 B	I	C - W	DPT_Ack	0/1	[Tx] Special Mode: Comfort	0 = Nothing; 1 = Tri gger
	1 B	1	C - W	DPT_Switch	0/1	[Tx] Special Mode: Comfort	0 = Off; 1 = On

121	1 B	I	C - W	DPT_Ack	0/1	[Tx] Special Mode: Standby	0 = Nothing; 1 = Tri gger
	1 B	I	C - W	DPT_Switch	0/1	[Tx] Special Mode: Standby	0 = Off; 1 = On
122	1 B	I	C - W	DPT_Ack	0/1	[Tx] Special Mode: Economy	0 = Nothing; 1 = Tri gger
	1 B	I	C - W	DPT_Switch	0/1	[Tx] Special Mode: Economy	0 = Off; 1 = On
123	1 B	I	C - W	DPT_Ack	0/1	[Tx] Special Mode: Protection	0 = Nothing; 1 = Tri gger
	1 B	I	C - W	DPT_Switch	0/1	[Tx] Special Mode: Protection	0 = Off; 1 = On
124	1 B	I	C - W	DPT_Window_ Door	0/1	[Tx] Window Statu s (Input)	0 = Closed; 1 = Op en
125	1 B	I	C - W	DPT_Trigger	0/1	[Tx] Comfort Prolo ngation	0 = Nothing; 1 = Ti med Comfort
126	1 B yte	0	C R - T -	DPT_HVACM ode	1=Comfort 2= Standby 3=Ec onomy 4=Buil ding Protectio n	[Tx] Special Mode Status	1-Byte HVAC Mod e

127	2 B yte s	1	C - W	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Setpoint	Thermostat Setpoint Input
	2 B yte s	I	C - W	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Basic Setpoint	Reference Setpoin t
128	1 B	I	C - W	DPT_Step	0/1	[Tx] Setpoint Step	0 = Decrease Setp oint; 1 = Increase Setpoint
129	2 B yte s	I	C - W	DPT_Value_T empd	-671088.64º – 670433.28º	[Tx] Setpoint Offse t	Float Offset Value
130	2 B yte s	0	C R - T -	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Setpoint Statu s	Current Setpoint
131	2 B yte s	0	CR- T-	DPT_Value_T emp	-273.00º – 670433.28º	[Tx] Basic Setpoint Status	Current Basic Setp oint
132	2 B yte s	0	CR- T-	DPT_Value_T empd	-671088.64º – 670433.28º	[Tx] Setpoint Offse t Status	Current Setpoint O ffset
133	1 B	I	C - W	DPT_Reset	0/1	[Tx] Setpoint Reset	Reset Setpoint to Default
	1 B	I	C - W	DPT_Reset	0/1	[Tx] Offset Reset	Reset Offset

134	1 B	I	C - W	DPT_Heat_Co ol	0/1	[Tx] Mode	0 = Cool; 1 = Heat
135	1 B	0	C R – T –	DPT_Heat_Co	0/1	[Tx] Mode Status	0 = Cool; 1 = Heat
136	1 B	I	C - W	DPT_Switch	0/1	[Tx] On/Off	0 = Off; 1 = On
137	1 B	0	C R - T -	DPT_Switch	0/1	[Tx] On/Off Status	0 = Off; 1 = On
138	1 B	I/ O	CR W	DPT_Switch	0/1	[Tx] Main System (Cool)	0 = System 1; 1 = System 2
139	1 B	I/ O	CR W	DPT_Switch	0/1	[Tx] Main System (Heat)	0 = System 1; 1 = System 2
140	1 B	I	C - W	DPT_Enable	0/1	[Tx] Enable/Disabl e Secondary Syste m (Cool)	0 = Disable; 1 = En able
141	1 B	1	C - W	DPT_Enable	0/1	[Tx] Enable/Disabl e Secondary Syste m (Heat)	0 = Disable; 1 = En able
142, 148	1 B yte	0	C R – T –	DPT_Scaling	0% – 100%	[Tx] [Sx] Control V ariable (Cool)	PI Control (Continu ous)
143, 149	1 B yte	0	CR- T-	DPT_Scaling	0% – 100%	[Tx] [Sx] Control V ariable (Heat)	PI Control (Continu ous)

	1 B yte	0	C R - T -	DPT_Scaling	0% – 100%	[Tx] [Sx] Control V ariable	PI Control (Continu ous)
144, 150	1 B	0	C R – T –	DPT_Switch	0/1	[Tx] [Sx] Control V ariable (Cool)	2-Point Control
	1 B	0	C R – T –	DPT_Switch	0/1	[Tx] [Sx] Control V ariable (Cool)	PI Control (PWM)
145, 151	1 B	0	CR- T-	DPT_Switch	0/1	[Tx] [Sx] Control V ariable (Heat)	2-Point Control
	1 B	0	C R – T –	DPT_Switch	0/1	[Tx] [Sx] Control V ariable (Heat)	PI Control (PWM)
	1 B	0	C R – T –	DPT_Switch	0/1	[Tx] [Sx] Control V ariable	2-Point Control
	1 B	0	C R – T –	DPT_Switch	0/1	[Tx] [Sx] Control V ariable	PI Control (PWM)
146, 152	1 B	0	CR- T-	DPT_Switch	0/1	[Tx] [Sx] PI State (Cool)	0 = PI Signal 0%; 1 = PI Signal Greater than 0%
147, 153	1 B	0	CR- T-	DPT_Switch	0/1	[Tx] [Sx] PI State (Heat)	0 = PI Signal 0%; 1 = PI Signal Greater than 0%

	1 B	0	CR- T-	DPT_Switch	0/1	[Tx] [Sx] PI State	0 = PI Signal 0%; 1 = PI Signal Greater than 0%
162	2 B yte s	0	C R – T –	DPT_Value_T emp	-273.00º – 670433.28º	[Internal Probe] Cu rrent Temperature	Temperature Sens or Value
163	1 B	0	C R – T –	DPT_Alarm	0/1	[Internal Probe] Ov ercooling	0 = No Alarm; 1 = Alarm
164	1 B	0	C R – T –	DPT_Alarm	0/1	[Internal Probe] Ov erheating	0 = No Alarm; 1 = Alarm

CUSTOMER SUPPORT

Join and send us your inquiries about Zennio devices: https://support.zennio.com

Zennio Avance y Tecnología S.L.

C/ Río Jarama, 132. Nave P-8.11 45007 Toledo (Spain). Tel. +34 925 232 002. www.zennio.com info@zennio.com



Documents / Resources



Zennio ZVITXLX4 PC-ABS Capacitive Push Button [pdf] User Manual ZVITXLX4, ZVITXLX6, ZVITXLX8, ZVITXLX10, ZVITXLX4 PC-ABS Capacitive Push Button, ZVITXLX4, PC-ABS Capacitive Push Button, Push Button, Button, Tecla XL

References

- • Home En | Zennio
- Home En | Zennio
- • Home En | Zennio
- • Home En | Zennio

Manuals+,