




GETTING TO KNOW YOUR **2015 CRUZE**



Review this Quick Reference Guide for an overview of some important features in your Chevrolet Cruze. More detailed information can be found in your Owner Manual. Some optional equipment described in this guide may not be included in your vehicle. For easy reference, keep this guide with your Owner Manual in your glove box.


www.chevrolet.com

INSTRUMENT PANEL



Instrument Cluster Symbols

	Check Engine		Charging System		Lights On
	Oil Pressure		Security		Antilock Brake System
	Power Steering		Safety Belt Reminder		Low Tire Pressure
	Airbag Readiness		Brake System		Cruise Control Set
	StabiliTrak/Traction Control Active				StabiliTrak/Traction Control Off



Refer to your Owner Manual to learn about the information being relayed by the lights, gauges and indicators of the instrument cluster.

See In Brief in your Owner Manual.

REMOTE KEYLESS ENTRY TRANSMITTER (KEY FOB)

Unlock

Press to unlock the driver's door.
Press again to unlock all doors.

Lock

Press to lock all doors. The driver's door will not lock when open if the Unlocked Door Anti Lock Out feature is turned on.

Vehicle Locator/Panic Alarm

Press and hold briefly to locate your vehicle. The turn signal lamps will flash and the horn will sound.

Press and hold for 3 seconds to activate the alarm. The turn signal lamps will flash and the horn will sound until the button is pressed again or the ignition is turned on.

Trunk

Press and hold to unlock the trunk.



Remote Vehicle Start*

Press and release the  **Lock** button and then press and hold the button until the turn signal lamps flash to start the engine from outside the vehicle.

After entering the vehicle, turn the ignition to the ON position.

- During a remote start, the engine will run for 10 minutes.
- Press and hold the  button until the parking lamps turn off to cancel a remote start.

Note: Open Vehicle Settings in the Configuration menu to change the remote lock, unlock, and remote start settings.

If the remote start heated seat option is selected, the heated seat button indicators do not illuminate and the temperature performance of the unoccupied heated seat may be reduced during the remote start. The heated seat turns off when the ignition is turned on.*

See Keys, Doors and Windows in your Owner Manual.

DOOR LOCKS

- ▶ To lock or unlock all doors, press the power door  **Lock**/ **Unlock** button located on the driver's door.

Note: Open Vehicle Settings in the Configuration menu to change the lock and unlock settings.


- ▶ To open a locked door from inside, pull the inside door handle to unlock the door and then pull the door handle again to open the door.
- ▶ To prevent passengers from opening a rear door from the inside, use the key to turn the  safety lock, located on the inside edge of each rear door, to the horizontal position.

See Keys, Doors and Windows in your Owner Manual.

KEYLESS ACCESS SYSTEM ♦

The Keyless Access System enables operation of the doors, ignition and trunk without removing the transmitter from a pocket or purse. The system will recognize the transmitter when it is within 3 feet of the vehicle.

Keyless Unlocking/Locking



- ▶ With the transmitter within range of the vehicle, press the button on a door handle to unlock the driver's door or all doors.
- ▶ Press the button on a door handle and all doors will lock if the ignition is off, the transmitter is removed from the vehicle, and all doors are closed.

Note: Open the Vehicle Settings in the Configuration menu to change the unlock and lock settings.

Keyless Trunk Opening

- ▶ With the transmitter within range, press the trunk release button above the license plate.

See Keys, Doors and Windows in your Owner Manual.

KEYLESS START ♦

Start

With the vehicle in Park or Neutral, press the brake pedal and then press and hold the **START/STOP** button to start the engine.

Note: The transmitter must be in the vehicle to turn on the ignition. If the Driver Information Center displays *No Remote Detected* or *Replace Battery in Remote Key*, place the transmitter in the center console pocket to enable the engine to start. (See the Owner Manual for instructions.)

Stop

Shift to Park and press the **START/STOP** button to turn off the engine.

Accessory

With the engine off, press the **START/STOP** button once to place the ignition system in the accessory position.

See Driving and Operating in your Owner Manual.

SEAT ADJUSTMENTS

Manual Driver's Seat



A. Seat Fore/Aft Adjustment

Lift the handle under the front of the seat near the console to slide the seat forward or rearward.


B. Seat Height Adjustment

Ratchet the middle lever to raise or lower the seat.

C. Seatback Recline Adjustment

Lift the rear lever to recline or raise the seatback.

Power Driver's Seat⁺



A. Seat Adjustment

Move the control to move the seat forward or rearward and to raise, lower or tilt the seat.

B. Seatback Recline Adjustment

Lift the rear lever to recline or raise the seatback.

See Seats and Restraints in your Owner Manual.

TILT/TELESCOPIC STEERING WHEEL

- ▶ With the vehicle in Park, push down the lever on the left side of the steering column to adjust the steering wheel. The steering wheel can then be moved up or down and in or out. Pull up the lever to lock the steering wheel in place.

See Instruments and Controls in your Owner Manual.

SUN VISORS

- ▶ Detach either sun visor from its center mount and pivot it to block the glare of the sun in a side window. On the driver's side only, the visor will slide along the visor rod.

See Keys, Doors and Windows in your Owner Manual.



Recirculation Mode

The Recirculation Mode can help to quickly cool the air inside the vehicle or prevent outside odors from entering the vehicle. It is not available while the Defog or Defrost Mode is selected. When the Recirculation Mode is used without air conditioning, the air humidity increases and the windows may fog.

Automatic Operation*

1. Press **AUTO**.
2. Set the temperature. Allow time for the system to automatically reach the desired temperature.

Note: When outside temperature and vehicle temperature are cold, fan speed will not increase until warmer air is available.

See *Climate Controls* in your Owner Manual.

BASE AUDIO SYSTEM

Refer to your Owner Manual for important safety information about using the infotainment system while driving.



Setting the Time

1. Press the **Power** button to turn on the radio.
2. Press the **CLOCK** button; or press the **CONFIG** button, turn the **MENU** knob to highlight Time and Date Settings, and then press the knob to select it.
3. Turn the **MENU** knob to highlight the desired time or date item; press the knob to select it.
4. Turn the **MENU** knob to change the value; press the knob to confirm the set value.
5. Press the **BACK** button to exit each menu.

Storing Favorite Stations


Radio stations from all bands (AM, FM or XM[®]) can be stored, in any order, on up to six pages of favorites.

1. Tune in the desired radio station.
2. Press the **FAV** button to display the page where the station is to be stored.
3. Press and hold one of the six numeric pushbuttons until the station is heard, indicating it is stored.
4. Repeat the steps for each pushbutton on each page.

Autostore Stations

- Press the **AS** button for 2 seconds to automatically store the 12 strongest AM or FM stations as autostore presets. Press the AS button to alternate between autostore station pages (AS displays on the radio).

Portable Audio Devices



A 3.5-mm auxiliary input jack (A) and a USB port[†] (B) are located in the center console. Route the device wires through the wire exit (C) of the console lid.

A portable audio device connected to the auxiliary input jack can be controlled only by using the portable device controls. To optimize speaker volume, fully increase the volume level of the portable device.

Compatible devices connected to the USB port can be controlled by the audio system. **Not all devices may be supported.** Use the **MENU** knob and the audio steering wheel controls to access various functions and to disconnect a USB device.

See Infotainment System in your Owner Manual.

BASE AUDIO SYSTEM

Bluetooth® System

Before using a Bluetooth-enabled device in the vehicle, it must be paired with the in-vehicle Bluetooth system. Not all devices will support all functions. The pairing process is disabled when the vehicle is moving. For more information, visit www.gmtotalconnect.com.

Pair a Phone

1. To use voice recognition, press the  **Push to Talk** button; after the beep, say "Pair."
Or press the **CONFIG** button and then select **Phone Settings > Bluetooth > Pair Device**.
2. Start the pairing process on the phone. Locate your vehicle name on the phone.
3. Enter the four-digit code that appears on the touch screen into the phone or confirm the six-digit code on the phone.

Storing Phone Numbers as Name Tags

Up to 30 phone numbers can be stored as name tags in the Hands-Free Directory.

1. Press the  **Push to Talk** button.
2. After the beep, say "Store," immediately followed by a phone number (e.g. "Store 123-555-1212"). Do not pause while speaking. The system prompts to assign a name tag to the phone number.

Using Bluetooth to Make Calls

1. Press the  **Push to Talk** button.
2. After the beep, say "Call" or "Dial," immediately followed by a stored name tag or 10- or 7-digit phone number (e.g. "Call John at Work" or "Dial 123-555-1212"). Do not pause while speaking. A name tag must have been previously stored.

Voice Pass-Thru

Voice Pass-Thru allows access to the voice recognition commands on the cell phone. This can be used as an alternative to creating stored name tags.


1. Press the  **Push to Talk** button; after the beep, say "Voice."
2. The system responds "OK, accessing <phone name.>" The cell phone must have been paired with the Bluetooth system.
3. Say a voice command (e.g. "Call John"). The cell phone's normal prompt messages will be heard according to the phone's operating instructions.

See Infotainment System in your Owner Manual.

Refer to your Owner Manual for important safety information about using the Bluetooth system while driving.

Chevrolet MyLink uses a Bluetooth or USB connection to link to a compatible mobile device, such as a smartphone, cell phone, USB flash drive or portable audio player/iPod®. MyLink enables streaming audio through a smartphone and hands-free voice control. For assistance with the MyLink system, contact Customer Assistance at 1-855-4-SUPPORT (1-855-478-7767) or visit www.chevrolet.com/mylink.

- | | | | | | | | | |
|--|--|-----------------------|---|---|---|---|-----------------------------------|-------------------------------------|
| 1-6:
Favorite
preset
stations | DEST:
Open the
Destination
menu | NAV:
Map
screen | RPT NAV:
Repeat
voice
guidance | CONFIG:
Open the
Settings
menu | INFO:
Available
song
information | FAV:
Pages of
favorite
radio
stations | TONE:
Open
the Tone
menu | AS:
Autostore
presets
list |
|--|--|-----------------------|---|---|---|---|-----------------------------------|-------------------------------------|



- | | | | | | | | | | |
|------------------|--|-------------------------|----------------|--|---|----------------|--|---------------|--|
| Power/
Volume | Previous
radio
station,
track or file | HOME:
Home
screen | Play/
Pause | SRCE:
Select
the audio
source | Next radio
station,
track or file | Phone/
Mute | MENU/SEL:
Tune radio
stations/
Open and
select menus | Eject
disc | BACK:
Move
back one
level in the
menus |
|------------------|--|-------------------------|----------------|--|---|----------------|--|---------------|--|

Touch screen infotainment system with navigation shown.

◆ Optional equipment

See your Infotainment System Owner Manual. 11

Setting the Time

1. Press the **CLOCK** button.
2. Touch **Set Time**.
3. Touch the **+** (**plus**) or **-** (**minus**) screen button to increase or decrease the hours, minutes or date.
4. Press the **BACK** button to exit the menu.

Storing Favorite Stations

Radio stations from all bands (AM, FM or XM♦) can be stored, in any order, on up to six pages of favorites.

1. Tune in the desired radio station.
2. Press the **FAV** button to display the page where the station is to be stored.
3. Press and hold one of the six preset screen buttons until a beep is heard.
4. Repeat the steps for each desired station.

Portable Audio Devices

An accessory power outlet, 3.5-mm auxiliary input jack and a USB port♦ are located in the center console.

- ▶ An iPod™, iPhone™, MP3 Player, a USB flash drive or a USB mass storage device can be connected to the USB port. Chevrolet MyLink will read the device, build a list of voice commands, and fill in missing song information and album graphics. Search for music on-screen or by voice commands.

Bluetooth® System

Before using a Bluetooth-enabled device in the vehicle, it must be paired with the in-vehicle Bluetooth system. Not all devices will support all functions. The pairing process is disabled when the vehicle is moving. For more information, visit www.gmttotalconnect.com.

Pair a Phone

1. To use voice recognition, press the  **Push to Talk** button; after the beep, say "Pair."
To use the screen buttons, press the **CONFIG** button and then touch **Phone Settings > Bluetooth > Pair Device**.
2. Start the pairing process on the phone. Locate your vehicle name on the phone.
3. Enter the four-digit code that appears on the touch screen into the phone or confirm the six-digit code on the phone.
4. If your phone prompts you to accept the connection or phone book download, click "yes" and always allow.

Streaming Audio

With a paired phone connected via Bluetooth, select Bluetooth Audio on the home screen to stream music from the phone. Control music operation using the phone controls.

See your Infotainment System Owner Manual.

Voice Recognition

Control the music source and make phone calls hands-free (after pairing your Bluetooth-enabled phone) using the enhanced voice recognition system.

1. Press the  **Push to Talk** button on the steering wheel.
2. The radio will say "Please say a command," followed by a beep.
3. After the beep, say what you want it to do.

Phone (using your paired phone):

Example command: "Call Amanda" or "Dial 555-1212"

Media Music Device Search (when connected to USB/AUX only):

Example command: "Play artist [name]" or "Play song [name]"

Radio Control:

Example command: "Tune FM 104.3" or "Tune XM Classic Vinyl"

PANDORA® Internet Radio

Listen to personalized radio stations based on favorite artists or genres.

- ▶ Download the Pandora app to your smartphone. Restart the smartphone and sign in to Pandora.
- ▶ Create a station on your phone to listen to a customized song list in the vehicle.
- ▶ Connect your smartphone/device to the system by Bluetooth or, for Apple devices, by a USB cable.
- ▶ Touch the Pandora icon on the touch screen to access Pandora. A slight delay may occur when loading a song or changing a station.

Stitcher SmartRadio™

Stream favorite podcasts, radio shows and news to your vehicle.

- ▶ Download the Stitcher app to your smartphone. Restart the smartphone and sign in to Stitcher.
- ▶ Select a category to listen to.
- ▶ If you like the station, touch the **Star** screen button to add it to your Favorites list.

Note: Pandora and Stitcher can be played using the Bluetooth connection. However, the Pandora and Stitcher screen icons and voice commands will be active only when connected to USB/AUX.

SiriusXM™ Satellite Radio[◆] (subscription required)

NEW – XM Travel Link includes fuel locations and prices, weather, and movies with theater locations. Additional subscription fee required.

NEW – XM Tune Select finds your favorite artists or songs on all XM stations and alerts you.

SiriusXM provides access to over 180 channels of commercial-free music, sports, talk, entertainment, comedy and weather using the radio controls or voice commands.

See your Infotainment System Owner Manual.

AUDIO STEERING WHEEL CONTROLS



+ - Volume

Press + or - to adjust the volume.

SRC Source

Press to select an audio source.

Next/Previous

Rotate up or down to go to the next or previous favorite radio station, CD track, or MP3 file.

Push to Talk

Press to interact with the OnStar® or Bluetooth system.

End Call/Mute

Press to end or reject an OnStar or a Bluetooth call.

Press to mute the vehicle speakers.

See Instruments and Controls in your Owner Manual.

CRUISE CONTROL

Setting Cruise Control



1. Press the **On/Off** button. The Cruise Control symbol will illuminate in white in the instrument cluster.
2. When traveling at the desired speed, rotate the **SET-** thumbwheel down to set the speed. The Cruise Control symbol will illuminate in green in the instrument cluster.

Adjusting Cruise Control

RES+ Resume/Accelerate

Rotate the thumbwheel up to resume a set speed.

When the system is active, rotate the thumbwheel up to increase speed.

SET- Set/Coast

When the system is active, rotate the thumbwheel down to decrease speed.

Cancel

Press to cancel the cruise control but retain the set speed in memory.

Pressing the brake pedal or clutch pedal (manual transmission only) also will cancel the cruise control.

The cruise control set speed is erased when cruise control or the vehicle ignition is turned off.

See Driving and Operating in your Owner Manual.

With OnStar 4G LTE and Wi-Fi®, up to seven devices (smartphones, tablets and laptops) can be connected to high-speed Internet through the vehicle's built-in Wi-Fi hotspot.

- ▶ To retrieve the SSID and password for the hotspot, press the OnStar Voice Command button on the overhead console or rearview mirror, wait for the prompt, and then say "Wi-Fi settings." The information will be displayed on the screen.

For assistance, press the blue OnStar button or call 1-888-4-ONSTAR (1-888-466-7827).

Note: See onstar.com for a detailed instruction guide, vehicle availability, details, and system limitations. Please drive responsibly and use your in-vehicle controls only when it's safe to do so.

See your Infotainment System Owner Manual.

DRIVER INFORMATION CENTER♦

The Driver Information Center (DIC) on the instrument cluster displays a variety of vehicle system information and warning messages.



DIC Controls

A. MENU

Press to display the:


- **Trip/Fuel menu (TRIP).** May include digital speedometer, fuel used, timer, navigation*, fuel range, average fuel economy, instantaneous fuel economy, average vehicle speed, and trip odometers.
- **Vehicle Information menu (OPTION).** May include units, tire pressure, remaining oil life, and battery voltage.
- **ECO menu (if equipped).** May include best average fuel economy, ECO index, and economy trend.

B.

Rotate the switch to scroll through the items of each menu.

C. SET/CLR

Press the button on the end of the lever to set a menu item or clear a message. Press and hold the button to reset a menu item.



See *Instruments and Controls* in your Owner Manual.

WINDSHIELD WIPERS



Washer Fluid

Pull the lever toward you to spray washer fluid on the windshield.

HI High Speed

LO Low Speed

 **INT Intermittent**

Rotate the band to adjust the delay between wipes. The wipers activate more often as the band is rotated upward.

OFF

1x Mist

Single wipe.

See Instruments and Controls in your Owner Manual.

EXTERIOR/INTERIOR LIGHTING

Automatic Headlamp System



 **Off/On**

AUTO Automatic Headlamp System

Automatically activates the Daytime Running Lamps (DRLs) or the headlamps and other exterior lamps depending on outside light conditions.

 **Parking Lamps**

Manual operation of the parking lamps.

 **Headlamps**

Manual operation of the headlamps.

 **Fog Lamps***

Press to turn the fog lamps on or off.

Instrument Panel Lighting

 **Instrument Brightness Control**

Rotate and hold the thumbwheel to adjust the instrument panel lighting.

Dome Lamp



 **Dome Lamp Override/Off**

Press to turn the dome lamp off at all times, even when a door is open.

 **Door Open**

Dome lamp turns on when a door is open.

 **On**

Press to turn on the dome lamp.

VEHICLE PERSONALIZATION♦

Some vehicle features can be customized by using the audio controls and menus. Personalization menus may include climate and air quality, comfort and convenience, collision/detection systems, languages, lighting, power door locks, remote lock/unlock/start, and factory settings.



1. Press the **CONFIG** button (A) to enter the System Configuration menu.
2. Turn the **MENU** knob (B) to highlight Vehicle Settings; press the knob to select it.
3. Turn the **MENU** knob to highlight the desired Settings menu; press the knob to select it.
4. Turn the **MENU** knob to highlight the desired item in the menu; press the knob to select it.
5. Turn the **MENU** knob to highlight the desired selection; press the knob to select it and move back to the last menu.
6. Press the **BACK** button (C) to move back within a menu and to exit each menu.

See Instruments and Controls in your Owner Manual.

STABILITRAK®/TRACTION CONTROL SYSTEMS

The traction control system limits wheelspin and the StabiliTrak stability control system assists with directional control of the vehicle in difficult driving conditions. Both systems turn on automatically every time the vehicle is started.

Traction control should be turned off using the  **StabiliTrak/Traction Control** button next to the shift lever if the vehicle is stuck and rocking the vehicle is required.

See Driving and Operating in your Owner Manual.

MANUAL TRANSMISSION – SELECTING REVERSE



Before shifting into Reverse, completely stop the vehicle. When selecting Reverse, pull up the ring on the shift lever and then swiftly move the lever to the left side of the gear pattern. Forcing the shift lever into gear may damage the transmission.

See Driving and Operating in your Owner Manual.

AUTOMATIC TRANSMISSION



Note: The transmission has a fuel-saving Neutral shift feature. It shifts into Neutral when the vehicle comes to a stop and the brake pedal is applied. It shifts back to Drive when the brake pedal is released. When stopped on a hill, the vehicle may roll very slightly before shifting into Drive.

Driver Shift Control

Driver Shift Control (DSC) allows the driver to shift gears manually. This feature can be used to drive the vehicle in a sportier manner or to downshift when driving on a downhill grade to provide engine braking.

1. Move the shift lever to the Manual (M) position.
2. Tap the shift lever forward (+) to upshift or rearward (–) to downshift. An M and the current gear will be displayed in the Driver Information Center.

If vehicle speed is too high or too low for the requested gear, the shift will not occur. When coming to a stop, the transmission will downshift automatically.

See Driving and Operating in your Owner Manual.

TIRE PRESSURE MONITOR


The **(!) Low Tire Pressure** warning light on the instrument cluster illuminates when one or more of the vehicle's tires is significantly underinflated. Fill the tires to the proper tire pressures. The proper tire pressures for the vehicle are listed on the Tire and Loading Information label, located below the driver's door latch. Current tire pressures can be viewed in the Driver Information Center.

Tire pressure is affected by cold weather and distance driven. If the low tire pressure warning light illuminates when the vehicle is first started in cooler temperatures and then turns off as the vehicle is driven, check for the proper tire pressures.

Refer to your Owner Manual for additional information about normal monthly tire maintenance.

See Vehicle Care in your Owner Manual.

REFUELING THE VEHICLE



- To open the fuel door, press and release the center of the rear edge of the door. It will pop out slightly. Pull the door open.

See Driving and Operating in your Owner Manual.

DRIVER ASSISTANCE SYSTEMS

The driver assistance systems use advanced technologies to help avoid collisions by providing visual and audible alerts under some imminent collision conditions.

Side Blind Zone Alert* – While driving, the Side Blind Zone Alert displays a  warning symbol on the left or right side mirror when a vehicle is detected in that side blind zone area. The warning symbol flashes if a turn signal is activated when a vehicle has been detected.

Rear Vision Camera*/Rear Cross-Traffic Alert* – When the vehicle is in Reverse, the Rear Vision Camera displays a view of the area behind the vehicle.

Rear Cross-Traffic Alert warns of traffic coming from either direction — up to 65 feet (20 m) from the left or right side of the vehicle — by displaying a visual alert on the Rear Vision Camera display and sounding three beeps from the left or right.

Rear Parking Assist* – When the vehicle is in Reverse, detected objects are indicated by audible beeps. The interval between beeps becomes shorter as the vehicle gets closer to an object. When the distance is less than 12 in. (30 cm), the beeps are continuous. The system only operates at speeds less than 5 mph.

Note: These systems may not be available if dirt or snow builds up on the sensors or camera lens. Keep the vehicle clean for proper operation.

See Driving and Operating in your Owner Manual.

CLEAN TURBO DIESEL FEATURES (IF EQUIPPED)

Diesel Exhaust Fluid (DEF)

DEF is used with diesel engines to reduce the amount of regulated emissions produced. The 4.8-gallon DEF tank is located under the load floor in the trunk. The amount of DEF in the tank must be maintained for the vehicle to run correctly.

The DEF level indicator is displayed on the Driver Information Center. When approaching empty, a message will be displayed to refill the DEF tank. If it is not refilled, the engine computer will begin to limit vehicle speed, starting at 65 mph, and over time and mileage will reduce maximum speed to less than 10 mph.

DEF may be obtained at your dealership or many diesel retailers. The DEF tank will be refilled at dealerships for the first two years of ownership as part of the regular maintenance package.



Diesel Particulate Filter (DPF)

The DPF filters the diesel exhaust gas. Occasionally, the DPF needs to be cleaned. The DPF cleaning cycle is automatically controlled by the engine computer and should normally be maintenance-free. If the vehicle is not being operated in a manner to allow effective DPF cleaning, a message will be displayed on the Driver Information Center. Refer to your Owner Manual for additional maintenance information.

See Driving and Operating in your Owner Manual.

ROADSIDE ASSISTANCE

**1-800-CHEV-USA
(1-800-243-8872)**

TTY Users: 1-888-889-2438

As the owner of a new Chevrolet, your vehicle is automatically enrolled in the Chevrolet Roadside Assistance program for 5 years/100,000 miles, whichever occurs first, at no expense to you. This value-added service is intended to provide you with peace of mind as you drive in the city or travel the open road.

Chevrolet's Roadside Assistance toll-free number is staffed by a team of technically trained advisors who are available 24 hours a day, 365 days a year, to provide minor repair information or make arrangements to tow your vehicle to the nearest Chevrolet dealer.

Roadside Assistance and OnStar

If you have a current OnStar subscription, press the OnStar button and the vehicle will send your current GPS location to an OnStar Advisor who will speak to you, assess your problem, contact Roadside Assistance and relay your exact location so you will get the help you need.

MYCHEVROLET AND ONSTAR® MOBILE APPS



The myChevrolet and OnStar mobile apps connect owners to a variety of vehicle information and services, such as a searchable Owner Manual, real-time fuel information and Roadside Assistance, as well as enabling users to perform Remote Keyless Entry transmitter commands, including locking and unlocking the doors and starting the vehicle.



An active OnStar account is required to use the OnStar mobile app. Visit **onstar.com** for more information. Download the mobile apps from your compatible device's app store.

CHEVROLET OWNER CENTER

The Chevrolet Owner Center, a complimentary service for Chevrolet owners, is a one-stop resource designed to enhance your Chevrolet ownership experience. Exclusive member benefits include online service reminders, vehicle maintenance tips, online owner manual and special privileges.

Sign up today at **my.chevrolet.com**.

We recommend always using ACDelco or genuine GM service parts.

Certain restrictions, precautions and safety procedures apply to your vehicle. Please read your Owner Manual for complete instructions. All information contained herein is based on the latest information available at the time of printing and is subject to change without notice. Copyright 2015 General Motors. All rights reserved.



22951275 B