Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

King Salmon: The Big Catch B00002SWA5

King Salmon: The Big Catch

Sega Genesis 16-Bit Cartridge Instruction Manual

1. Introduction

Welcome to *King Salmon: The Big Catch* for the Sega Genesis. This manual provides essential information for setting up, operating, and maintaining your game cartridge to ensure an optimal gaming experience. Prepare for a realistic fishing simulation where strategy and quick reflexes are key to landing the elusive King Salmon.

2. Setup

2.1 Console Connection

Ensure your Sega Genesis console is properly connected to your television and power source according to the console's instruction manual. Verify all cables are securely attached.

2.2 Inserting the Game Cartridge

1. Turn off your Sega Genesis console before inserting or removing any game cartridge.
2. Hold the *King Salmon: The Big Catch* cartridge by its edges.
3. Carefully insert the cartridge into the cartridge slot on the Sega Genesis console, ensuring the label faces forward. Push down firmly until it clicks into place. Do not force the cartridge.
4. Turn on your television and select the correct input channel.
5. Turn on your Sega Genesis console. The game should now appear on your screen.



Image: The *King Salmon: The Big Catch* Sega Genesis game cartridge and its accompanying manual, displayed within the game case. The manual features artwork of a salmon and the game title, while the cartridge label shows similar imagery and Sega Genesis branding.

3. Operating Instructions

3.1 Basic Gameplay

King Salmon: The Big Catch is a realistic fishing simulation. Players must master casting, reeling, and setting the hook to successfully catch fish. Pay attention to environmental cues and fish behavior to improve your chances.

3.2 Game Modes

- **Leisure Mode:** Offers a relaxed fishing experience without the pressure of competition. Ideal for practicing techniques and exploring different fishing environments.
- **Championship Mode:** Participate in an ultimate fishing derby. Compete against other anglers to land the biggest and most fish, aiming for high scores and championship titles.

3.3 Player Selectable Equipment

Before heading out, players can select various fishing equipment options. Experiment with different rods, reels, lines, and lures to find the best combination for specific fishing conditions and target species.

3.4 Password Memory

The game features a special password memory system. After completing certain milestones or sessions, the game may provide a password. Record this password accurately to resume your game progress at a later time.

4. Maintenance

4.1 Cartridge Care

- Always store the game cartridge in its protective case when not in use to prevent dust and damage.
- Avoid touching the metal connectors at the bottom of the cartridge. If they become dirty, gently clean them with a cotton swab lightly dampened with isopropyl alcohol. Allow to dry completely before reinserting.
- Keep the cartridge away from extreme temperatures, direct sunlight, and moisture.

4.2 Console Care

Refer to your Sega Genesis console's instruction manual for proper cleaning and maintenance procedures to ensure optimal performance and longevity of both the console and game cartridges.

5. Troubleshooting

5.1 Game Does Not Start

- Ensure the cartridge is fully and correctly inserted into the console slot.
- Turn the console off, remove the cartridge, reinsert it, and turn the console back on.
- Check the metal connectors on the cartridge for dirt or damage. Clean if necessary.
- Verify that your television is set to the correct input channel.

5.2 Controls Not Responding

- Ensure your controller is securely plugged into the console.
- Test with another controller if available to rule out a controller malfunction.

5.3 Graphics or Sound Issues

- Clean the cartridge connectors as described in Section 4.1.
- Check all audio/video cables connecting the console to the television.

6. Specifications

- **Product ASIN:** B00002SWA5
- **Type of Item:** Video Game
- **Manufacturer:** Vic Tokai, Inc.
- **Product Dimensions:** 7.5 x 4.3 x 0.7 inches
- **Item Weight:** 0.8 ounces
- **Rated:** Kids to Adults
- **Date First Available:** July 25, 2006
- **Platform:** Sega Genesis 16-Bit Cartridge

7. Warranty Information

As a vintage video game cartridge, *King Salmon: The Big Catch* may no longer be covered by an original manufacturer's

warranty. Please consult the retailer or seller from whom you purchased the product for any specific return or exchange policies they may offer.

8. Support

For inquiries regarding the original product, you may contact the manufacturer:

Vic Tokai, Inc.
22904 Lockness Ave.
Torrance, CA 90501

Please note that support for vintage products may be limited.

Sega and Genesis are trademarks of Sega Enterprises Ltd. ©1993 Sage's Creation, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00002SWA5

More documents and user manuals: **https://manuals.plus/**