Warner Home Video B00003CXUP

Valentine DVD Instruction Manual

Model: B00003CXUP

1. Introduction

This instruction manual provides essential information for the proper use and care of your Valentine DVD. Please read this manual thoroughly before playback to ensure optimal performance and longevity of your product.



Image 1.1: Front cover of the Valentine DVD. The cover features the film's title "VALENTINE" prominently, with the names of lead actors David Boreanaz, Denise Richards, Marley Shelton, and Katherine Heigl. Below the title, a distressed face with a notebook page overlay is visible, containing handwritten text. The lower half of the cover displays images of the main cast members, including Denise Richards and David Boreanaz, against a smoky, reddish background. A tagline reads: "Remember that kid everyone ignored on Valentine's Day? He remembers you."

2. Setup

1. **Unpack the DVD:** Carefully remove the DVD disc from its case. Hold the disc by its edges to avoid touching the playing surface.
2. **Inspect the Disc:** Check the disc for any visible scratches, smudges, or damage. Clean if necessary (refer to Section 4: Maintenance).
3. **Insert into Player:** Open the disc tray of your DVD player or computer's optical drive. Place the disc label-side up onto the tray spindle. Close the disc tray.
4. **Power On:** Ensure your DVD player and television/monitor are powered on and correctly connected.
5. **Select Input:** Use your television remote to select the correct input source (e.g., HDMI 1, AV, Component) that corresponds to your DVD player.

3. Operating Instructions

3.1 Basic Playback

- **Automatic Playback:** Most DVD players will automatically begin playing the disc or display the main menu upon insertion.
- **Main Menu:** If the main menu appears, use the navigation buttons (up, down, left, right) on your remote control to select "Play Movie" or "Start." Press "Enter" or "OK" to confirm.
- **Pause/Play:** Press the **PLAY/PAUSE** button to pause or resume playback.
- **Stop:** Press the **STOP** button to end playback and return to the beginning of the disc or the main menu.
- **Fast Forward/Rewind:** Use the **FFWD** and **REW** buttons to quickly scan through the movie.
- **Chapter Skip:** Use the **NEXT/PREV CHAPTER** buttons to jump to the next or previous chapter.

3.2 Language and Subtitle Options

The Valentine DVD supports English audio and English and French subtitles.

- **Audio:** During playback, press the **AUDIO** button on your remote to cycle through available audio tracks (English).
- **Subtitles:** Press the **SUBTITLE** button on your remote to cycle through available subtitle options (English, French, Off).
- These options may also be accessible from the disc's main menu or a dedicated "Setup" or "Languages" menu.

3.3 Special Features

This DVD may include special features such as:

- Director's Commentary
- Cast and Crew Interviews
- Club Reel
- Studio Extras
- Theatrical Trailer

Access these features from the main menu of the DVD.

4. Maintenance

- **Handling:** Always hold the DVD disc by its outer edges or by placing a finger through the center hole. Avoid touching

the shiny playing surface.

- **Cleaning:** If the disc has fingerprints or smudges, gently wipe it with a soft, lint-free cloth (e.g., microfiber cloth) from the center outwards. Do not use abrasive materials or harsh cleaning solutions.
- **Storage:** Store the DVD in its original case, away from direct sunlight, extreme temperatures, and high humidity. Keep discs upright to prevent warping.
- **Avoid Scratches:** Do not place the disc on rough surfaces. Return the disc to its case immediately after use.

5. Troubleshooting

Problem	Possible Cause	Solution
Disc does not play or load.	Disc is dirty, scratched, or inserted incorrectly. Player malfunction.	Clean the disc. Ensure it is inserted label-side up. Try the disc in another player to rule out player issues.
Video or audio skips/freezes.	Disc surface is dirty or damaged.	Clean the disc thoroughly. If damage is visible, the disc may be unplayable.
No audio.	TV/player volume is low or muted. Incorrect audio track selected.	Check volume levels. Ensure TV is not muted. Press the AUDIO button on your remote to select the correct audio track.
No subtitles.	Subtitles are turned off or incorrect language selected.	Press the SUBTITLE button on your remote to cycle through available subtitle options.

6. Specifications

- **Title:** Valentine
- **Model Number (ASIN):** B00003CXUP
- **Brand/Studio:** Warner Home Video
- **Media Format:** DVD (Closed-captioned, Color, Dolby, NTSC, Subtitled, Widescreen)
- **Genre:** Horror
- **MPAA Rating:** R (Restricted)
- **Run Time:** 1 hour and 36 minutes
- **Release Date:** July 24, 2001
- **Number of Discs:** 1
- **Language:** English
- **Subtitles:** English, French
- **Director:** Jamie Blanks
- **Actors:** David Boreanaz, Denise Richards, Jessica Capshaw, Jessica Cauffiel, Marley Shelton
- **Product Dimensions:** 7.5 x 5.5 x 0.5 inches
- **Product Weight:** 3.2 ounces

7. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your physical DVD purchase or contact the retailer/distributor directly. Specific warranty terms and support contacts are typically provided by the point of purchase or the publisher, Warner Home Video.

Publisher: Warner Home Video

© 2001 Warner Home Video. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.