Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Westek 6009B

Westek 6009B 100W Full Range Lamp Socket Manual Dimmer

INSTRUCTION MANUAL

Introduction

This manual provides instructions for the safe and effective use of the Westek 6009B 100W Full Range Lamp Socket Manual Dimmer. Please read all instructions carefully before installation and operation. This device is designed to convert any standard lamp into a dimmable light source, offering full-range dimming for incandescent bulbs only.

Safety Information

- For indoor use only.
- Do not exceed the maximum wattage of 100W.
- **Compatible with incandescent bulbs only.** Do not use with LED or CFL bulbs, as this may cause damage to the dimmer or bulb, and may result in improper operation.
- Ensure the lamp is unplugged from the power outlet before installation.
- Keep away from water and moisture.

Setup and Installation

Follow these steps to install your Westek 6009B dimmer:

1. **Unplug the Lamp:** Before beginning, ensure the lamp you intend to use is unplugged from the wall outlet.
2. **Remove Existing Bulb:** Carefully unscrew the existing light bulb from the lamp socket.
3. **Screw in the Dimmer:** Screw the Westek 6009B dimmer into the lamp socket. Ensure it is securely tightened.
4. **Install New Bulb:** Screw an incandescent light bulb (up to 100W) into the dimmer's socket.
5. **Plug in the Lamp:** Plug the lamp's power cord back into the wall outlet.



Image: Front view of the Westek 6009B dimmer, showing the screw-in base and the dimmer knob.



Image: Side view of the Westek 6009B dimmer, highlighting the black rotary dimmer knob.



Image: Bottom view of the Westek 6009B dimmer, showing the screw-in base and the model number '6009B' printed on the side.

Operating Instructions

Once installed, operating the dimmer is straightforward:

- **Turning On/Off:** Rotate the black knob clockwise until you hear a click to turn the light on. Rotate counter-clockwise until you hear a click to turn the light off.
- **Dimming:** After turning the light on, continue rotating the knob clockwise to increase brightness or counter-clockwise to decrease brightness. The dimmer provides a full range of light intensity from dim to bright.

Your browser does not support the video tag.

Video: A 6-second demonstration of the Westek 6009B dimmer, showing its physical appearance and rotation.

Maintenance

The Westek 6009B dimmer requires minimal maintenance:

- **Cleaning:** Disconnect power to the lamp before cleaning. Wipe the dimmer with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** Always unplug the lamp before replacing the light bulb. Ensure the replacement bulb is an incandescent type and does not exceed 100W.

Troubleshooting

- **Light does not turn on:**
  - Check if the lamp is securely plugged into the wall outlet.
  - Ensure the dimmer knob is rotated fully clockwise past the 'click' to the ON position.
  - Verify the light bulb is securely screwed into the dimmer and is not burnt out.
  - Confirm the bulb is an incandescent type and within the 100W limit.
- **Light does not dim properly:**
  - This dimmer is designed for incandescent bulbs only. Using LED or CFL bulbs will result in improper dimming or no dimming at all.
  - Ensure the bulb wattage is within the specified range.
- **Dimmer feels warm:**
  - It is normal for dimmers to generate some heat during operation. If the dimmer becomes excessively hot or emits smoke/odor, immediately unplug the lamp and discontinue use.

Specifications

Model Number	6009B
Brand	Westek
Maximum Wattage	100 Watts
Voltage	120 Volts
Bulb Type Compatibility	Incandescent Only
Product Dimensions	2.5 x 2 x 2 inches
Item Weight	0.944 ounces

Warranty and Support

This product comes with a manufacturer's warranty. For specific warranty details or technical support, please refer to the official Westek website or contact their customer service. Contact information can typically be found on the product packaging or the manufacturer's website.
For further assistance, please visit the Westek Store on Amazon.

© 2023 Westek. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00004XS8Z

More documents and user manuals: **https://manuals.plus/**