Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zircon B00005B1JZ

The Walking Cycloon Audio CD User Manual

Model: B00005B1JZ | Brand: Zircon

Introduction

Welcome to the user manual for *The Walking Cycloon* Audio CD by Sunnyland Slim. This manual provides essential information for the proper handling, playback, and care of your audio CD. Please read through this guide to ensure optimal enjoyment and longevity of your product.



Image: Front cover of *The Walking Cycloon* Audio CD. The artwork displays a portrait of Sunnyland Slim against a background of abstract purple and yellow shapes, with the album title prominently displayed.

Setup

Setting up your *The Walking Cycloon* Audio CD for playback is straightforward. Follow these steps:

1. **Unpack the CD:** Carefully remove the Audio CD from its packaging. Avoid touching the playing surface (the shiny side) to prevent fingerprints and scratches. Hold the CD by its edges or by placing a finger through the center hole.
2. **Prepare your Player:** Ensure your CD player (e.g., home stereo, car CD player, computer CD/DVD drive) is clean and powered on.
3. **Insert the CD:** Open the CD tray or slot on your player. Gently place the CD onto the spindle or into the slot with the label side facing up. Ensure it is seated correctly.
4. **Close the Tray:** Close the CD tray or allow the player to draw the CD in.
5. **Select Input:** If using a home stereo, select the correct input source (e.g., "CD," "Disc") on your amplifier or receiver.

Operating Instructions

Once the CD is loaded, you can begin playback. Standard CD player controls apply:

- **Play/Pause:** Press the **PLAY** button to start playback. Press **PAUSE** to temporarily stop, and press **PLAY** again to resume.
- **Stop:** Press the **STOP** button to end playback and reset the CD to the beginning of the first track.

- **Skip Tracks:** Use the **SKIP FORWARD** (>>|) or **SKIP BACKWARD** (|<<) buttons to navigate between tracks.
- **Fast Forward/Rewind:** Hold down the **FAST FORWARD** (>>) or **REWIND** (<<) buttons to scan through the current track.
- **Eject:** Press the **EJECT** button to remove the CD from the player.

Refer to your specific CD player's manual for detailed instructions on advanced features such as programming tracks, repeat functions, or shuffle play.

Maintenance and Care

Proper care will extend the life of your Audio CD and ensure consistent sound quality:

- **Handling:** Always hold the CD by its outer edge or center hole. Avoid touching the playing surface.
- **Cleaning:** If the CD becomes dirty or smudged, gently wipe the playing surface with a soft, lint-free cloth (e.g., microfiber) in a straight line from the center to the outer edge. Do not wipe in a circular motion. Use a specialized CD cleaning solution if necessary, but avoid abrasive cleaners or solvents.
- **Storage:** Store the CD in its original jewel case or a protective sleeve when not in use. Keep it away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not bend the CD or place heavy objects on it. Avoid dropping the CD.

Troubleshooting

If you encounter issues with your *The Walking Cycloon* Audio CD, consider the following common solutions:

Problem	Possible Cause	Solution
CD skips or stutters during playback.	Dirt, dust, or fingerprints on the playing surface; minor scratches; dirty CD player lens.	Clean the CD carefully as described in the Maintenance section. If the problem persists, try playing another CD to determine if the issue is with the player.
CD does not play or is not recognized.	CD inserted incorrectly; CD player malfunction; severely damaged CD.	Ensure the CD is inserted label-side up. Try ejecting and re-inserting the CD. Test with another CD. If other CDs play, the original CD may be damaged.
Poor sound quality (e.g., muffled, distorted).	Dirty CD; audio system settings; damaged audio cables.	Clean the CD. Check your audio system's volume, balance, and equalizer settings. Ensure all audio cables are securely connected.

If these steps do not resolve the issue, consult the user manual for your specific CD player or contact the manufacturer of your audio equipment.

Specifications

Key specifications for *The Walking Cycloon* Audio CD (Model: B00005B1JZ):

- **Artist:** Sunnyland Slim
- **Album Title:** The Walking Cycloon
- **Format:** Audio CD
- **ASIN:** B00005B1JZ
- **Label:** Zircon

- **Manufacturer:** Zircon
- **Number of Discs:** 1
- **SPARS Code:** DDD (Digital recording, Digital mixing, Digital mastering)
- **Package Dimensions:** Approximately 5.51 x 4.88 x 0.39 inches
- **Item Weight:** Approximately 2.88 ounces
- **Date First Available:** August 19, 2012

Warranty and Support

As an audio CD, *The Walking Cycloon* typically does not come with a manufacturer's warranty beyond the initial period for defects in manufacturing. If you received a damaged or defective CD, please contact your retailer or point of purchase within their specified return policy period (e.g., 30 days as per common return policies).
For general inquiries about the artist or album, please refer to publicly available music databases or fan communities. For issues related to the physical product (e.g., manufacturing defects), contact the label "Zircon" or the retailer from whom you purchased the CD.

© 2024 Zircon. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00005B1JZ

More documents and user manuals: **https://manuals.plus/**