CorningWare French White

CorningWare French White 2-1/2-Quart Round Casserole Dish with Glass Cover

Instruction Manual

1. Product Overview

This manual provides instructions for the CorningWare French White 2-1/2-Quart Round Casserole Dish with its matching glass cover. This bakeware is designed for versatile use in various kitchen environments, offering convenience for cooking, serving, and storing.



Image 1.1: The CorningWare French White 2-1/2-Quart Round Casserole Dish with its clear glass lid. The dish is white stoneware with a fluted exterior design.

Key Features:

- Durable stoneware material suitable for oven, microwave, refrigerator, and freezer use.
- Non-porous surface resists absorption of food odors, flavors, and stains.
- Material designed to resist chipping and cracking.
- Includes a matching glass lid for cooking, serving, and storage.

2. Safety Information

- **Always use oven mitts or potholders** when handling hot bakeware or lids.
- Avoid sudden temperature changes. Do not place a hot dish directly on a cold surface or add cold liquids to a hot dish, as this may cause breakage.
- Do not use the casserole dish or lid on a stovetop burner, under a broiler, or over an open flame. This product is designed for oven, microwave, refrigerator, and freezer use only.
- Inspect the dish and lid for any chips, cracks, or damage before each use. Discontinue use if damage is present.
- Keep out of reach of children when hot.

3. Components

The CorningWare French White 2-1/2-Quart Round Casserole Dish set includes:

- One (1) 2-1/2-Quart Round Stoneware Casserole Dish (French White)
- One (1) Matching Glass Cover

4. Setup and First Use

1. Unpack all components and remove any packaging materials.
2. Wash the casserole dish and glass lid thoroughly with warm, soapy water before first use. Rinse completely and dry.
3. Ensure the dish and lid are completely dry before storing or using in an oven.

5. Operating Instructions

Oven Use:

- The stoneware dish is oven safe. Place food in the dish and cover with the glass lid if desired.
- Always preheat your oven before placing the dish inside.
- Use oven mitts when removing the hot dish from the oven.

Microwave Use:

- Both the stoneware dish and glass lid are microwave safe.
- Ensure the lid is not sealed tightly when microwaving to allow steam to escape.

Refrigerator and Freezer Use:

- The dish and lid are safe for refrigeration and freezing.
- Allow hot food to cool to room temperature before placing in the refrigerator or freezer to prevent thermal shock.

6. Care and Maintenance

Cleaning:

- The casserole dish and glass lid are dishwasher safe.
- For hand washing, use warm, soapy water and a non-abrasive sponge or cloth.
- To remove stubborn food residue, soak the dish in warm, soapy water before cleaning.
- Avoid using abrasive cleaners, scouring pads, or sharp utensils that could scratch the surface.

Storage:

- Store the dish and lid in a dry place.
- When stacking, place a soft cloth or paper towel between items to prevent scratching.

7. Troubleshooting

- **Lid does not fit properly:** Ensure the lid is correctly aligned with the rim of the dish. If the dish or lid appears warped or damaged, discontinue use.
- **Food sticking:** Ensure adequate greasing or non-stick spray is used for recipes prone to sticking.
- **Stains or discoloration:** The non-porous surface resists stains. For persistent stains, try a paste of baking soda and water, let it sit, then scrub gently.

8. Specifications

Attribute	Detail
Brand	CorningWare
Model	French White
Capacity	2-1/2 Quarts (approximately 2.5 Liters)
Dish Material	Stoneware
Lid Material	Glass
Color	French White
Shape	Round
Product Dimensions	4"D x 11"W x 11"H (approximate)
Item Weight	3.5 Pounds
Care Instructions	Dishwasher Safe, Freezer Safe, Microwave Safe, Oven Safe, Refrigerator Safe

9. Warranty and Support

The CorningWare French White Casserole Dish comes with a**10-year limited warranty** on the stoneware dish itself. The matching glass lid is covered by a **one-year limited warranty**.

This warranty covers defects in material and workmanship under normal household use. It does not cover damage resulting from misuse, abuse, accidents, or commercial use.

For warranty claims or product support, please contact CorningWare customer service. Refer to the official CorningWare website or product packaging for the most current contact information.