Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oster 006647-000-000

Oster 10-Speed Blender User Manual

Model: 006647-000-000

Introduction

Thank you for choosing the Oster 10-Speed Blender. This manual provides important information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and keep them for future reference.





Image: The Oster 10-Speed Blender featuring its 5-cup Boroclass glass jar, control panel, and stainless steel blade system.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before use.
2. To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contact with moving parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
7. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but must be used only when the blender is not running.
11. Blades are sharp. Handle carefully.
12. Always operate blender with lid in place.
13. When blending hot liquids, use caution; steam can cause burns.

Parts Description

- **Blender Base:** Houses the motor and control panel.
- **5-Cup Boroclass Glass Jar:** Durable, dishwasher-safe blending container.
- **Lid:** Secures the jar during operation.
- **2-ounce Filler Cap:** Removable cap in the lid for adding ingredients while blending.
- **Crush Pro 4 Blade:** Stainless steel, 4-point design for efficient blending and crushing.
- **Sealing Gasket:** Ensures a leak-proof seal between the blade assembly and the jar.
- **Jar Bottom/Blade Assembly:** Secures the blade and gasket to the jar.

Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or disposal.
2. **Clean:** Wash the glass jar, lid, filler cap, and blade assembly in warm, soapy water. Rinse thoroughly and dry. The Boroclass glass jar is dishwasher safe.
3. **Assemble Blade:** Place the sealing gasket onto the blade assembly.
4. **Attach Blade to Jar:** Invert the glass jar and place the blade assembly with gasket into the opening at the bottom of the jar. Twist the jar bottom/blade assembly clockwise until securely tightened.
5. **Place Jar on Base:** Place the assembled jar onto the blender base, ensuring it is seated correctly.
6. **Plug In:** Plug the blender into a standard electrical outlet.

Operating Instructions

1. **Add Ingredients:** Place ingredients into the glass jar. Do not fill above the maximum fill line. For best results, add liquids first, then soft ingredients, and finally ice or frozen items.
2. **Secure Lid:** Place the lid firmly on the jar and insert the filler cap.
3. **Select Speed:** Choose the desired speed setting from the control panel. The blender offers 10 speeds, including specific functions like:
    - **OFF:** Turns the blender off.
    - **LOW/HIGH:** Continuous blending at low or high speed.
    - **PULSE:** For short bursts of power and controlled chopping.
    - **Grate, Blend, Grind, Liquefy, Crush, Chop, Whip, Mix, Puree:** Pre-programmed settings for various tasks.
4. **Start Blending:** Press the desired speed button. For PULSE, hold the button for short intervals.
5. **Add Ingredients During Blending:** If needed, remove the filler cap and add small ingredients through the opening while the blender is running. Replace the cap immediately.
6. **Stop Blending:** Press the "OFF" button when blending is complete.
7. **Remove Jar:** Unplug the blender before removing the jar from the base.

Tips for Best Performance:

- Do not overload the blender. If the motor stalls, turn it off immediately, unplug, and remove some ingredients.
- For thick mixtures, use the PULSE function or add more liquid.
- The 450 blending watts and Crush Pro 4 Blade are designed for efficient ice crushing.

Maintenance and Cleaning

1. **Unplug:** Always unplug the blender before cleaning.
2. **Disassemble:** Remove the jar from the base. Unscrew the jar bottom/blade assembly from the jar. Remove the blade and gasket.
3. **Clean Jar and Parts:** The 5-Cup Boroclass Glass Jar, lid, filler cap, blade, and gasket are dishwasher safe. Alternatively, wash them in warm, soapy water. Rinse thoroughly and dry.
4. **Clean Base:** Wipe the blender base with a damp cloth. Do not immerse the base in water or any other liquid.
5. **Reassemble:** Ensure all parts are completely dry before reassembling.

Troubleshooting

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; power outage; jar not seated correctly.	Check power cord; check circuit breaker; ensure jar is securely placed on the base.
Motor stalls or slows down.	Overloaded jar; ingredients too thick.	Turn off, unplug, remove some ingredients; add more liquid; use PULSE function.
Leaking from bottom of jar.	Blade assembly not tightened; gasket missing or improperly placed.	Ensure blade assembly is securely tightened; check that the gasket is correctly seated.
Loud noise during operation.	Jar not seated correctly; hard ingredients.	Ensure jar is properly aligned on the base; reduce amount of hard ingredients.

Specifications

- **Model Number:** 006647-000-000
- **Brand:** Oster
- **Color:** White
- **Power:** 700 Power Watts / 450 Blending Watts
- **Capacity:** 5 cups (Boroclass Glass Jar)
- **Speeds:** 10 (including PULSE, Grate, Blend, Grind, Liquefy, Crush, Chop, Whip, Mix, Puree)
- **Blade Material:** Stainless Steel (Crush Pro 4 Blade)
- **Drive System:** DURALAST All-Metal Drive
- **Power Source:** Corded Electric
- **UPC:** 034264042490

Warranty and Support

Warranty Information:

- This Oster blender comes with a **1 Year Limited Warranty** on the entire product.
- Additionally, it features an **Oster 10 Year DURALAST All-Metal Drive Limited Warranty**, ensuring lasting durability for the metal drive system.
- Please refer to the official warranty documentation included with your purchase for full terms and conditions.

Customer Support:
For further assistance, product registration, or to view the official User Guide PDF, please visit the Oster website or contact customer service.

Download Official User Guide (PDF)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00006IUUU

More documents and user manuals: **https://manuals.plus/**