Sony D-EJ360

Sony D-EJ360 PSYC CD Walkman Instruction Manual

Model: D-EJ360

Introduction

The Sony D-EJ360 PSYC CD Walkman is a portable compact disc player designed for on-the-go audio playback. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance and longevity.
This unit supports playback of standard audio CDs and CD-R/RW discs. It incorporates advanced features such as Skip-Free G-Protection and Digital Mega Bass for an enhanced listening experience.

Key Features

- **Skip-Free G-Protection:** Advanced shock protection to minimize audio interruptions during active use.
- **CD-R/RW Playback:** Compatibility with recordable and rewritable compact discs.
- **Digital Mega Bass:** Enhances low-frequency sounds for a richer bass experience.
- **Bookmark Playback Function:** Allows users to program and recall favorite songs from multiple discs.
- **Multiple Playback Modes:** Includes shuffle, program play, and repeat play options.
- **Automatic Volume Limiter System (AVLS):** A 2-position system that helps conserve battery life and maintain consistent volume levels.
- **Extended Battery Life:** Provides approximately 40 hours of playback using two AA batteries.

Setup

1. Battery Installation

The Sony D-EJ360 requires two (2) AA batteries for operation. Batteries are not included with the unit.

1. Locate the battery compartment on the underside of the CD Walkman.

2. Slide the battery compartment cover in the direction indicated by the arrow to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

2. Connecting Headphones

Connect your headphones to the headphone jack located on the side of the CD Walkman.



This image displays the Sony D-EJ360 PSYC CD Walkman in its red finish, accompanied by the included Street Style headphones. The device features a compact, circular design with control buttons visible on the front.

Operating Instructions

1. Power On/Off

- To power on, press the **PLAY/PAUSE** button.
- To power off, press the **STOP** button until the display turns off.

2. Loading and Unloading CDs

1. Press the **OPEN** button or slide the lid release to open the CD compartment.
2. Place a CD or CD-R/RW disc onto the spindle with the label side facing up.
3. Gently press the disc until it clicks into place.

4. Close the lid firmly until it latches.
5. To unload, open the lid and carefully lift the disc from the spindle.

3. Playback Controls

- **PLAY/PAUSE (►/‖‖):** Press once to start playback or pause. Press again to resume.
- **STOP (■):** Stops playback. Press and hold to power off.
- **SKIP (▶▶| / |◀◀):** Press to skip to the next track or return to the beginning of the current/previous track.
- **SEARCH (▶▶ / ◀◀):** Press and hold to fast-forward or rewind within a track.
- **VOLUME (+/-):** Adjusts the listening volume.

4. Playback Modes

The D-EJ360 offers various playback modes:

- **Normal Play:** Plays tracks in sequential order.
- **Repeat Play:** Repeats the current track or all tracks on the disc.
- **Shuffle Play:** Plays tracks in a random order.
- **Program Play:** Allows you to create a custom playlist of tracks.
- **Bookmark Playback:** Enables you to mark favorite songs from multiple CDs and play them back at the touch of a button. Refer to the on-screen display for bookmarking instructions.

5. G-Protection and AVLS

- **G-Protection:** This feature is automatically active to provide skip-free playback. It buffers audio data to prevent interruptions caused by shocks or vibrations.
- **AVLS (Automatic Volume Limiter System):** This system helps to prevent excessively high volume levels and conserve battery power. It has a 2-position switch, typically located on the unit, to adjust its effect.

Maintenance

1. Cleaning the Unit

- Wipe the exterior of the CD Walkman with a soft, dry cloth. For stubborn dirt, use a cloth lightly dampened with water and a mild detergent, then wipe dry.
- Do not use abrasive cleaners, alcohol, benzene, or thinners, as these can damage the finish.
- Keep the lens inside the CD compartment clean. If the lens is dirty, use a commercially available CD lens cleaner.

2. Disc Care

- Handle discs by their edges to avoid fingerprints on the playing surface.
- Clean discs with a soft, lint-free cloth, wiping gently from the center outwards.
- Do not use solvents such as benzene, thinners, or commercially available record cleaners.
- Store discs in their cases to protect them from dust and scratches.

3. Battery Care

- Remove batteries if the unit will not be used for an extended period to prevent leakage.
- Do not mix old and new batteries, or different types of batteries.

Troubleshooting

Problem	Solution
No power	Ensure batteries are inserted correctly with correct polarity. Replace with fresh AA batteries. Check if the HOLD switch is engaged. Disengage it if necessary.
Disc skips or playback is interrupted	Clean the disc thoroughly with a soft, lint-free cloth. Ensure the disc is not scratched or damaged. Verify that the G-Protection feature is active (it is typically always on). Avoid excessive movement or strong vibrations during playback.
No sound or low volume	Check headphone connection. Increase the volume using the volume controls. Ensure the AVLS switch is not set to a very low position. Test with a different pair of headphones.
Disc does not play	Ensure the disc is inserted correctly with the label side up. Close the CD compartment lid completely. Try a different audio CD or CD-R/RW disc. Clean the disc.

Specifications

- **Model Number:** D-EJ360
- **Supported Disc Types:** Audio CD, CD-R, CD-RW
- **Power Source:** 2 x AA batteries (not included)
- **Battery Life:** Approximately 40 hours (with AA batteries)
- **Dimensions (Approx.):** 1 x 5.4 x 5 inches (H x W x D)
- **Weight (Approx.):** 12.3 ounces (without batteries)
- **Special Features:** Skip-Free G-Protection, Digital Mega Bass, AVLS
- **Connectivity:** Auxiliary (for headphones)

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Sony website. Specific warranty terms may vary by region and purchase date.
For further assistance, contact Sony customer service through their official support channels.

© 2024 Sony Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question