De'Longhi EC5

DeLonghi EC5 Steam-Driven 4-Cup Espresso and Coffee Maker User Manual

Model: EC5

Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your DeLonghi EC5 Steam-Driven 4-Cup Espresso and Coffee Maker. Please read this manual thoroughly before first use and retain it for future reference.

Important Safety Information

- **Electrical Safety:** Ensure the appliance is connected to a grounded outlet with the correct voltage. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Hot Surfaces:** The appliance surfaces, especially the heating plate and steam wand, become very hot during operation. Use handles and knobs, and allow the appliance to cool before cleaning.
- **Steam Pressure:** The patented safety cap is steam-pressurized. Do not open the cap while the machine is operating or under pressure. Allow pressure to release completely before opening.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Close supervision is necessary when the appliance is used near children.
- **Proper Use:** Use the appliance only for its intended purpose of making espresso and frothing milk. Any other use may result in injury or damage.
- **Warranty:** Warranty does not cover misuse of product.

Parts and Components

Familiarize yourself with the various parts of your DeLonghi EC5 Espresso Maker.

- **Water Tank/Boiler:** Located at the top, holds water for brewing and steaming.
- **Safety Cap:** Pressure-release cap for the water tank.
- **Filter Holder:** Holds the coffee filter and attaches to the brewing head.

- **Coffee Filter:** For ground coffee.
- **Brewing Head:** Where the filter holder attaches and espresso is dispensed.
- **Swivel Jet Frother:** Steam wand for frothing milk.
- **Steam Control Knob:** Regulates steam output for the frother.
- **On/Off Switch with Indicator Light:** Controls power to the unit.
- **Glass Carafe:** Heat-resistant carafe for collecting espresso, with measurement markings.
- **Removable Drip Tray:** Collects drips and spills for easy cleaning.



Figure 1: Front view of the DeLonghi EC5 Espresso Maker, showing the main unit with two espresso cups on the drip tray.

Initial Setup

1. **Unpacking:** Carefully remove all packaging materials and ensure all parts are present. Dispose of packaging responsibly.
2. **Placement:** Place the espresso maker on a stable, flat, heat-resistant surface, away from water sources and heat. Ensure adequate ventilation around the unit.
3. **First Use Cleaning:** Before first use, clean all removable parts (filter holder, coffee filter, glass carafe, drip tray) with warm soapy water. Wipe the exterior of the unit with a damp cloth.
4. **Rinsing Cycle:** Fill the water tank with fresh, cold water up to the 4-cup mark. Place the empty glass carafe under the brewing head. Turn on the machine and allow all the water to pass through the system to rinse it. Discard this water.

Operating Instructions

Making Espresso

1. **Fill Water Tank:** Ensure the machine is off and cool. Unscrew the safety cap and fill the water tank with fresh, cold water using the glass carafe for measurement (up to 4 cups). Replace the safety cap securely.
2. **Add Coffee:** Place the desired amount of finely ground espresso coffee into the coffee filter. For one cup, use one level scoop; for two cups, use two level scoops. Gently tamp the coffee down.
3. **Attach Filter Holder:** Insert the coffee filter into the filter holder. Align the filter holder with the brewing head and twist firmly to the right until it is securely locked in place.
4. **Position Carafe:** Place the glass carafe with its lid under the filter holder.
5. **Brew Espresso:** Turn the On/Off switch to the "On" position. The indicator light will illuminate. Once the water heats up and pressure builds, espresso will begin to flow into the carafe. The machine will stop brewing automatically when the water tank is empty.
6. **Serve:** Once brewing is complete, turn off the machine. Carefully remove the carafe and serve the espresso.

Frothing Milk (for Cappuccino/Latte)

1. **Prepare Milk:** Fill a pitcher with cold milk (preferably low-fat for better foam). Do not fill more than one-third of the pitcher.
2. **Heat Machine:** After brewing espresso, or if only frothing, ensure the machine is on and heated. The steam control knob should be closed.
3. **Position Frother:** Submerge the tip of the swivel jet frother just below the surface of the milk in the pitcher.
4. **Release Steam:** Slowly turn the steam control knob counter-clockwise to release steam. Move the pitcher up and down gently to incorporate air and create foam. Continue until the milk is frothed to your desired consistency and temperature.
5. **Stop Steam:** Turn the steam control knob clockwise to close the steam. Remove the pitcher.
6. **Clean Frother:** Immediately wipe the frother with a damp cloth to prevent milk residue from drying. Briefly open the steam knob again to clear any milk from inside the wand.



Figure 2: A hand holding a glass pitcher, frothing milk using the swivel jet frother of the DeLonghi EC5.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your espresso maker.

Daily Cleaning

- **Drip Tray:** Empty and rinse the removable drip tray after each use.
- **Filter Holder and Filter:** Remove used coffee grounds. Rinse the filter holder and coffee filter under warm water. Use a small brush if necessary to remove stubborn residue.
- **Swivel Jet Frother:** As mentioned in operation, wipe immediately after use and briefly purge steam to clear any milk residue.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.

Descaling

Mineral deposits from water can build up over time, affecting performance. Descale your machine regularly, depending on water hardness and frequency of use (e.g., every 2-3 months).

1. **Prepare Descaling Solution:** Follow the instructions on a commercial descaling solution suitable for espresso machines, or use a mixture of white vinegar and water (1:1 ratio).
2. **Run Descaling Cycle:** Fill the water tank with the descaling solution. Place a large container under the brewing head and frother. Turn on the machine and allow half of the solution to pass through the brewing head. Then, open the steam knob and allow the remaining solution to pass through the frother.
3. **Rinse:** After the descaling solution has run through, fill the water tank with fresh, clean water and run two full cycles to thoroughly rinse the machine. Discard all rinse water.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No coffee dispenses or very slow flow.	Clogged filter; too finely ground coffee; machine needs descaling.	Clean the filter and filter holder. Use a coarser grind. Perform a descaling cycle.
Weak or watery espresso.	Insufficient coffee grounds; coffee too coarse; not enough pressure.	Increase coffee amount. Use a finer grind. Ensure safety cap is tightly closed.
No steam from frother.	Frother clogged with dried milk; insufficient water in tank; machine not hot enough.	Clean the frother thoroughly. Ensure water tank is filled. Allow machine to heat up fully.
Machine leaks water.	Drip tray full; filter holder not properly secured; safety cap not tight.	Empty drip tray. Re-secure filter holder. Tighten safety cap.

Specifications

- **Model:** EC5
- **Brand:** De'Longhi
- **Type:** Steam-Driven Espresso Machine
- **Capacity:** 4-Cup (8.5-ounce glass carafe)
- **Color:** Black
- **Dimensions (L x W x H):** 10.24 x 8.07 x 11.81 inches
- **Weight:** 5.95 pounds
- **Power:** 2.3E+2 Volts
- **Features:** 2-cup adapter, patented safety cap, swivel jet frother, removable drip tray, on/off switch with indicator light.

Warranty and Support

Your DeLonghi EC5 Espresso Maker comes with a limited warranty. Please refer to the original purchase documentation for specific warranty terms and conditions.
Important Note: Warranty does not cover misuse of product.
For technical support, spare parts, or service, please visit the official De'Longhi website or contact their customer service.
A digital version of this user manual is available for download: Download User Manual (PDF)

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question