De'Longhi ST 100 P

De'Longhi ST 100 P Steam Cleaner User Manual

Model: ST 100 P

1. Introduction

Thank you for choosing the De'Longhi ST 100 P Steam Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read this manual thoroughly before using the steam cleaner and keep it for future reference.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- Use only manufacturer's recommended attachments.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot water or other hot liquids.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

3. Product Overview

Familiarize yourself with the components of your De'Longhi ST 100 P Steam Cleaner.



Figure 1: De'Longhi ST 100 P Steam Cleaner. The image shows the main canister unit in black with a red band, connected to a black hose and a floor cleaning nozzle. The canister has "Sterilsteam Super Power" and "De'Longhi" printed on it.

Main Components:

1. Main Unit (Canister)
2. Water Tank Cap
3. Steam Ready Indicator Light
4. Power Switch
5. Steam Hose
6. Extension Tubes
7. Floor Nozzle
8. Small Brush

9. Window Squeegee
10. Funnel
11. Measuring Cup

4. Setup and Assembly

Before first use, ensure all packaging materials are removed and the appliance is placed on a stable, flat surface.

1. **Filling the Water Tank:** Unscrew the water tank cap. Using the provided measuring cup and funnel, fill the tank with up to 1.8 liters of clean tap water. Do not overfill. Screw the cap back on securely.
2. **Attaching Accessories:** Connect the steam hose to the main unit by inserting it firmly until it clicks into place. Attach the desired cleaning accessory (e.g., floor nozzle, small brush) to the end of the extension tube, or directly to the steam hose if no extension is needed.
3. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet.

5. Operating Instructions

Follow these steps for effective and safe steam cleaning.

1. **Power On:** Press the power switch to turn on the steam cleaner. The steam ready indicator light will illuminate, indicating the unit is heating up.
2. **Heating Time:** Allow approximately 8-10 minutes for the water to heat up and steam to be generated. The indicator light will turn off or change color when the unit is ready for use.
3. **Steam Release:** Press the steam release button on the handle of the steam hose to release steam. Direct the steam towards the surface you wish to clean.
4. **Cleaning Surfaces:**
    - **Floors (Carpet):** For carpets, use the floor nozzle. Move the nozzle slowly over the carpet surface to allow the steam to penetrate and loosen dirt.
    - **Hard Surfaces:** For tiles, sealed hardwood, or linoleum, use the floor nozzle or appropriate brush attachment. Wipe with a clean cloth after steaming if necessary.
    - **Windows/Mirrors:** Attach the window squeegee. Steam the surface and then use the squeegee to remove condensation and dirt.
    - **Grout/Small Areas:** Use the small brush attachment for targeted cleaning of grout lines or stubborn spots.
5. **Refilling:** If the steam output decreases significantly, the water tank may be empty. Turn off the unit, unplug it, and allow it to cool for at least 5 minutes before carefully unscrewing the cap and refilling.
6. **Power Off:** After use, press the power switch to turn off the appliance and unplug it from the outlet.

6. Maintenance and Cleaning

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Emptying the Water Tank:** After each use, ensure the unit is cool, then carefully unscrew the water tank cap and empty any remaining water.
- **Cleaning Accessories:** Wash removable accessories (brushes, nozzles) with warm soapy water and rinse thoroughly. Allow them to air dry completely before storing.
- **Descaling:** Depending on water hardness in your area, periodic descaling may be necessary. Consult the

manufacturer's website or customer support for recommended descaling procedures and products.

- **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
No steam or very little steam.	Water tank is empty or low. Unit not heated sufficiently. Blocked nozzle/hose.	Refill water tank. Allow sufficient heating time (8-10 minutes). Check for blockages and clean if necessary.
Water leaking from nozzle.	Unit not fully heated. Condensation build-up.	Allow unit to fully heat up before use. Point nozzle away from surfaces and press steam button until only steam is released.
Steam cleaner not turning on.	Not plugged in. Power outlet issue. Faulty power switch.	Ensure power cord is securely plugged into a working outlet. Check circuit breaker. Contact customer support if issue persists.

8. Technical Specifications

Model: ST 100 P

Brand: De'Longhi

Power: 1400 Watts

Water Tank Capacity: 1.8 Litres

Weight: Approximately 9.07 kg (20 lbs)

Form Factor: Canister

Recommended Surface: Carpet (and other suitable surfaces)

Cordless: No

9. Warranty and Support

De'Longhi products are manufactured to the highest quality standards. For detailed warranty information, please refer to the warranty card included with your product or visit the official De'Longhi website. For technical assistance, spare parts, or repairs, please contact De'Longhi customer support in your region.
Website: www.delonghi.com

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question