Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi HVE134

De'Longhi HVE134 Fan Heater User Manual

Model: HVE134

Introduction

This manual provides detailed instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi HVE134 Fan Heater. Please read this manual thoroughly before using the appliance and keep it for future reference.

Important Safety Information

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.

- Do not use this heater in bathrooms, laundry areas, or similar indoor locations where water may be present.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

Product Overview

The De'Longhi HVE134 is a compact and efficient fan heater designed for personal or small room heating. It features a robust design and intuitive controls.



Figure 1: Front view of the De'Longhi HVE134 Fan Heater, showing the main fan grille and the De'Longhi logo at the bottom left.



Figure 2: Rear view of the De'Longhi HVE134 Fan Heater, illustrating the air intake grille and the power cord exit point.

Components:

- **Control Knobs:** Located on the top, typically for thermostat and power/mode selection.
- **Air Outlet Grille:** Front grille where heated air is expelled.
- **Air Intake Grille:** Rear grille for air circulation.
- **Power Cord:** For connecting to an electrical outlet.

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for storage if needed.

2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 3 feet (0.9 m) of clear space around the front, sides, and rear of the heater to allow for proper air circulation and to prevent fire hazards. Do not place it directly under a power outlet.
3. **Power Connection:** Ensure the heater is switched OFF before plugging it into a suitable 240V AC electrical outlet. Do not use extension cords or power strips with this appliance.



Figure 3: The De'Longhi HVE134 Fan Heater positioned on a flat surface, ready for operation. Ensure adequate clearance around the unit.

Operating Instructions

Control Panel:

The heater typically features two control knobs on the top:

- **Thermostat Knob:** Used to set the desired room temperature. Turn clockwise to increase the temperature setting.
- **Function Selector Knob:** Used to select the operating mode (e.g., Fan Only, Low Heat, High Heat, Off).

Initial Operation:

1. Plug the heater into a suitable electrical outlet.
2. Turn the Function Selector Knob to the desired heat setting (e.g., "Low Heat" or "High Heat"). For fan-only operation without heat, select the "Fan" setting.
3. Turn the Thermostat Knob to the maximum setting. The heater will begin to operate.
4. Once the room reaches the desired temperature, slowly turn the Thermostat Knob counter-clockwise until the heater turns off. The heater will now automatically maintain this temperature by cycling on and off.

Safety Features:

- **Tip-Over Switch:** The heater is equipped with a safety switch that automatically turns the unit off if it is accidentally tipped over. If this occurs, place the heater upright on a stable surface, and it will resume operation.
- **Overheat Protection:** An internal thermal cut-off switch will automatically turn the heater off if it overheats. If this happens, unplug the heater, allow it to cool down for 30 minutes, and check for any obstructions to the air intake or outlet.

Maintenance

Regular maintenance ensures the longevity and efficient operation of your fan heater.

- **Cleaning:** Always unplug the heater from the electrical outlet before cleaning. Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents. Do not immerse the heater in water.
- **Air Intake/Outlet:** Periodically vacuum the air intake and outlet grilles to remove dust and lint buildup. This helps maintain optimal airflow and prevents overheating.
- **Storage:** If the heater is not in use for an extended period, store it in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.

Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit; unit tipped over; overheat protection activated.	Check if the plug is securely in the outlet. Ensure the outlet is functional. Place the heater upright on a stable surface. Unplug, wait 30 minutes, and plug back in.
Heater produces no heat.	Function selector set to "Fan Only"; thermostat set too low.	Turn the Function Selector Knob to a heat setting (Low or High). Turn the Thermostat Knob to a higher setting.
Heater cycles on and off frequently.	Thermostat set too close to room temperature; air intake/outlet blocked.	Adjust the thermostat to a slightly higher setting. Clean air intake and outlet grilles. Ensure proper clearance around the heater.

Problem	Possible Cause	Solution
Unusual noise or smell.	Dust buildup; internal component issue.	Unplug and clean the heater. If the issue persists, discontinue use and contact customer support.

Specifications

Feature	Detail
Brand	De'Longhi
Model Number	HVE134
Product Dimensions	17 x 24 x 25 cm
Item Weight	1.32 kg
Power/Wattage	2400 watts
Heat Output	2400 Watts
Amperage	20 Amps

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official De'Longhi website. You can also find support resources and contact information on the De'Longhi Store on Amazon.

© 2024 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0000C6WNS

More documents and user manuals: **https://manuals.plus/**