Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC UX-P550

JVC UX-P550 Micro Component System User Manual

Model: UX-P550

Introduction

This user manual provides detailed instructions for the operation, setup, and maintenance of your JVC UX-P550 Micro Component System. Please read this manual thoroughly before using the system to ensure proper and safe operation. Keep this manual for future reference.



Figure 1: JVC UX-P550 Micro Component System. An overview of the JVC UX-P550 Micro Component System, showing the central unit, two wooden-cased speakers, and the remote control. The central unit features a silver finish with a blue LCD display.

Safety Precautions

- Do not expose the unit to rain or moisture.
- Ensure proper ventilation to prevent overheating.
- Do not block ventilation openings with items such as newspapers, tablecloths, or curtains.

- Avoid placing the unit near heat sources or in direct sunlight.
- Use only the specified power supply.
- Do not open the casing; refer all servicing to qualified personnel.

Setup

Unpacking

Carefully remove all components from the packaging. Verify that all items listed below are present:

- JVC UX-P550 Main Unit
- Speaker Pair (2 units)
- Remote Control
- Power Cord
- FM Antenna
- AM Loop Antenna
- Speaker Cables

Speaker Connection

Connect the speaker cables to the corresponding terminals on the main unit and the speakers. Ensure correct polarity (+ to + and - to -) for optimal sound quality. The left speaker connects to the LEFT terminals and the right speaker to the RIGHT terminals.

Antenna Connection

For FM reception, connect the supplied FM antenna to the FM 75Ω COAXIAL terminal. Extend the antenna fully for better reception. For AM reception, connect the AM loop antenna to the AM terminals and position it away from the main unit for minimal interference.

Power Connection

After all other connections are made, plug the power cord into the AC inlet on the rear of the main unit, then into a standard wall outlet.

Operating Instructions

Basic Operation

- **Power On/Off:** Press the **STANDBY/ON** button on the front panel or remote control.
- **Volume Control:** Rotate the **VOLUME** knob on the front panel or use the **VOLUME +/-** buttons on the remote control.
- **Source Selection:** Press the **DVD/CD**, **FM/AM**, or **AUX** buttons on the front panel or remote control to select the desired input source.

DVD/CD Playback

1. Press the **DVD/CD** button to select the DVD/CD source.
2. Press the **OPEN/CLOSE** button to open the disc tray.
3. Place a disc (DVD, CD, CD-R/-RW, WMA, MP3, JPEG, SVCD) onto the tray with the label side up.
4. Press **OPEN/CLOSE** again to close the tray. Playback will start automatically for most discs.
5. Use **PLAY/PAUSE**, **STOP**, **SKIP**, and **SEARCH** buttons for playback control.

Radio Operation (FM/AM)

1. Press the **FM/AM** button to select the radio tuner.
2. Press **BAND** to switch between FM and AM bands.
3. Use the **TUNING +/-** buttons to manually tune to a station.
4. Press and hold **TUNING +/-** for automatic station search.
5. To preset a station, tune to the desired station, then press **MEMORY** followed by a preset number button.

Sound Enhancements

- **3D-Phonic:** Press the **3D PHONIC** button to activate or deactivate the surround sound effect.
- **RHYTHMAX:** Press the **RHYTHMAX** button to enhance bass and treble for dynamic sound.
- **Bass/Treble:** Use the **BASS/TREBLE** controls (if available on remote or menu) to adjust tone.

Maintenance

Cleaning the Unit

Wipe the exterior of the unit with a soft, dry cloth. For stubborn stains, dampen the cloth slightly with water or a mild detergent solution, then wipe dry. Do not use abrasive cleaners, benzene, or alcohol, as these can damage the finish.

Disc Care

Handle discs by their edges. Keep discs clean and free from scratches. Store discs in their cases when not in use. If a disc is dirty, wipe it gently from the center outwards with a soft, lint-free cloth.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not securely plugged in.	Check power cord connection to the unit and wall outlet.
No sound	Volume is too low or muted. Speaker cables are disconnected or incorrectly connected.	Increase volume. Check speaker cable connections and polarity.
Disc does not play	Disc is dirty, scratched, or inserted incorrectly. Disc format is not supported.	Clean the disc. Insert disc with label side up. Ensure disc format is compatible (DVD, CD, CD-R/-RW, WMA, MP3, JPEG, SVCD).
Poor radio reception	Antenna not properly connected or positioned. Interference from other electronic devices.	Adjust antenna position. Move unit away from other electronics.

Specifications

- **Model:** JVC UX-P550
- **Power Output:** 100 Watts (Total Music Power)
- **Power Source:** AC 230V, 50Hz (Wired Electric)

- **Supported Disc Formats:** DVD, CD, CD-R/-RW, WMA, MP3, JPEG, SVCD, DVD-Audio
- **Tuner:** FM/AM with RDS
- **Sound Enhancements:** 3D-Phonic, RHYTHMAX
- **Connectivity:** Auxiliary input
- **Number of Speakers:** 2 (Stereo)
- **Item Weight:** Approximately 11 kg

Warranty and Support

Warranty Information

JVC products are covered by a limited warranty. Please refer to the warranty card included with your product for specific terms and conditions, or visit the official JVC website for the most up-to-date warranty information in your region. Keep your proof of purchase for warranty claims.

Customer Support

For technical assistance, service, or inquiries regarding your JVC UX-P550 Micro Component System, please contact JVC customer support. You can find contact details (phone numbers, email, or support portals) on the official JVC website or in the documentation provided with your purchase.
JVC Official Website: www.jvc.com

© 2024 JVC. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00027BPQ4

More documents and user manuals: **https://manuals.plus/**