Roland PD-8

Roland PD-8 Electronic V-Drum Pad User Manual

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Roland PD-8 Electronic V-Drum Pad. Please read these instructions thoroughly before using the product to ensure optimal performance and longevity. Keep this manual accessible for future reference.

Product Overview

The Roland PD-8 is a durable rubber pad designed for use with most Roland V-Drums modules. It features dual-trigger support, allowing for distinct sounds such as rim shots and bow/edge sounds, enhancing your electronic drumming experience.



Figure 1: Top view of the Roland PD-8 Electronic V-Drum Pad. This image displays the circular black rubber playing surface with the Roland logo subtly embossed, and the chrome mounting bracket at the top.

Key Features:

- PD-8 rubber pad with dual-trigger support
- Designed for playing rim shots and bow/edge sounds
- Compatible with most V-Drums modules
- Durable rubber construction

What's in the Box:

- Roland PD-8 Electronic V-Drum Pad

Setup

Follow these steps to properly set up your PD-8 pad:

1. **Mounting the Pad:** Secure the PD-8 pad to a drum stand or rack using its integrated mounting bracket. Ensure the pad is stable and positioned comfortably for playing.
2. **Connecting to a Module:** Connect the PD-8 pad to an input on your Roland V-Drums module using a standard stereo trigger cable (not included unless specified). The PD-8 requires a stereo cable to utilize its dual-trigger capabilities for both head and rim sounds.
3. **Module Settings:** Refer to your V-Drums module's manual to configure the input settings for the PD-8. Select the appropriate pad type (e.g., 'PD-8' or a compatible rubber pad setting) to ensure correct triggering and sound assignment for both the pad surface and the rim. Adjust sensitivity and threshold settings as needed for your playing style.



Figure 2: Angled view of the Roland PD-8 Electronic V-Drum Pad, showing the rubber playing surface and the chrome mounting hardware. This perspective highlights the connection point for the trigger cable.

Operating Instructions

The PD-8 pad is designed for intuitive play. Its dual-trigger system allows for varied sound production:

- **Head Trigger:** Striking the main rubber surface of the pad will trigger the primary sound assigned to that input on your V-Drums module (e.g., a tom sound or hi-hat open sound).
- **Rim Trigger:** Striking the raised rubber rim of the pad will trigger the secondary sound (e.g., a rim shot, hi-hat closed sound, or edge sound for cymbals). Ensure your module is configured to recognize both triggers.

Experiment with different striking dynamics and positions to fully explore the expressive capabilities of the PD-8 pad in conjunction with your V-Drums module.

Maintenance

Proper care will extend the life and performance of your PD-8 pad:

- **Cleaning:** Wipe the rubber surface and housing with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents, as these can damage the rubber and finish.
- **Storage:** Store the pad in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check the mounting bracket and cable connections for any signs of wear or damage.

Troubleshooting

If you encounter issues with your PD-8 pad, consider the following:

- **No Sound or Intermittent Triggering:**
  - Ensure the trigger cable is securely connected to both the pad and the V-Drums module.
  - Verify that the correct input on the module is selected and configured for a PD-8 or compatible rubber pad.
  - Check the cable for damage. Try a different stereo trigger cable if available.
  - Adjust the sensitivity and threshold settings on your V-Drums module. If sensitivity is too low or threshold too high, light hits may not register.
- **Only Head or Rim Triggering (not both):**
  - Confirm you are using a stereo trigger cable. A mono cable will only transmit one trigger signal.
  - Ensure the V-Drums module input is set to a dual-trigger pad type.
  - Check the module's rim sensitivity settings.
- **Unwanted Double Triggering:**
  - Adjust the 'retrigger cancel' or 'scan time' settings on your V-Drums module to prevent multiple triggers from a single strike.

If problems persist, consult your V-Drums module's manual or contact Roland support.

Specifications

Feature	Specification
Model Name	PD-8
Brand	Roland
Material	Rubber
Color	Black
Size	8 inches
Connector Type	MIDI (Trigger Input)
Product Dimensions (L x W x H)	4 x 10 x 4.25 inches
Item Weight	2.2 pounds (approx. 1 Kilogram)
Included Components	Roland PD-8 Electronic V-Drum Pad
Country of Origin	China

Warranty and Support

Specific warranty details for the Roland PD-8 Electronic V-Drum Pad are not provided within this document. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Roland website. For technical support or service inquiries, please contact Roland customer service directly.

You can find additional support resources and contact information on the official Roland website: www.roland.com

© 2023 Roland Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question