Little Tikes 4547

Little Tikes Endless Adventures Tikes Town Playhouse Instruction Manual

Model: 4547

Product Overview

The Little Tikes Endless Adventures Tikes Town Playhouse is an innovative play structure designed to inspire imaginative play with its unique 'around the town' theme. It features four distinct walls, each offering different interactive elements for children aged 18 months to 6 years.



Image: The Little Tikes Endless Adventures Tikes Town Playhouse, showcasing its multi-themed design with children engaged in play.

Assembly Instructions

Assembly is required for the Little Tikes Endless Adventures Tikes Town Playhouse. While the process is designed to be straightforward, having two adults for assembly is recommended. Ensure all components are present before beginning.

Components Checklist:

- Four themed wall panels
- Roof sections
- Basketball hoop and ball
- Gas pumper
- Sticker sheet (for detailing)
- Fasteners and tools (if included)

General Assembly Steps:

1. Unpack all components and verify against the checklist.
2. Connect the four wall panels together using the provided fasteners, ensuring they align correctly.
3. Attach the roof sections securely to the top of the assembled walls.
4. Install the basketball hoop, gas pumper, and any other accessories to their designated locations on the playhouse walls.
5. Apply the decorative stickers to the appropriate areas as indicated in the visual guide (not provided here).

Note: While stickers enhance the playhouse's appearance, their longevity may vary with outdoor exposure. Consider additional weather protection for prolonged vibrancy.

Operating Features

The Tikes Town Playhouse offers a variety of interactive features across its four distinct walls, encouraging diverse imaginative play scenarios.

Schoolhouse/Firehouse Wall:

- Features a small table and a chalkboard for learning and creative expression.
- Includes an open-and-close door for entry and exit.

Sports Wall:

- Equipped with a basketball hoop and a sports ball for shooting practice.
- Features a sports net and targets for various game playing.

Gas Station Wall:

- Includes a gas pumper for pretend vehicle refueling.
- Features a phone for communication during play.

Grocery Store/Bank Wall:

- Offers a drive-up window with see-through shutters for customer interaction.
- Includes an ATM machine for banking role-play.

Your browser does not support the video tag.

Video: A detailed walkthrough of the Little Tikes Adventure Town Playhouse, highlighting its various features and interactive elements.

Maintenance

Cleaning:

- Regularly clean the playhouse with mild soap and water.
- Avoid abrasive cleaners or harsh chemicals, as these can damage the plastic material and fade colors.
- Rinse thoroughly with water and allow to air dry.

Storage and Weather Protection:

- While designed for outdoor use, prolonged exposure to extreme weather conditions (e.g., intense sun, heavy snow, freezing temperatures) can affect the product's lifespan and appearance.
- Consider covering the playhouse during harsh weather or storing it indoors during off-seasons to preserve its

condition.

- Check for loose fasteners periodically and tighten as needed to maintain structural integrity.

Troubleshooting

Fading Colors/Stickers:

- Over time, outdoor exposure can lead to color fading, especially for stickers. This is a normal process for plastic outdoor toys.
- To minimize fading, position the playhouse in a shaded area or use a protective cover when not in use.

Stability Issues:

- Ensure the playhouse is assembled on a flat, level surface to prevent wobbling or instability.
- Regularly inspect all connections and fasteners to ensure they are tight and secure.

Specifications

Feature	Detail
Brand	Little Tikes
Model Number	4547
Material Type	Plastic
Item Dimensions (D x W x H)	51.5"D x 58.75"W x 20"H (58.75 x 51.5 x 20 inches)
Item Weight	95 Pounds
Manufacturer Minimum Age	18 Months
Manufacturer Maximum Age	72 Months
Number of Windows	5

Warranty and Support

Manufacturer Warranty:

For warranty-related inquiries or assistance, please contact Little Tikes Customer Service directly.

Customer Support:

For any product support needs, please call Little Tikes Customer Service at 1-800-321-0183.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How much does the Little Tikes Endless Adventures Tikes Town Playhouse cost?

The current price of the Little Tikes Endless Adventures Tikes Town Playhouse (Model 4547) is not listed in the provided manual or technical specifications, as prices vary by retailer and over time. Historical data...

Read full answer