Tascam DP-01

TASCAM DP-01 Digital Portastudio Recorder User Manual

Model: DP-01 | Brand: Tascam

Introduction

Welcome to the user manual for the TASCAM DP-01 Digital Portastudio Recorder. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your DP-01 unit. The DP-01 is designed to offer an intuitive recording experience with dedicated controls for efficient music production.



Image: The Tascam DP-01 Digital Portastudio Recorder, showcasing its compact and intuitive design with various controls and a display screen.

Key Features

The TASCAM DP-01 Digital Portastudio Recorder offers a range of features designed for multi-track recording:

- **40GB Hard-Drive storage capacity:** Provides ample space for multiple recording projects.
- **8-track recording at uncompressed CD quality:** Allows for high-fidelity multi-track audio capture.
- **2-track simultaneous recording:** Enables recording of two independent audio sources at once.
- **Dedicated stereo mix-down track:** Facilitates the creation of a final stereo mix from your multi-track project.
- **Dedicated controls on each channel for volume, pan, EFX send, EQ high & EQ low:** Offers hands-on control over individual track parameters without navigating complex menus.

Setup Guide

Unpacking and Initial Inspection

Carefully remove all components from the packaging. Verify that all items are present and undamaged. Retain the packaging for future transport or storage.

Power Connection

Connect the supplied AC adaptor to the DC IN jack on the rear panel of the DP-01. Plug the AC adaptor into a suitable power outlet. Use only the specified Tascam AC adaptor (PS-1225) to ensure proper operation and prevent damage.



Image: The Tascam PS-1225 AC adaptor with its power cord and connector. This adaptor is essential for powering the DP-01 unit.

Connecting Audio Inputs

The DP-01 features various input options for connecting instruments and microphones:

- **Microphone/Line Inputs:** Use the 1/4-inch jacks on the front panel for connecting microphones or line-level instruments such as keyboards or drum machines.
- **Guitar Input:** A dedicated 1/4-inch input is available on the front panel for direct guitar connection, optimized for instrument-level signals.



Image: This image displays the front panel of the Tascam DP-01, highlighting the 1/4-inch jacks for microphone/line inputs, a dedicated guitar input, and the headphones jack.

Connecting Audio Outputs

Connect your monitoring system (speakers, headphones) to the appropriate output jacks:

- **Line Output:** Use the RCA or 1/4-inch jacks on the rear for connecting to studio monitors, an external mixer, or an audio interface.
- **Headphones:** Connect headphones to the 1/4-inch stereo jack on the front panel for private monitoring during recording and mixing.



Image: This image shows the rear panel of the Tascam DP-01, detailing the power input, MIDI I/O, digital output, USB port, send/return jacks, line outputs, and stereo mix output.

USB Connection

The DP-01 can be connected to a computer via its USB port for data transfer. When connected, the unit functions as an external hard drive, allowing easy transfer of recorded tracks and project files to your computer for backup or further editing.
Note: Ensure proper shutdown procedures are followed when disconnecting the USB cable or powering off the unit to prevent data corruption or loss.

Operation Guide

Overview of Controls

The DP-01 features a user-friendly interface with dedicated physical controls for each function, minimizing the need for menu diving.



Image: A comprehensive top-down view of the Tascam DP-01, illustrating the layout of faders, knobs for EQ and effects, mute buttons, record arm buttons, and the main display with navigation controls.

Recording Tracks

Follow these steps to record audio onto the DP-01:

1. **Arming Tracks:** Press the REC button for the desired track(s) you wish to record onto. The corresponding LED will illuminate, indicating the track is armed.
2. **Input Level Adjustment:** Use the INPUT knobs associated with your connected input source to set appropriate recording levels. Monitor the level meters on the display to ensure signals are strong but do not clip (peak into the red).
3. **Starting Recording:** Press the RECORD button (red) followed by the PLAY button to begin recording.
4. **Stopping Recording:** Press the STOP button to end the recording process.

Mixing and Mastering

The DP-01 allows for intuitive mixing with dedicated controls:

- **Volume Faders:** Adjust the playback level of each individual track using its dedicated fader.
- **Pan Knobs:** Position each track in the stereo field (left to right) using the PAN knobs.
- **EQ Controls:** Utilize the HIGH and LOW EQ knobs for basic tonal adjustments on each track, allowing you to shape the sound.
- **Effects Send:** Route portions of tracks to external effects processors (connected via the SEND/RETURN jacks) using the EFX SEND controls.
- **Master Fader:** Control the overall output level of your stereo mix.

Data Management

The DP-01 stores all projects and recorded audio on its internal 40GB hard drive. It is highly recommended to regularly back up your projects to a computer via USB to prevent data loss due to unforeseen circumstances.

Important: Always shut down the unit properly by pressing the SHUT DOWN button and waiting for the confirmation message on the display before powering off or disconnecting the power cable. Failure to do so can lead to hard drive corruption and irreversible data loss.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your TASCAM DP-01:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the unit. Avoid abrasive cleaners, solvents, or strong detergents.
- **Hard Drive Care:** The internal hard drive is sensitive to physical shock. Avoid dropping, bumping, or subjecting the unit to strong vibrations, especially during operation. Transport the unit carefully, ideally in its original packaging or a padded case.
- **Firmware Updates:** Periodically check the official Tascam website for any available firmware updates. Firmware updates can improve performance, add features, or fix bugs. Follow the provided instructions carefully if performing an update.
- **Environmental Conditions:** Operate and store the unit in a stable environment. Avoid extreme temperatures, high humidity, direct sunlight, and dusty conditions, as these can negatively impact the internal components and hard drive.

Troubleshooting

This section provides solutions to common issues you might encounter with your DP-01.

Problem	Possible Cause	Solution
No power	AC adaptor not connected; Power switch off.	Ensure AC adaptor is securely connected to the unit and plugged into a working power outlet; Turn the POWER switch ON.
No sound output	Output cables disconnected or faulty; Master or track volume faders down; Headphones not connected or volume low.	Check all audio cable connections to monitors/mixer; Raise master and individual track volume faders; Connect headphones to the PHONES jack and adjust headphone volume.
Cannot record	Track not armed for recording; Input level too low; Hard drive full or corrupted.	Press the REC button for the desired track(s) to arm them; Adjust INPUT level knobs to ensure a strong signal; Delete unnecessary projects or transfer data to a computer to free up space. If corruption is suspected, perform a proper shutdown and restart.
Unit freezes or data loss occurs	Improper shutdown procedure; Physical shock to the hard drive during operation.	Always use the SHUT DOWN function before powering off the unit; Handle the unit carefully to avoid impacts, especially when powered on. Regularly back up your projects to an external device.

Specifications

Detailed technical specifications for the TASCAM DP-01 Digital Portastudio Recorder:

- **Model:** DP-01
- **Storage:** 40GB Hard Drive
- **Recording Tracks:** 8
- **Simultaneous Recording:** 2 tracks
- **Dimensions (W x D x H):** Approximately 21.75 x 14.9 x 6.9 inches (55.2 x 37.8 x 17.5 cm)

- **Weight:** Approximately 10.35 pounds (4.7 kg)
- **Connectivity:** USB 2.0, MIDI In/Out, Digital Out, Analog Inputs (1/4" Mic/Line, Guitar), Analog Outputs (RCA Line Out, 1/4" Stereo Mix Out, 1/4" Headphones)
- **Power:** Dedicated AC Adaptor (Tascam PS-1225)
- **Date First Available:** December 19, 2005

Warranty and Support

For detailed warranty information, technical support, and service inquiries, please refer to the official Tascam website or contact their customer service department directly. Specific warranty periods and service procedures may vary by region and purchase date.

Online Resources: Visit the Tascam Store on Amazon for additional product information and resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question