KODAK 1886597

Kodak Easyshare Camera Dock Series 3 Instruction Manual

Introduction

The Kodak Easyshare Camera Dock Series 3 provides a convenient solution for charging your camera's battery, transferring photos to your computer, and viewing images on a television. This dock simplifies the process of managing your digital photos and ensures your camera is always ready for use.

Package Contents

Verify that all items are present in your package:

- Kodak Easyshare Camera Dock Series 3
- 5V AC Adapter
- NiMH Rechargeable Battery Pack
- USB Cable



Image: Front view of the Kodak Easyshare Camera Dock Series 3 retail box, illustrating the product and its primary functions.

Product Overview

The Kodak Easyshare Camera Dock Series 3 features a dedicated slot for your compatible Kodak Easyshare camera, an AC adapter port for power, and a USB port for computer connectivity. An LED indicator provides status updates for charging and data transfer.



Image: The Kodak Easyshare Camera Dock Series 3, showcasing its design and camera slot.

Setup

1. Connect the AC Adapter

1. Plug the 5V AC adapter into the power port on the back of the Camera Dock Series 3.
2. Plug the other end of the AC adapter into a standard electrical outlet.

2. Insert Battery into Camera

Ensure the NiMH rechargeable battery pack is correctly inserted into your compatible Kodak Easyshare camera according to your camera's instruction manual.

3. Place Camera on Dock

Carefully align your compatible Kodak Easyshare camera with the connector on the dock and gently press down until it is securely seated. The camera should click into place.

Operation

Charging the Camera Battery

Once the camera is properly seated on the dock and the AC adapter is connected, the battery will begin charging. The LED indicator on the dock will show the charging status. A full charge typically takes 3.5 hours or less. A complete refresh charge for a NiMH battery may take up to 8 hours.

Transferring Pictures to a Computer

1. Connect one end of the supplied USB cable to the USB port on the back of the Camera Dock Series 3.
2. Connect the other end of the USB cable to an available USB port on your computer.
3. Ensure your camera is seated on the dock.
4. Press the 'Transfer' button on the dock (if available on your model) or follow the on-screen prompts on your computer to initiate photo transfer. The LED indicator will show transfer status.

Viewing Pictures on a TV

The Camera Dock Series 3 supports connecting your camera to a television for viewing photos. An AV cable (not included with all packages) is required for this function. Connect the AV cable from your camera (while docked) to the video input on your television. Select the appropriate input channel on your TV to view your camera's content.

Compatibility

Compatible Cameras

The Kodak Easyshare Camera Dock Series 3 is compatible with:

- Kodak C Series, V Series, and Z Series cameras
- Easyshare One, LS755, and Picture Viewer cameras
- With the D-26 adapter (sold separately), it is also compatible with CX7000 Series, DX7000 Series, CX6000 Series, DX6000 Series, LS753, LS743, and LS633 cameras.

Compatible Operating Systems

For photo transfer and software functionality, the dock is compatible with:

- **PCs:** Windows 98, 2000, Me, XP
- **Macs:** OS 10.2.3, 10.2.8, 10.3 or greater

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the dock. Do not use liquid cleaners or solvents.
- **Battery Care:** For optimal battery life, avoid fully discharging the NiMH battery pack frequently. Store the dock and camera in a cool, dry place when not in use.
- **Storage:** When not in use, disconnect the AC adapter from the power outlet.

Troubleshooting

- **Camera not charging:** Ensure the AC adapter is securely connected to both the dock and a working power outlet. Verify the camera is properly seated on the dock. Check the NiMH battery pack for proper insertion into the camera.
- **Pictures not transferring to computer:** Confirm the USB cable is connected correctly to both the dock and the computer. Ensure your computer's operating system is compatible and that any necessary Kodak software is installed. Try restarting your computer and reconnecting the dock.

- **No image on TV:** Verify that an AV cable is connected from your camera (while docked) to the TV's video input. Ensure the TV is set to the correct input source (e.g., AV1, Video 1).
- **LED indicator not lighting up:** Check all power connections. If the issue persists, the dock or AC adapter may require service.

Specifications

Model Number	1886597
Product Dimensions	8 x 6 x 2 inches (20.3 x 15.2 x 5.1 cm)
Item Weight	1.25 pounds (0.57 kg)
Power Input	5V AC Adapter
Charging Time	Approximately 3.5 hours (NiMH battery)
Hardware Interface	USB
Total USB Ports	1
Color	Silver

Warranty and Support

For information regarding product warranty, service, or technical support, please refer to the documentation included with your original purchase or visit the official Kodak support website. Keep your proof of purchase for warranty claims.