Casio DB-36-9AVDF

Casio Data Bank Watch DB-36-9AVDF Instruction Manual

Model: DB-36-9AVDF | Brand: Casio

1. Introduction

This manual provides detailed instructions for the proper use and maintenance of your Casio Data Bank Watch, model DB-36-9AVDF. This digital timepiece features a 30-page databank, multi-lingual display, and a 10-year battery, designed for reliability and convenience.



Image 1.1: Front view of the Casio Data Bank DB-36-9AVDF digital watch. The display shows time, date, and day of the week. The watch features a black resin case and band with four control buttons.

2. Setup

2.1 Initial Time and Date Setting

1. In Timekeeping Mode, press and hold the **ADJUST** button until the seconds digits begin to flash, indicating the setting screen.
2. Press the **MODE** button to cycle through the settings: Seconds → Hour → Minute → Year → Month → Day.
3. Use the **SEARCH** (or **FORWARD**) and **REVERSE** buttons to change the flashing value.
4. Once all settings are correct, press the **ADJUST** button to exit the setting screen.

2.2 12/24 Hour Format Selection

In Timekeeping Mode, press the **SEARCH** button to toggle between 12-hour and 24-hour time formats.

2.3 Language Setting

Your watch supports up to 13 display languages for the day of the week. Refer to the detailed instructions in the full Casio module manual (Module 2515) for specific steps on how to change the display language.

3. Operating the Watch

Use the **MODE** button to navigate between the different modes: Timekeeping, Databank, Alarm, Stopwatch, and Countdown Timer.

3.1 Timekeeping Mode

Displays the current time, date, and day of the week. Press the**LIGHT** button to illuminate the display.

3.2 Databank Mode

This mode allows you to store and recall up to 30 pages of data, typically names and telephone numbers. Each page can hold a specific number of characters. Refer to the full module manual for detailed data entry and recall procedures.

3.3 Alarm Mode

The watch features 5 multi-function alarms, including a snooze alarm. To set an alarm:

1. Enter Alarm Mode using the **MODE** button.
2. Use the **SEARCH** button to select the desired alarm (AL1 to AL5).
3. Press and hold the **ADJUST** button until the alarm time digits flash.
4. Use **MODE** to select hour or minute, and**SEARCH**/**REVERSE** to change the value.
5. Press **ADJUST** to confirm.
6. Press **SEARCH** to toggle the alarm on/off.

3.4 Stopwatch Mode

The 1/100 second stopwatch measures elapsed time, split times, and two finishes.

1. Enter Stopwatch Mode.
2. Press the **SEARCH** button to start/stop the stopwatch.
3. Press the **ADJUST** button to reset to zero while stopped.

3.5 Countdown Timer Mode

The countdown timer can be set for up to 24 hours.

1. Enter Countdown Timer Mode.
2. Press and hold the **ADJUST** button until the timer setting flashes.
3. Use **MODE** to select hour or minute, and**SEARCH**/**REVERSE** to change the value.
4. Press **ADJUST** to confirm.
5. Press **SEARCH** to start/stop the countdown.

3.6 LED Light with Afterglow

Press the **LIGHT** button to illuminate the display. The afterglow feature keeps the light on for a few seconds after the button is released.

3.7 Hourly Time Signal

In Alarm Mode, press the **REVERSE** button to toggle the hourly time signal (SIG) on or off.

4. Maintenance

4.1 Battery Replacement

The watch uses one CR2025 lithium battery, providing approximately 10 years of operation. When the display becomes dim or functions become erratic, it is time to replace the battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

4.2 Water Resistance

This watch is rated for 50-meter (5 ATM) water resistance. This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is not suitable for swimming, diving, or showering with hot water, as steam and pressure changes can compromise the seals.

4.3 Care and Cleaning

- Clean the watch with a soft, dry cloth. For stubborn dirt, use a soft cloth dampened with water and a mild soap, then wipe dry.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- Do not expose the watch to gasoline, cleaning solvents, aerosol sprays, adhesives, paints, or other chemicals, as they can damage the resin case and band.

5. Troubleshooting

5.1 Display is Blank or Dim

This usually indicates a low battery. Replace the CR2025 battery as described in the Maintenance section.

5.2 Buttons Do Not Respond

Ensure the watch is not in a frozen or extremely hot environment. If the issue persists, a battery replacement might be necessary, or a reset procedure (refer to the full module manual for specific reset instructions, often involving shorting a specific contact after battery removal).

5.3 Time is Inaccurate

Check if the time and date settings are correct. If the watch consistently gains or loses significant time, the internal module may require service. A new battery can sometimes resolve minor inaccuracies.

6. Specifications

Model Number	DB-36-9AVDF
Module Number	2515
Accuracy	±30 seconds per month
Battery	CR2025 (Approx. 10 years battery life)
Water Resistance	50 meters (5 ATM)
Case Dimensions (H x W x D)	42.0 x 35.5 x 9.8 mm
Weight	30 g
Calendar	Auto Calendar (pre-programmed until the year 2039)
Display Languages	Up to 13 languages for day of week
Databank Capacity	30 pages

7. Warranty and Support

Your Casio watch is covered by a limited warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your purchase or visit the official Casio website. For technical support, service, or to locate an authorized service center, please contact Casio customer service directly through their official channels.

© 2024 Casio Computer Co., Ltd. All rights reserved. This manual is for informational purposes only.