Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Franke ER-40W

Franke ER-40W Esprit Round Synthetic Cutting Board User Manual

Model: ER-40W | Brand: Franke

1. Product Overview

The Franke ER-40W Esprit Round Synthetic Cutting Board is a durable and versatile kitchen accessory designed for food preparation. Made from high-quality synthetic material, this round cutting board is an ideal companion for various kitchen tasks, offering a stable and hygienic surface for cutting, chopping, and slicing.



An image of the Franke ER-40W Esprit Round Synthetic Cutting Board, showcasing its white, round design with integrated handles.

2. Setup

The Franke ER-40W cutting board requires minimal setup. Upon unboxing, it is recommended to wash the board thoroughly with warm, soapy water before its first use to ensure cleanliness and hygiene.

1. Remove all packaging materials from the cutting board.
2. Wash the cutting board by hand using mild dish soap and warm water.
3. Rinse thoroughly and dry completely before storage or use.

3. Operating Instructions

The cutting board is designed for safe and efficient food preparation. Follow these guidelines for optimal use:

- **Placement:** Place the cutting board on a stable, flat surface to prevent slipping during use. A damp cloth underneath

can provide extra stability.

- **Food Separation:** For hygiene, consider using separate cutting boards for raw meats, poultry, and seafood, and another for fruits, vegetables, and cooked foods.
- **Cutting Surface:** Utilize the entire surface of the board to distribute wear evenly and prolong its lifespan.
- **Knife Care:** While synthetic boards are durable, excessive force or serrated knives can leave marks. This does not affect the board's functionality.

4. Maintenance and Care

Proper care will extend the life and maintain the hygiene of your cutting board. The Franke ER-40W is designed for hand washing only.

- **Cleaning:** After each use, wash the cutting board immediately with warm water and mild dish soap. Use a brush or sponge to scrub away food particles.
- **Rinsing:** Rinse thoroughly under running water to remove all soap residue.
- **Drying:** Dry the board completely with a clean towel or allow it to air dry upright before storing. Do not store wet.
- **Stain Removal:** For stubborn stains, a paste of baking soda and water can be applied, left for a few minutes, then scrubbed and rinsed.
- **Disinfection:** Periodically, you may disinfect the board with a diluted bleach solution (1 teaspoon bleach per quart of water) or a food-safe disinfectant, followed by thorough rinsing.
- **Avoid Dishwasher:** Do not place the cutting board in a dishwasher, as high temperatures can cause warping or damage to the synthetic material.

5. Troubleshooting

Most issues with a cutting board are related to cleaning and storage. Here are some common concerns:

Problem	Possible Cause / Solution
Board appears stained or discolored.	Food residues left for too long. Clean immediately after use. For existing stains, use baking soda paste or a diluted bleach solution as described in the Maintenance section.
Board warps or deforms.	Exposure to high heat (e.g., dishwasher, hot pans). Always hand wash and avoid extreme temperatures.
Board slips during use.	Unstable surface. Ensure the surface is dry and flat. Place a damp cloth or non-slip mat underneath for added stability.

6. Specifications

Feature	Detail
Model Number	ER-40W
Brand	Franke
Color	White

Feature	Detail
Material	Synthetic
Shape	Round
Product Dimensions	18 x 18 x 2 inches
Item Weight	2 Pounds
Care Instructions	Hand Wash Only
Special Feature	Weather Resistant

7. Warranty and Support

Franke products are manufactured to high standards. For specific warranty information regarding your Franke ER-40W Esprit Round Synthetic Cutting Board, please refer to the documentation included with your purchase or visit the official Franke website.

For customer support, inquiries, or to report any issues, please contact Franke customer service through their official channels. Contact information can typically be found on the Franke website or on your purchase receipt.

Note: Always retain your proof of purchase for warranty claims.

© 2023 Franke. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00084RN3U

More documents and user manuals: **https://manuals.plus/**