Shoprider GK8

Shoprider Dasher 4 Four Wheel Scooter Instruction Manual

Model: GK8

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and setup of your Shoprider Dasher 4 Four Wheel Scooter, Model GK8. Please read this manual thoroughly before using the scooter to ensure proper understanding and to prevent injury or damage.
The Shoprider Dasher 4 is designed for personal mobility, offering a balance of portability and comfort. It features a quick-disconnect system for easy disassembly into three main parts, making it convenient for transport.

- **Weight Capacity:** Up to 300 lb
- **Portability:** Dismantles into three parts, heaviest part approximately 26 lb.
- **Comfort:** Swivel seating and adjustable tiller.
- **Tires:** Solid tires for a smoother ride.

2. Safety Information

Always prioritize safety when operating your mobility scooter. Adhere to all local traffic laws and regulations.

2.1 Important Legal Disclaimer

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is a mobility aid and should be used as intended. Consult a healthcare professional if you have any medical conditions that may affect your ability to operate this device safely.

2.2 General Safety Guidelines

- Do not operate the scooter under the influence of alcohol or medication that impairs judgment.
- Always ensure all parts are securely assembled before use.
- Avoid steep inclines and uneven terrain that may compromise stability.
- Use caution when operating in crowded areas.
- Regularly check tire pressure (if applicable) and battery charge.

3. Setup and Assembly

The Shoprider Dasher 4 is designed for quick and easy assembly and disassembly. It separates into three main components for transport and storage.

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Verify that all parts listed in the packing list are present.
3. Retain packaging for future transport or storage.

3.2 Assembly Steps

1. **Attach the Rear Section:** Align the rear drive unit with the front chassis and secure it according to the quick-disconnect mechanism. Ensure it clicks into place.
2. **Install the Seat:** Place the swivel seat post into the receiver on the chassis. Ensure it is fully seated and locked. The seat can swivel for easier access.
3. **Adjust the Tiller:** Loosen the tiller adjustment knob, position the curved tiller to a comfortable height and angle, then tighten the knob securely.
4. **Connect Battery:** Ensure the battery pack is properly installed and connected. Refer to the battery compartment instructions for details.
5. **Attach Basket:** If included, attach the front basket to the tiller.



Figure 1: Fully assembled Shoprider Dasher 4 Four Wheel Scooter, showcasing its compact design, adjustable tiller, and swivel seat. The front basket is visible.

3.3 Disassembly for Transport

To disassemble, reverse the assembly steps. The quick-disconnect system allows the scooter to break down into three manageable pieces, with the heaviest part weighing approximately 26 lbs, facilitating easy loading into a vehicle.



Figure 2: Top-down view of the Shoprider Dasher 4 Four Wheel Scooter, highlighting the spacious foot platform and the controls on the tiller.

4. Operating Instructions

4.1 Controls Overview

- **Key Switch:** Turns the scooter on/off.
- **Speed Control Dial:** Adjusts the maximum speed.
- **Throttle Lever:** Push forward for forward motion, pull back for reverse.
- **Battery Indicator:** Displays remaining battery charge.
- **Horn Button:** Activates the warning horn.

4.2 First Use and Driving

1. Ensure the battery is fully charged before first use.
2. Turn the key switch to the "ON" position.
3. Set the speed control dial to a low setting for initial practice.
4. Gently press the throttle lever to begin moving. Release the lever to engage the automatic braking system.
5. Practice steering and maneuvering in an open, safe area.

4.3 Charging the Battery

Connect the charger to the charging port on the scooter and then to a standard wall outlet. The battery indicator will show charging status. Always charge in a well-ventilated area. It is recommended to keep the battery in a warm place, especially during colder weather, to maintain optimal performance and lifespan.

5. Maintenance

5.1 Regular Checks

- **Battery:** Check battery charge level before each use. Charge regularly, even if not used daily, to prolong battery life.
- **Tires:** The Dasher 4 comes with solid tires, eliminating the need for air pressure checks. Inspect for wear and tear.
- **Connections:** Periodically check all electrical connections and fasteners for tightness.
- **Cleaning:** Wipe down the scooter with a damp cloth. Avoid using excessive water or harsh chemicals.

5.2 Storage

When storing the scooter for extended periods, ensure the battery is fully charged and stored in a warm, dry place. Disconnect the battery if storing for several months.

6. Troubleshooting

Problem	Possible Cause	Solution
Scooter does not turn on.	Battery discharged; Key not fully inserted; Loose battery connection.	Charge battery; Ensure key is fully inserted and turned to ON; Check battery connections.
Scooter moves slowly or lacks power.	Low battery charge; Speed dial set too low; Overload.	Charge battery; Adjust speed dial; Reduce load (ensure not exceeding 300 lb capacity).
Horn is too quiet.	Potential horn malfunction.	Contact customer support for inspection or replacement.
Basket does not stay on.	Improper attachment; Damaged mounting clips.	Ensure basket is correctly secured to the tiller; Inspect mounting clips for damage and contact support if necessary.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact Shoprider customer support.

7. Specifications

Feature	Detail
Model Name	Shoprider® Dasher 4
Item Model Number	GK8
Brand	Shoprider
Product Dimensions (L x W x H)	44 x 22 x 33 inches
Item Weight	118 Pounds (total)
Weight Capacity	300 lb
Disassembly	Dismantles into three parts (heaviest part approx. 26 lb)
Seating	Swivel Seating
Tiller	Curved, Height Adjustable
Tires	Solid

Feature	Detail
Color (as reviewed)	Burgundy

8. Warranty and Support

8.1 Warranty Information

Specific warranty details for the Shoprider Dasher 4 (Model GK8) are typically provided with the product at the time of purchase or can be obtained directly from the manufacturer. Please refer to your purchase documentation or visit the official Shoprider website for the most current warranty terms and conditions.

8.2 Customer Support

For technical assistance, parts, or service inquiries, please contact Shoprider customer support.
Manufacturer: Shoprider
(Contact information such as phone number or website URL is typically found on the product packaging or manufacturer's official website.)

© 2026 Shoprider. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question