Shoprider 888B-4BGRD

Shoprider Sunrunner 4 Wheel Scooter Instruction Manual

Model: 888B-4BGRD

1. Introduction

Thank you for choosing the Shoprider Sunrunner 4 Wheel Scooter. This manual provides essential information for the safe and efficient operation, maintenance, and care of your scooter. Please read this manual thoroughly before operating the scooter and keep it for future reference.

The Sunrunner 4 is designed for stability and comfort, featuring a deluxe captain seat, full tiller shroud, and a headlight package. It offers a weight capacity of 300 lbs and a maximum speed of 5 mph with a 25-mile battery capacity.



Image 1.1: The Shoprider Sunrunner 4 Wheel Scooter, showcasing its design and features.

2. Safety Information

Your safety is paramount. Always adhere to the following safety guidelines:

- **Read the Entire Manual:** Understand all instructions and warnings before operating the scooter.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 300 lbs. Overloading can affect stability and performance.
- **Battery Safety:** Use only the specified batteries. Ensure proper charging procedures are followed to prevent hazards.
- **Terrain:** Operate the scooter on stable, level surfaces. Avoid steep inclines, uneven terrain, or soft ground that could cause instability.
- **Visibility:** Use the headlight package in low-light conditions to ensure visibility.
- **Environmental Conditions:** Avoid operating the scooter in heavy rain, snow, or extreme temperatures.
- **Children and Pets:** Keep children and pets away from the scooter during operation and charging.

- **Maintenance:** Regularly inspect the scooter for any signs of wear or damage. Do not operate if any components are compromised.

3. Setup

The Shoprider Sunrunner 4 Wheel Scooter typically requires minimal assembly. It comes with two product-specific batteries included.

3.1 Battery Installation and Initial Charging

1. Locate the battery compartment, usually under the seat or at the rear of the scooter.
2. Carefully install the two included batteries, ensuring correct polarity as indicated.
3. Connect the battery charger to the charging port on the scooter.
4. Plug the charger into a standard electrical outlet.
5. Allow the batteries to charge fully before first use. This may take several hours. Refer to the charger's indicator lights for charging status.

3.2 Seat and Tiller Adjustment

- **Seat Adjustment:** The deluxe captain seat features sliding and swivel capabilities. Use the levers or controls located beneath the seat to adjust its position forward, backward, and to rotate it for easier access.
- **Tiller Adjustment:** The adjustable tiller allows you to set the steering column to a comfortable height and angle. Loosen the adjustment knob, position the tiller, and then securely tighten the knob.

4. Operating Instructions

4.1 Controls Overview

The main controls are located on the tiller:

- **Key Switch:** Insert the key and turn to the 'ON' position to power on the scooter.
- **Speed Control Dial:** Adjusts the maximum speed of the scooter. Start with a lower setting until you are comfortable.
- **Throttle Lever:** Push the lever forward to move forward, and pull it backward to reverse. Releasing the lever engages the electromagnetic brake.
- **Headlight Switch:** Activates the front headlight for improved visibility.
- **Battery Indicator:** Displays the current battery charge level.

4.2 Driving the Scooter

1. Ensure the seat and tiller are adjusted for your comfort and safety.
2. Turn the key to the 'ON' position.
3. Set the speed control dial to a low setting.
4. Gently press the throttle lever to begin moving. Increase pressure for more speed, up to the set maximum.
5. To stop, release the throttle lever. The electromagnetic brake will automatically engage.
6. Steer by turning the tiller. The scooter has a turn radius of 36 inches.
7. When finished, turn the key to the 'OFF' position and remove it.

5. Maintenance

Regular maintenance ensures the longevity and reliable performance of your scooter.

5.1 Battery Care

- **Charging:** Charge the batteries after each day of use, even if only for a short period. This helps maintain battery health and extends their lifespan.
- **Storage:** If storing the scooter for an extended period, ensure the batteries are fully charged and then charge them at least once a month.
- **Replacement:** Batteries have an average life of 25 miles per charge. Replace batteries when they no longer hold a sufficient charge.

5.2 Cleaning

- Wipe down the scooter regularly with a damp cloth and mild detergent.
- Avoid using abrasive cleaners or solvents that could damage the finish.
- Do not spray water directly onto electrical components.

5.3 Tire Inspection

The scooter is equipped with solid wheels, which do not require air pressure maintenance. Periodically inspect the tires for excessive wear or damage.

6. Troubleshooting

If you encounter issues with your scooter, refer to the following common troubleshooting steps:

- **Scooter Does Not Power On:**
  - Ensure the key is fully inserted and turned to the 'ON' position.
  - Check battery connections.
  - Verify batteries are charged.
- **Scooter Moves Slowly or Not at All:**
  - Check battery charge level. Low batteries will reduce performance.
  - Ensure the speed control dial is not set to the lowest setting.
  - Verify that the freewheel lever (if present) is in the 'drive' position, not 'neutral'.
- **Unusual Noises:**
  - Turn off the scooter and inspect for any loose parts or obstructions.
  - If noises persist, contact customer support.

For issues not resolved by these steps, please contact Shoprider customer support.

7. Specifications

Feature	Specification
Model Number	888B-4BGRD

Weight Capacity	300 lbs
Maximum Speed	5 mph
Battery Capacity (Average Life)	25 miles
Turn Radius	36 inches
Brake Style	Electromagnetic
Product Dimensions (L x W x H)	49 x 22 x 38 inches
Item Weight	215 lbs
Frame Material	Stainless Steel
Wheel Type	Solid, Swivel
Batteries Required	2 Product Specific (included)

8. Warranty Information

The Shoprider Sunrunner 4 Wheel Scooter comes with a**1 Year Limited Parts Warranty**. This warranty covers manufacturing defects in materials and workmanship for a period of one year from the date of purchase. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, please refer to the documentation provided with your scooter or contact Shoprider customer support.

9. Customer Support

For technical assistance, parts, or warranty inquiries, please contact Shoprider customer support. Refer to the contact information provided with your product packaging or visit the official Shoprider website for current support details.

When contacting support, please have your model number (888B-4BGRD) and purchase date readily available.

© 2023 Shoprider. All rights reserved.