Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Andis 21420

Andis EasyClip Pro-Animal Detachable Blade Clipper Kit User Manual

Model: 21420 | Brand: Andis

1. Introduction

This manual provides instructions for the safe and effective use of your Andis EasyClip Pro-Animal Detachable Blade Clipper Kit. This professional-grade clipper is designed for animal grooming, offering quiet operation and powerful performance for various coat types. Please read this manual thoroughly before initial use and retain it for future reference.

2. Safety Information

WARNING: To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions.

- Keep out of reach of children.
- Do not use while sleeping or in the shower.
- Always unplug the clipper when not in use, before cleaning, or before attaching/detaching parts.
- Follow recommended cleaning and maintenance procedures as outlined in this manual.
- Do not operate the clipper with a damaged cord or plug. If the cord or plug is damaged, discontinue use and contact customer support.
- Avoid placing or storing the clipper where it can fall or be pulled into a tub or sink.
- Do not immerse the clipper in water or other liquids.
- Use this product only for its intended use as described in this manual.

3. Package Contents

Your Andis EasyClip Pro-Animal Clipper Kit includes the following items:

- Andis EasyClip Pro-Animal Pet Clipper (Purple)
- Detachable Size #10 Ceramic Blade
- 4 Snap-On Comb Attachments (1/8", 1/4", 3/8", 1/2")
- Clipper Blade Lubricating Oil
- Durable Hard Storage Case

- Basic Step-By-Step Instructions (this manual)



Figure 3.1: Contents of the Andis EasyClip Pro-Animal Clipper Kit.

4. Setup

1. **Unpack the Clipper:** Carefully remove all components from the storage case.
2. **Inspect the Blade:** Ensure the detachable ceramic blade (#10) is securely attached. If not, align the blade with the clipper head and snap it into place until it clicks.



Figure 4.1: Attaching/Detaching the blade.

3. **Oil the Blade:** Before each use, apply 2-3 drops of the included lubricating oil across the teeth of the blade and 1 drop on each side of the blade rail. Turn the clipper on for a few seconds to distribute the oil. This ensures smooth

operation and extends blade life.

4. **Select Comb Attachment (Optional):** If a longer cutting length is desired, select one of the four snap-on comb attachments. Slide the comb firmly onto the blade until it locks into place.
5. **Power Connection:** Plug the clipper into a suitable electrical outlet. Ensure the voltage matches your local power supply.

5. Operating Instructions

Follow these steps for effective animal grooming:

1. **Prepare the Pet:** Ensure the animal's coat is clean, dry, and free of mats or tangles. Brush the coat thoroughly before clipping to remove loose hair and debris.
2. **Turn On the Clipper:** Slide the power switch to the "ON" position. The clipper operates with a quiet rotary motor.
3. **Begin Grooming:** Hold the clipper firmly and move it against the direction of hair growth for a shorter cut, or with the direction of hair growth for a longer, more natural finish. Use smooth, even strokes.



Figure 5.1: Grooming an animal with the clipper.

4. **Monitor Blade Temperature:** Periodically check the blade temperature. If the blade becomes hot, turn off the clipper, remove the blade, and allow it to cool. Using a hot blade can cause discomfort to the animal. Blade coolant sprays (sold separately) can also be used.
5. **Turn Off the Clipper:** Once grooming is complete, slide the power switch to the "OFF" position and unplug the clipper from the outlet.

6. Maintenance

Proper maintenance ensures the longevity and performance of your clipper.

- **Cleaning the Blade:** After each use, remove the blade and use a small brush (not included) to brush away any accumulated hair from between the blade teeth and the clipper head.
- **Oiling the Blade:** Re-oil the blade as described in the "Setup" section before storing. This prevents rust and keeps the blade sharp.
- **Cleaning the Clipper Body:** Wipe the clipper body with a clean, dry cloth. Do not use harsh chemicals or

abrasive cleaners.

- **Cord Care:** Do not wrap the cord around the clipper. Store the cord loosely to prevent damage.
- **Storage:** Store the clipper and all accessories in the provided hard storage case in a cool, dry place, out of reach of children.

7. Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Not plugged in; power outlet not working; damaged cord/plug.	Ensure clipper is securely plugged in. Test outlet with another device. If cord/plug is damaged, do not use; contact support.
Clipper pulls hair or cuts poorly.	Blade is dull; blade is not oiled; hair is matted/dirty; incorrect blade tension.	Oil the blade. Clean and brush pet's coat thoroughly. Replace dull blade. Ensure blade is properly attached.
Blade gets hot quickly.	Insufficient oiling; prolonged use; dirty blade.	Ensure blade is properly oiled. Take breaks during grooming. Clean blade thoroughly. Use blade coolant spray.
Excessive noise or vibration.	Blade not properly seated; internal issue.	Remove and reattach the blade, ensuring it clicks into place. If problem persists, contact support.

8. Specifications

- **Model:** 21420
- **Power Source:** Corded Electric
- **Motor Type:** Rotary
- **Blade Type:** Detachable Ceramic Blade (#10)
- **Included Comb Attachments:** 1/8", 1/4", 3/8", 1/2"
- **Item Weight:** 1.5 Pounds (approx.)
- **Dimensions (L x W x H):** 10.3 x 10.2 x 3.1 inches (approx.)
- **Material:** Polymer housing
- **Cord Length:** 12 feet (heavy-duty)

9. Warranty Information

The Andis EasyClip Pro-Animal Detachable Blade Clipper Kit comes with a **1 Year Limited Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, neglect, alteration, or unauthorized repair. Please retain your proof of purchase for warranty claims.

10. Customer Support

For technical assistance, warranty claims, or to purchase replacement parts, please contact Andis Customer Service:

- **Website:** www.andis.com
- **Phone:** Refer to the Andis website for regional contact numbers.

You can also refer to the officialUser Manual (PDF) for additional details.

© 2025 Andis Company. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0009XH6ZA

More documents and user manuals: **https://manuals.plus/**