Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia HS-26W-0279591

Nokia HS-26W Wireless Bluetooth Headset User Manual

Model: HS-26W-0279591 | Brand: Nokia

Introduction

This manual provides comprehensive instructions for the Nokia HS-26W Wireless Bluetooth Headset. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. The Nokia HS-26W is designed for convenient and comfortable hands-free communication.
It is compatible with mobile phones and devices supporting Bluetooth Specification 1.1 and higher, and specifically the Hands-Free Profile (HFP) and/or Headset Profile (HSP).

Product Overview



Figure 1: Nokia HS-26W Wireless Bluetooth Headset. This image shows the white headset with its transparent earhook, highlighting the main button and volume controls.

Key Features:

- **Bluetooth Wireless Technology:** Enables wireless connection to compatible devices.
- **Elastic Earhook:** Designed for comfortable wear over either ear.
- **Large Answer/End Button:** Provides convenient call management.
- **Extended Battery Life:** Offers up to 5 hours of talk time and up to 150 hours of standby time.
- **Handy Volume Control:** Allows easy adjustment of audio levels directly from the headset.

Setup

Charging the Headset:

Before first use, fully charge the headset. Connect the charger to the headset's charging port. The indicator light will show charging status and turn off or change color when fully charged. Charging time may vary.

Pairing with a Device:

1. Ensure the headset is charged and turned off.
2. Activate Bluetooth on your mobile phone or device. Refer to your device's user manual for specific instructions.

3. Put the Nokia HS-26W headset into pairing mode. Typically, this involves pressing and holding the main button until an indicator light flashes rapidly or a specific tone is heard.
4. On your device, search for Bluetooth devices. The Nokia HS-26W should appear in the list.
5. Select "Nokia HS-26W" from the list. If prompted for a passcode, enter **0000** (four zeros).
6. Once paired, the headset's indicator light may change, and a confirmation tone might be heard. The headset is now ready for use.

Note: The headset does not seem to have a dedicated pairing mode button; it enters pairing mode automatically when discoverable. If issues arise, ensure no other devices are actively connected to the headset.

Operating Instructions

Power On/Off:

- **To Power On:** Press and hold the main button until the indicator light illuminates.
- **To Power Off:** Press and hold the main button until the indicator light turns off.

Call Management:

- **Answer a Call:** Press the large answer/end button once.
- **End a Call:** Press the large answer/end button once during a call.
- **Reject a Call:** Press and hold the large answer/end button for approximately 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the large answer/end button when no call is active.

Volume Control:

Use the dedicated volume control buttons on the headset to adjust the listening volume during a call or when playing audio.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.
- **Avoid Moisture:** Do not expose the headset to water or excessive moisture.

Troubleshooting

Problem	Possible Cause	Solution
Headset does not power on.	Battery is discharged.	Charge the headset fully.
Cannot pair the headset with my device.	Headset not in pairing mode; Bluetooth off on device; device out of range.	Ensure headset is in pairing mode (refer to Setup section). Turn on Bluetooth on your device. Move headset closer to the device.

Problem	Possible Cause	Solution
Poor audio quality or static.	Device too far from headset; interference; low battery.	Move closer to the device. Avoid obstacles between headset and device. Charge the headset.
No sound from headset.	Volume too low; headset not connected; incorrect audio output selected on device.	Increase headset volume. Ensure headset is paired and connected. Check audio settings on your device.

Specifications

Model Number: HS-26W-0279591

Connectivity Technology: Wireless (Bluetooth)

Bluetooth Specification: Compatible with Bluetooth 1.1 and higher

Supported Profiles: Hands-Free Profile (HFP), Headset Profile (HSP)

Talk Time: Up to 5 hours

Standby Time: Up to 150 hours

Control Type: Volume Control, Touch (for main button)

Form Factor: On Ear / Over Ear (with earhook)

Color: White

Item Weight: 0.01 Ounces (approximately 0.28 grams)

Package Dimensions: 2.6 x 0.9 x 0.8 inches

Manufacturer: Nokia

UPC: 758478007136

Date First Available: October 26, 2005

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Nokia support website. Keep your proof of purchase for warranty claims.

© 2023 Nokia. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000BVM8BM

More documents and user manuals: **https://manuals.plus/**