Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Emerson CK5029

Emerson CK5029 AM/FM LED Clock Radio

User Instruction Manual

Introduction

Thank you for purchasing the Emerson CK5029 AM/FM LED Clock Radio. This device combines the functionality of an alarm clock with a dual-band AM/FM radio, featuring a clear LED display for time and settings. Designed for ease of use, it provides reliable timekeeping and audio entertainment. Please read this manual thoroughly before operating your new clock radio to ensure proper use and to maximize its features.



Figure 1: Front view of the Emerson CK5029 AM/FM LED Clock Radio, displaying the time on its red LED screen and showing the top-mounted controls and antenna.

Safety Information

- Do not expose this unit to rain or moisture to prevent fire or shock hazards.
- Ensure the power cord is not pinched or walked on, especially at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus,

the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Use only attachments/accessories specified by the manufacturer.

Setup

1. Power Connection

Connect the AC power cord into a standard wall outlet. The unit is designed to operate on 120V AC, 60Hz. Ensure the voltage in your region matches this requirement.

2. Battery Backup Installation

For continuous timekeeping during power outages, install a 9-volt battery (not included) into the battery compartment located on the bottom of the unit. This battery backup will maintain the time and alarm settings in case of a power interruption, though the display will not be illuminated.

1. Open the battery compartment cover.
2. Insert one 9-volt battery, observing the correct polarity (+ and -).
3. Close the battery compartment cover securely.

3. Setting the Time

To set the current time:

1. Press and hold the **TIME SET** button. The display will begin to flash.
2. While holding the **TIME SET** button, press the **HOUR** button repeatedly to advance the hour. Observe the PM indicator light if setting a PM hour.
3. While holding the **TIME SET** button, press the **MINUTE** button repeatedly to advance the minute.
4. Release the **TIME SET** button to save the set time.

Operating Instructions

1. Radio Operation

Your clock radio features both AM and FM bands.

- **Turning On/Off:** Press the **RADIO ON/OFF** button to turn the radio on or off.
- **Selecting Band:** Slide the **AM/FM** switch to select your desired radio band.
- **Tuning:** Rotate the **TUNING** knob to select your desired radio station.
- **Volume Control:** Rotate the **VOLUME** knob to adjust the sound level.
- **Antenna:** For optimal FM reception, extend the telescopic antenna fully. For AM reception, rotate the unit for best signal.

2. Setting the Alarm

You can set an alarm to wake you up with either the radio or a buzzer.

1. Press and hold the **ALARM SET** button. The alarm time display will begin to flash.
2. While holding the **ALARM SET** button, press the **HOUR** button repeatedly to set the alarm hour.
3. While holding the **ALARM SET** button, press the **MINUTE** button repeatedly to set the alarm minute.

4. Release the **ALARM SET** button to save the alarm time.
5. Slide the **ALARM MODE** switch (usually located on the side or back) to select your desired alarm mode: **OFF**, **BUZZER**, or **RADIO**.

3. Snooze Function

When the alarm sounds, press the large **SNOOZE** button (often located on top) to temporarily silence the alarm. The alarm will sound again after approximately 9 minutes.

4. Stopping the Alarm

To stop the alarm completely until the next day, slide the **ALARM MODE** switch to **OFF**.

Maintenance

Cleaning

Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish. Ensure the unit is unplugged before cleaning.

Battery Replacement

Replace the 9-volt battery annually or if you notice the time is incorrect after a power outage. Refer to the "Battery Backup Installation" section for instructions.

Troubleshooting

Problem	Possible Cause	Solution
Unit does not power on.	Power cord not securely plugged in.	Check that the AC power cord is firmly plugged into a working wall outlet.
Display is blank during power outage.	Battery backup not installed or depleted.	Install a fresh 9-volt battery for backup. The display will not light up during battery backup, but time will be retained.
Poor radio reception.	Antenna not extended/positioned correctly; interference.	Extend FM telescopic antenna fully. For AM, rotate the unit for best reception. Move unit away from other electronic devices.
Alarm does not sound.	Alarm not set correctly; alarm mode switch is OFF.	Verify alarm time is set. Ensure the ALARM MODE switch is set to BUZZER or RADIO, not OFF. Check volume if radio alarm is selected.

Specifications

Model: CK5029

Brand: Emerson

Tuner Technology: AM, FM

Display Type: Digital LED

Power Source: AC 120V, 60Hz (Battery Powered for backup)

Battery Backup: 9-volt (not included)

Radio Bands Supported: 2-Band

Frequency: 108 MHz (FM max, typical for clock radios)

Material: Plastic

Item Weight: Approximately 1.4 Pounds (635.03 g)

Product Dimensions: 19.56 x 6.6 x 16.26 cm (7.7 x 2.6 x 6.4 inches)

Warranty and Support

Specific warranty information for the Emerson CK5029 is not provided within this manual. For details regarding warranty coverage, technical support, or service inquiries, please refer to the documentation included with your purchase or visit the official Emerson Radio website. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may contact Emerson customer service through their official channels.

© 2023 Emerson Radio Corp. All rights reserved. Model: CK5029

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000CC49QM

More documents and user manuals: **https://manuals.plus/**