Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney Disney Princess Castle Radio Clock

Disney Princess Castle Radio Clock User Manual

Model: Disney Princess Castle Radio Clock

Introduction

Welcome to the user manual for your new Disney Princess Castle Radio Clock. This enchanting clock radio is designed to bring a touch of magic to any room, featuring beloved Disney Princesses Cinderella, Belle, and Aurora. It combines the functionality of a digital clock with an FM radio, all housed within a charming castle design. Please read this manual carefully to ensure proper setup and operation of your device.



Image Description: This image displays the Disney Princess Castle Radio Clock still in its original pink packaging. The front of the box features illustrations of Cinderella, Belle, and Aurora. The clock itself, designed as a pink castle with white turrets, is visible through a clear plastic window. Text on the box indicates "FM Radio" and "Disney Princess" branding.

Setup

1. Battery Installation

The Disney Princess Castle Radio Clock requires **3 AAA batteries** (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back or bottom of the clock unit.
2. Using a small Phillips head screwdriver, unscrew the battery compartment cover.

3. Insert 3 new AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

Important: Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove batteries when not in use or discharged.

2. Placement

Place the clock radio on a flat, stable surface away from direct sunlight, heat sources, and excessive moisture. Ensure there is adequate ventilation around the unit.



Image Description: This image shows the back of the Disney Princess Castle Radio Clock's packaging. The castle clock is visible from the rear, with its battery compartment area indicated. Text on the packaging specifies "Requires 3 AAA batteries (not included)" and includes FCC compliance statements. Illustrations of Cinderella, Belle, and Aurora are also present on the box.

Operating Instructions

Familiarize yourself with the buttons and controls on your Disney Princess Castle Radio Clock. While specific button labels may vary slightly, the general functions are as follows:

Setting the Time

1. Locate the "SET" or "TIME SET" button, usually on the back or bottom of the unit. Press and hold it until the display starts flashing.
2. Use the "HOUR" and "MINUTE" buttons (often labeled with arrows or +/-) to adjust the time. Press the "HOUR" button to change the hour and the "MINUTE" button to change the minute.
3. Once the correct time is set, press the "SET" or "TIME SET" button again to confirm and exit the setting mode.

Setting the Alarm

1. Locate the "ALARM SET" button. Press and hold it until the alarm time display starts flashing.
2. Use the "HOUR" and "MINUTE" buttons to set your desired alarm time.
3. Press the "ALARM SET" button again to confirm.
4. To activate or deactivate the alarm, locate the "ALARM ON/OFF" or "ALARM" switch/button. An indicator (e.g., a bell icon) on the display usually shows if the alarm is active.
5. When the alarm sounds, press the "SNOOZE" button (if available) for a temporary pause, or any other button to turn off the alarm for the day.

Using the FM Radio

1. Locate the "RADIO ON/OFF" or "POWER" button for the radio function. Press it to turn the radio on.
2. Use the "TUNING" dial or "FREQ +/-" buttons to scan for FM radio stations. The clock face itself has a "TUNING" knob.
3. Adjust the volume using the "VOLUME" dial or buttons.
4. To turn off the radio, press the "RADIO ON/OFF" or "POWER" button again.

Maintenance

Cleaning

To clean the clock radio, gently wipe the surface with a soft, slightly damp cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Ensure the unit is dry before operating.

Battery Replacement

When the display dims or the radio performance degrades, it's time to replace the batteries. Refer to the "Battery Installation" section under Setup for instructions on how to replace the 3 AAA batteries.

Troubleshooting

Problem	Possible Cause	Solution
Clock display is dim or blank.	Batteries are low or depleted.	Replace with new AAA batteries. Ensure correct polarity.

Problem	Possible Cause	Solution
Radio static or poor reception.	Weak signal; antenna not extended/positioned correctly.	Adjust the position of the clock radio. Try tuning to a stronger station.
Alarm does not sound.	Alarm not activated; alarm volume too low; incorrect alarm time set.	Ensure the alarm is turned ON. Check alarm volume. Verify the alarm time is set correctly.
Buttons are unresponsive.	Batteries are low or unit needs reset.	Replace batteries. Remove batteries for 1 minute, then reinsert to reset the unit.

Specifications

- **Brand:** Disney
- **Model:** Disney Princess Castle Radio Clock
- **Display Type:** Digital
- **Style:** Modern
- **Special Feature:** Radio (FM)
- **Product Dimensions:** 6"W x 7"H
- **Power Source:** Battery Powered (3 x AAA batteries, not included)
- **Shape:** Round (clock face) / Castle (overall design)
- **Theme:** Disney, Princess (Cinderella, Belle, Aurora)
- **Mounting Type:** Tabletop
- **Operation Mode:** Electrical
- **Item Weight:** Approximately 1.15 pounds
- **ASIN:** B000E5TAT8
- **UPC:** 0711119905611

Warranty and Support

Specific warranty information for the Disney Princess Castle Radio Clock is not provided in the product details. For any questions regarding product support, troubleshooting beyond this manual, or warranty inquiries, please contact Disney customer service or visit the official Disney consumer products website.
You may find general support information at theShopDisney Help Center (link provided as a general example for Disney products).

© 2023 Disney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000E5TAT8

More documents and user manuals: **https://manuals.plus/**