JAKKS Pacific 59268

JAKKS Pacific Toymax Scooby Doo TV Game Model 59268 Instruction Manual

Model: 59268 | Brand: JAKKS Pacific

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your JAKKS Pacific Toymax Scooby Doo TV Game, Model 59268. This plug-and-play video game console allows you to guide Scooby-Doo and friends through various adventures directly on your television. Please read this manual thoroughly before use to ensure proper functionality and enjoyment.

Package Contents

Before you begin, please ensure all components are present:

- 1 x Scooby Doo TV Game Console (Mystery Machine shaped controller)
- 5 x Pre-loaded Games (integrated into the console)
- Attached RCA Audio/Video Cables

Note: 4 AA batteries are required for operation and are not included.

Setup Instructions

Follow these steps to connect your Scooby Doo TV Game to your television:

1. **Install Batteries:** Locate the battery compartment on the underside of the Mystery Machine controller. Open the cover and insert 4 new AA batteries, ensuring correct polarity (+/-). Close the battery cover securely.
2. **Connect to TV:** Identify the RCA input ports on your television. These are typically colored yellow for video and white for mono audio (or red/white for stereo, in which case use the white port for audio).

   Yellow Cable: Connect to the yellow VIDEO IN port on your TV.

   White Cable: Connect to the white AUDIO IN port on your TV.
3. **Power On TV:** Turn on your television and select the appropriate video input channel (e.g., AV1, Video 1, Input). Refer to your TV's manual if you are unsure.
4. **Power On Game:** Locate the power switch on the Scooby Doo TV Game controller. Slide it to the 'ON' position. The game should now appear on your TV screen.



Image 1: The Scooby Doo TV Game controller, showing the joystick, buttons, and attached RCA audio/video cables for TV connection.

Operating Instructions

The Scooby Doo TV Game is designed for intuitive play. Here's how to operate it:

- **Joystick Control:** Use the central joystick to navigate menus, move characters, and select options within the games.
- **Action Buttons:** The buttons on the controller perform various actions depending on the game. Typically, these are used for jumping, interacting, or confirming selections.
- **Game Selection:** Upon powering on, you will typically be presented with a game selection menu. Use the joystick to highlight your desired game and an action button to select it.
- **Controller Orientation:** Ensure the cable extending from the controller is facing towards your television for proper control input. Incorrect orientation may lead to reversed controls.

Included Games:

Your console comes with 5 exciting Scooby Doo adventures:

1. Searching the Castle
2. The River of Frights
3. Race to Fontecastello

4. The Mysterious Doors
5. The Dungeons of Fontecastello

GameKey Ready: This controller is also GameKey ready. GameKeys are sold separately and allow for additional game content.

Maintenance

To ensure the longevity of your Scooby Doo TV Game, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the console. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the finish or internal components.
- **Storage:** Store the console in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Battery Care:** Remove batteries from the compartment if the console will not be used for an extended period (e.g., several weeks or months) to prevent potential battery leakage and damage.

Troubleshooting

If you encounter any issues with your Scooby Doo TV Game, please refer to the following common solutions:

Problem	Solution
No picture or sound on TV.	◦ Ensure the RCA audio/video cables are securely connected to both the game console and the correct input ports on your television. ◦ Verify that your television is set to the correct video input channel (e.g., AV1, Video 1). ◦ Check that the game console's power switch is in the 'ON' position. ◦ Replace the AA batteries with fresh ones.
Controls are reversed or not responding correctly.	◦ Ensure the Mystery Machine controller is oriented correctly, with the cable extending towards the television. ◦ Check battery power and replace if necessary.
Graphics appear pixelated or low quality on an HD TV.	This is a standard definition (SD) plug-and-play game. When displayed on modern high-definition (HD) televisions, SD content may appear pixelated or less sharp than HD content. This is normal for this type of product and not an indication of a defect.

Specifications

Brand	JAKKS Pacific
Model Number	59268
Included Components	Console (with 5 integrated games), RCA Audio/Video Cables
Power Source	4 x AA Batteries (not included)
Connectivity	RCA Audio/Video (Composite)
Number of Players	1 Player (base unit)
Recommended Age	5 years and up
Item Dimensions (L x W x H)	9.61 x 8.39 x 0.12 inches
UPC	720634592688

Warranty Information

Specific warranty details for the JAKKS Pacific Toymax Scooby Doo TV Game Model 59268 are not provided in this document. Please refer to the product packaging or the official JAKKS Pacific website for any available warranty information.

Customer Support

For further assistance or inquiries regarding your JAKKS Pacific Toymax Scooby Doo TV Game, please visit the official JAKKS Pacific website or contact their customer service department. Contact information is typically available on the product packaging or their corporate website.

© 2024 JAKKS Pacific. All rights reserved. Scooby-Doo and all related characters and elements are trademarks of Hanna-Barbera. (s24)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question