Kichler 9320BK

Kichler 8.5" Polypropylene 1-Light Outdoor Flush Mount (Model 9320BK) Instruction Manual

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Kichler 8.5" Polypropylene 1-Light Outdoor Flush Mount. Please read all instructions carefully before beginning installation and retain this manual for future reference.
This outdoor flush mount features a classic black finish and frosted glass, designed to provide ambient lighting in covered outdoor areas such as entryways, patios, or porches.

Important Safety Information

To reduce the risk of fire, electric shock, or personal injury, always follow these basic safety precautions:

- Always turn off the electrical current at the main circuit breaker or fuse box before installation, cleaning, or servicing the fixture.
- Consult a qualified electrician if you are unsure about the installation process or have any electrical questions.
- Ensure all wiring connections are secure and comply with all local electrical codes and ordinances.
- This fixture is rated for outdoor use only, specifically in covered areas.
- Use only one medium E26 base bulb, with a maximum equivalent wattage of 60W. Do not exceed the specified maximum wattage.
- Do not connect the fixture to an ungrounded electrical system.

Package Contents

Verify that all components listed below are included in your package. If any parts are missing or damaged, do not attempt to assemble or install the fixture. Contact Kichler customer service for assistance.

- Mounting Strap
- Strap Mounting Screws
- Mounting Screws
- Nipple

- Hex Nut
- Finial
- Frosted Glass Shade
- Retainer Clips
- Wire Nuts
- Instruction Manual

Note: Bulb(s) are not included. This fixture requires one medium E26 base bulb, up to 60W equivalent.

Installation Instructions

Tools Required: Screwdriver, Wire Strippers, Pliers, Electrical Tape, Safety Glasses.

1. **Step 1: Prepare for Installation.** Before beginning, ensure the electrical current is completely turned off at the main circuit breaker or fuse box. This is a critical safety step.
2. **Step 2: Attach Mounting Strap.** Secure the provided mounting strap to the electrical junction box in your ceiling using the strap mounting screws. Ensure the strap is firmly and securely attached.
3. **Step 3: Make Electrical Connections.** Carefully connect the fixture's wires to the corresponding house wires using the provided wire nuts. Connect the black wire (live) from the fixture to the black wire from the junction box. Connect the white wire (neutral) from the fixture to the white wire from the junction box. Connect the ground wire from the fixture to the house ground wire. After making connections, wrap each wire nut with electrical tape for added security.
4. **Step 4: Mount the Fixture.** Carefully align the fixture base with the mounting strap. Secure the fixture to the mounting strap using the mounting screws, nipple, hex nut, and finial. Ensure the fixture is flush against the ceiling and securely fastened.
5. **Step 5: Install Glass Shade.** Gently place the frosted glass shade into the fixture. Secure it in place using the retainer clips, ensuring it is stable and will not fall.
6. **Step 6: Install Bulb.** Screw one medium E26 base bulb (up to 60W equivalent, not included) into the socket. Do not overtighten the bulb.
7. **Step 7: Restore Power.** Once installation is complete and all components are secure, turn the electrical current back on at the main circuit breaker or fuse box.



Image: Kichler 8.5" Polypropylene 1-Light Outdoor Flush Mount, Black.

Operating Instructions

This Kichler flush mount light is designed for simple operation. Once installed and power is restored, the light can be controlled via a standard wall switch (push button or rotary type, not included) connected to the circuit.
The fixture is dimmable, allowing you to adjust the light intensity if connected to a compatible dimmer switch and using a dimmable E26 bulb. Ensure any dimmer switch used is compatible with the bulb type (e.g., incandescent or dimmable LED).
Ensure the bulb used is a medium E26 base, with a maximum equivalent wattage of 60W.

Care and Maintenance

Regular cleaning will help maintain the appearance and performance of your Kichler light fixture.

- **Cleaning:** Before cleaning, ensure the electric current is turned off at the main circuit breaker. Clean metal components with a soft cloth moistened with a mild liquid soap solution. Wipe clean and buff with a very soft dry cloth. Do not use abrasive cleaners, harsh chemicals, or solvents, as they may damage the finish or glass.
- **Bulb Replacement:** Always turn off power at the circuit breaker before replacing the bulb. Allow the bulb to cool completely before touching it. Unscrew the old bulb and replace it with a new medium E26 base bulb (up to 60W equivalent).

Troubleshooting

If you encounter issues with your light fixture, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture.	Check the circuit breaker and wall switch. Ensure power is on.
	Loose wire connection.	Turn off power at the circuit breaker. Check all wire connections for tightness.
	Faulty bulb.	Turn off power. Replace the bulb with a new one (E26, max 60W equivalent).
Light flickers.	Loose bulb.	Turn off power. Tighten the bulb in the socket.
	Incompatible dimmer switch or bulb.	Ensure the dimmer switch is compatible with the bulb type. Use a dimmable bulb if using a dimmer.
Light is too dim/bright.	Incorrect bulb wattage.	Ensure bulb wattage is appropriate for desired brightness (max 60W equivalent). Use a dimmer switch for adjustable brightness.

If the issue persists after attempting these solutions, contact a qualified electrician or Kichler customer support.

Product Specifications

Feature	Detail
Brand	Kichler
Model Number	9320BK
Material	Polypropylene
Finish	Black
Shade Material	Plastic (Frosted Glass)
Dimensions (L x W x H)	8.5"L x 8.5"W x 8.5"H
Item Weight	2.12 Pounds
Light Source	Incandescent (compatible with LED equivalent)
Number of Light Sources	1
Bulb Base	E26 Medium
Max Wattage	60W equivalent
Voltage	120 Volts
Indoor/Outdoor Usage	Outdoor
Installation Type	Flush Mount

Feature	Detail
Water Resistance Level	Water Resistant
Dimmable	Yes (with compatible dimmer and bulb)
UL Listed	Yes

Warranty and Support

This Kichler product comes with a **1-year warranty** against manufacturer defects from the date of purchase.
For warranty claims, technical assistance, or to report missing or damaged parts, please contact Kichler customer support directly. Keep your proof of purchase for warranty validation.
You can find more information and contact details on the official Kichler website or by visiting the Kichler Store on Amazon: Visit the Kichler Store on Amazon.

Official Product Video

Your browser does not support the video tag.

Video: Kichler Brand Story. This video provides an overview of the Kichler brand and its commitment to lighting solutions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question