Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kichler 9736TZ

Kichler Barrie Outdoor Wall Light

MODEL: 9736TZ

Brand: Kichler

Product Overview

The Kichler Barrie 9736TZ is a 21.75-inch, 1-light outdoor wall light designed to enhance exterior spaces with its classic and sophisticated aesthetic. Featuring a Tannery Bronze finish and clear beveled glass, this fixture provides ambient illumination suitable for various home styles. It is constructed from durable aluminum and glass, ensuring longevity and resistance to outdoor elements.



Image: Kichler Barrie 21.75 inch outdoor wall light in Tannery Bronze.

Safety Information

- Always turn off the main power supply at the circuit breaker before installation, maintenance, or bulb replacement.
- Consult a qualified electrician if you are unsure about any part of the installation process.
- Ensure all electrical connections are secure and comply with local electrical codes.
- This fixture is designed for outdoor, wet locations.

Installation Instructions

The Kichler Barrie outdoor wall light is designed for surface mount installation and requires assembly. Follow these general steps for installation. Refer to the detailed diagram included with your product packaging for specific wiring and mounting instructions.

1. **Prepare the Installation Area:** Turn off power at the circuit breaker. Ensure the mounting surface is clean, dry, and structurally sound.

2. **Mount the Crossbar:** Attach the provided crossbar with ground screw to your electrical junction box using the strap mounting screws.
3. **Connect Wiring:** Carefully connect the fixture's wires to your household electrical wires according to standard electrical codes (usually black to black, white to white, and ground to ground). Secure connections with wire nuts.
4. **Secure the Fixture:** Position the fixture over the crossbar and secure it to the mounting surface using the provided screws, lockwashers, and knobs. Ensure the fixture is snug against the wall to prevent moisture entry.
5. **Install the Bulb:** Insert one E26 base incandescent bulb, up to 100 watts (bulb not included).
6. **Restore Power:** Turn the power back on at the circuit breaker.

Your browser does not support the video tag.

Video: A user demonstrates the installation and features of the Kichler Barrie outdoor wall light, highlighting its design and ease of bulb replacement.



Image: Kichler Barrie outdoor wall lights installed on a home exterior.

Operating Instructions

This outdoor wall light operates using a standard wall switch (push button type) and is compatible with dimmable bulbs and dimmer switches. Ensure the bulb installed is dimmable if you intend to use this feature.

- **Turning On/Off:** Use your existing wall switch to control the light.
- **Dimming (Optional):** If a dimmable bulb and compatible dimmer switch are installed, adjust the dimmer to achieve your desired light level.

Maintenance

Regular maintenance will ensure the longevity and optimal performance of your Kichler Barrie outdoor wall light.

- **Cleaning:** Periodically clean the fixture with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or glass.
- **Bulb Replacement:** Before replacing the bulb, turn off the power at the circuit breaker. Allow the old bulb to cool completely. Carefully unscrew the old bulb and screw in a new E26 base incandescent bulb (max 100W).
- **Inspection:** Annually inspect the wiring and mounting for any signs of wear, corrosion, or looseness. Tighten any loose connections or screws as needed.

Your browser does not support the video tag.

Video: A user provides a review of the outdoor wall light, discussing its durability, ease of installation, and design, which can be helpful for understanding maintenance aspects.

Troubleshooting

If your Kichler Barrie outdoor wall light is not functioning correctly, consider the following common issues:

- **Light does not turn on:**
  - Check the circuit breaker to ensure power is supplied to the fixture.
  - Verify the light bulb is securely screwed in and not burnt out. Replace if necessary.
  - Ensure all wiring connections are secure.
- **Light flickers:**
  - Confirm the bulb is fully tightened.
  - If using a dimmer, ensure the bulb is compatible with the dimmer switch.
  - Check for loose wiring connections.

For persistent issues, contact a qualified electrician or Kichler customer support.

Specifications

Brand	Kichler
Model Number	9736TZ
Color	Tannery Bronze
Material	Aluminum, Glass
Style	Traditional
Light Fixture Form	Wall

Product Dimensions	8"L x 8"W x 21.75"H
Indoor/Outdoor Usage	Outdoor
Power Source	Hardwire
Installation Type	Surface Mount
Special Feature	Dimmable
Control Method	Push Button (via wall switch)
Light Source Type	Incandescent
Number of Light Sources	1
Voltage	120 Volts
Max Wattage	100 watts
Bulb Base	E26
Item Weight	4.75 Pounds
Assembly Required	Yes
UL Listed	Yes

Warranty and Support

The Kichler Barrie outdoor wall light comes with a limited one (1) year warranty from the date of purchase. For detailed warranty information and to register your product, please visit the official Kichler website:
Kichler Outdoor Warranty Information
For additional support, product inquiries, or to explore other Kichler products, visit the Kichler Store:
Visit the Kichler Store on Amazon

© 2023 Kichler. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000H6WQOA

More documents and user manuals: **https://manuals.plus/**