KODAK V705

Kodak EasyShare V705 Digital Camera User Manual

Model: V705

Introduction | What's in the Box | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides instructions for the proper use and care of your Kodak EasyShare V705 Digital Camera. The V705 features a unique dual-lens design, offering both ultra-wide-angle and 5x optical zoom capabilities, along with a 7.1-megapixel sensor for high-quality images.



Figure 1: Kodak EasyShare V705 Digital Camera. This image shows the compact silver body of the camera with its distinctive dual-lens system, indicating its wide-angle and zoom capabilities.

2. What's in the Box

Verify that all items are present before beginning setup:

- Kodak EasyShare V705 Dual-Lens Digital Camera
- Camera Pouch
- Carry Strap
- Kodak Rechargeable Li-ion Battery
- Adapter/Cables for USB and Video
- 5V AC Adapter with Power Cord(s) for in-camera battery charging
- Getting Started Guide
- Custom Camera Insert for optional Kodak EasyShare Photo Frame Dock 2 (dock not included)
- Custom Camera Insert for optional Kodak EasyShare Camera and Printer Docks

3. Setup

3.1. Charging the Battery

The camera uses a Kodak rechargeable Li-ion battery. Before first use, fully charge the battery.

1. Insert the rechargeable Li-ion battery into the camera's battery compartment.
2. Connect the 5V AC adapter to the camera and a power outlet.
3. Allow the battery to charge until the charging indicator light signals completion.

3.2. Inserting a Memory Card (Optional)

The camera has internal memory. For extended storage, insert a compatible memory card.

1. Open the memory card compartment door.
2. Insert the memory card in the correct orientation until it clicks into place.
3. Close the compartment door securely.

If the memory card becomes full, the camera can switch to its internal memory to avoid missing a shot.

3.3. Initial Power On

Press the power button to turn on the camera. The 2.5-inch high-resolution LCD display will activate, providing a clear view for framing shots and reviewing images.

4. Operating the Camera

4.1. Basic Photography

The Kodak EasyShare V705 is designed for ease of use, capturing 7.1-megapixel images suitable for prints up to 15 x 20 inches.

- **Dual-Lens System:** The camera features both an ultra-wide-angle lens and a 5x optical zoom lens, allowing for versatile shooting from expansive landscapes to detailed close-ups.
- **Kodak Perfect Touch Technology:** This feature automatically enhances pictures, making them more vivid and revealing details in dark shadows.
- **Anti-Blur Technology:** Reduces blur caused by camera shake, subject movement, and low-light conditions, helping to ensure sharper images.
- **Scene Modes:** Select from 22 scene modes (e.g., portrait, landscape, night, sport) and three color modes to optimize camera settings for various shooting environments. Panorama stitch mode allows capturing up to 180 degrees of wide-angle coverage.
- **On-Camera Cropping:** Crop images directly on the camera to focus on important details.
- **Blurry Picture Alert:** The camera notifies you if a picture is out of focus, allowing for immediate retakes.
- **Digital Red-Eye Reduction:** Automatically reduces red-eye during picture capture.
- **Histogram Feature:** Use the histogram on live view, quick view, and review modes to verify picture exposure.

4.2. Video Recording

The V705 can record VGA video (640 x 480) at 30 frames per second with sound.

- **Zoom During Video:** Utilize the optical zoom function while recording videos to get closer to the action.
- **Digital Image Stabilization:** Helps maintain steady video footage.
- **On-Camera Video Trim:** Trim videos directly on the camera to create smaller file sizes for sharing.
- **MPEG-4 Compression:** Efficiently stores more video footage using less memory.
- **Video Prints:** Create prints from video frames (4, 9, or 16 up).

4.3. Sharing Features

- **Share Button:** Use the dedicated Share button on the camera to tag pictures for easy printing or emailing later when connected to a computer with Kodak EasyShare Software.
- **Favorites Feature:** Mark special pictures as favorites for quick access.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your camera.

- **Cleaning the Lenses and Screen:** Use a soft, lint-free cloth specifically designed for optical surfaces. Avoid harsh chemicals.
- **Battery Care:** Store the battery in a cool, dry place when not in use. Avoid extreme temperatures.
- **Storage:** When not in use, store the camera in its pouch or a protective case to prevent dust and scratches. Avoid storing in direct sunlight or high humidity.
- **Software Updates:** Periodically check the Kodak support website for any available firmware or software updates for your camera.

6. Troubleshooting

This section addresses common issues you might encounter with your Kodak EasyShare V705.

Problem	Possible Solution
Camera does not power on.	Ensure the battery is fully charged and correctly inserted. Try charging the battery for a longer period.
Images are blurry.	Check for the blurry picture alert. Ensure sufficient lighting. Hold the camera steady or use anti-blur technology. Clean the lens.
Red-eye in photos.	Ensure digital red-eye reduction is enabled in camera settings.
Poor battery life.	Reduce LCD brightness. Limit flash usage. Ensure battery is fully charged before use. Consider purchasing a spare battery for extended shooting.
Cannot transfer photos to computer.	Ensure the USB cable is securely connected to both the camera and computer. Verify Kodak EasyShare Software is installed on your computer.

7. Specifications

Feature	Detail
Model Name	Kodak EasyShare V705
Effective Still Resolution	7.1 MP
Photo Sensor Technology	CCD
Optical Zoom	5x (Dual-Lens: Ultra-Wide-Angle & Zoom)
Minimum Focal Length	23 Millimeters
Image Stabilization	Digital, Optical
Display Type	2.5-inch LCD display
Video Resolution	640 x 480 (VGA) at 30 fps
Video Capture Format	MPEG-4
Supported File Format	JPEG, RAW
Expanded ISO Range	50 - 1000

Feature	Detail
Connectivity Technology	USB
Battery Type	Lithium Ion (Rechargeable)
Item Weight	12 ounces
Color	Silver
GTIN (UPC)	041771891190

8. Warranty and Support

8.1. Warranty Information

The Kodak EasyShare V705 Digital Camera comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For further assistance, technical support, or warranty service, please refer to the official Kodak support channels. Visit the **KODAK Store on Amazon** or the official Kodak website for contact information and resources.

© 2024 KODAK. All rights reserved.