KODAK 8642563

Kodak Funsaver One Time Use Film Camera Instruction Manual

Model: 8642563

Introduction

The Kodak Funsaver One Time Use Film Camera is designed for ease of use, providing a simple way to capture memories with the classic look of film photography. This manual provides essential instructions for operating your camera.



Image: Packaging for the Kodak Funsaver One Time Use Film Camera 2-pack, showing the camera design and film speed.

Setup

The Kodak Funsaver camera comes pre-loaded with Kodak 800 speed, 27 exposure 35mm film. No assembly or film loading is required before initial use.

Battery Installation (for Flash)

The camera's flash function requires batteries. While typically pre-installed, ensure the camera has working batteries if the flash does not activate. The camera uses 2 AA batteries.

Operating Instructions

Follow these steps to take a photograph with your Kodak Funsaver camera:

1. **Wind the Film:** Use the thumbwheel on the top right of the camera to advance the film until it stops. This cocks the shutter for the next shot.
2. **Charge the Flash (Optional):** If shooting indoors or in low light, slide the flash button on the front of the camera upwards. Hold it until the red light on the top of the camera illuminates, indicating the flash is charged and ready. The flash has a range of 4 to 11.5 feet (1.2 to 3.5 meters).
3. **Compose Your Shot:** Look through the viewfinder to frame your subject. For optimal flash results, ensure your subject is within the recommended flash range.
4. **Take the Picture:** Press the shutter button firmly. If using the flash, it will fire automatically when the shutter is pressed.
5. **Repeat:** After each shot, wind the film again to prepare for the next picture.





Image: Front and back views of the Kodak Funsaver camera, highlighting the lens, flash, and film winding mechanism.

Film Development

Once all 27 exposures have been used, the camera is ready for film development. Take the entire camera to a photo lab that offers 35mm film processing. The lab will remove the film and develop your pictures.

Your browser does not support the video tag.

Video: A demonstration on how to use the Kodak Funsaver camera, including winding the film, activating the flash, and taking pictures. It also shows examples of photos taken with the camera.

Maintenance

As a one-time-use camera, the Kodak Funsaver requires minimal maintenance. Keep the camera dry and avoid exposing it to extreme temperatures or direct sunlight for prolonged periods, as this can affect film quality. Do not attempt to open the camera body, as this will expose the film and ruin your pictures.

Troubleshooting

- **Flash Not Firing:** Ensure you have slid the flash button up and held it until the red light illuminates. If the light does not come on, the batteries may be depleted or the flash mechanism may be faulty.
- **Film Not Advancing:** Ensure you are turning the thumbwheel until it completely stops. If it still doesn't advance, the film may be at the end of its roll (27 exposures).
- **Blurry Photos:** Hold the camera steady when taking a picture. Ensure your subject is within the optimal focus range (approximately 4 feet to 11.5 feet for flash photography).

Specifications

- **Product Dimensions:** 1.8 x 5.5 x 6.5 inches
- **Item Weight:** 9 ounces (0.56 Pounds)
- **Film Format Type:** 35mm
- **Film Speed:** Kodak 800 speed
- **Exposures:** 27 per camera
- **Special Feature:** Built-in Manual Flash

- **Flash Range:** 4 to 11.5 feet (1.2 to 3.5 meters)
- **Batteries:** 2 AA batteries required (for flash)
- **Shutter Type:** Focal Plane Shutter

Warranty and Support

For specific warranty information or support inquiries regarding your Kodak Funsaver camera, please refer to the packaging or contact Kodak customer service directly. As a one-time-use product, warranty coverage typically applies to manufacturing defects only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question