Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer UB 33

Beurer UB 33 Fleece Heated Under Blanket for Single Bed Instruction Manual

Model: UB 33

1. Introduction

This manual provides essential instructions for the safe and effective use of your Beurer UB 33 Fleece Heated Under Blanket. Please read all instructions carefully before first use and retain for future reference. This product is designed to provide comfortable warmth for a single bed.

2. Safety Information

Always observe the instructions for use and safety notes provided with the product. The Beurer Safety System (BSS) is integrated to prevent overheating. Do not use if the blanket is wet or folded. Ensure the control unit is always accessible.

3. Included Components

Your Beurer UB 33 package contains the following items:

- 1 x Heated Under Blanket
- 1 x Control Unit
- 1 x Operating Instructions Manual

4. Setup

1. **Unpack the Blanket:** Carefully remove the heated under blanket from its packaging.
2. **Position on Mattress:** Unfurl the electric under blanket and lay it flat and crease-free on your mattress. Ensure it covers the desired sleeping area without overlapping or folding.
3. **Cover with Fitted Sheet:** Pull a standard fitted sheet over both the mattress and the electric under blanket in the usual manner. This helps secure the blanket and prevents heat loss.
4. **Connect Control Unit:** Connect the control unit to the under blanket by firmly inserting the connector.

5. **Plug into Power:** Insert the power plug into a suitable electrical socket.





Image: The Beurer UB 33 heated under blanket positioned flat on a mattress.

Video: A demonstration of how to set up and use the Beurer UB 33 heated under blanket, including laying it on the mattress, connecting the control, and selecting temperature settings.

5. Operation

1. **Pre-heating:** For optimal warmth, switch on the under blanket approximately 30 minutes before going to bed.
2. **Temperature Settings:** The control unit offers three temperature settings:
    - **Setting 1:** Recommended for long-term use, providing gentle warmth.
    - **Setting 2:** Medium heat.
    - **Setting 3:** For fast heating to quickly warm the bed.
3. **Switching Off:** To turn off the under blanket, slide the control to setting '0'. Always switch off and unplug the blanket when not in use.



Image: Detailed view of the control unit, showing the three temperature settings and the off position.

6. Cleaning and Maintenance

Proper cleaning and maintenance ensure the longevity and safe operation of your heated under blanket.

1. **Disconnect Power:** Before cleaning, always disconnect the plug from the power source and remove the control unit from the blanket.
2. **Spot Cleaning:** Small marks can be removed using a damp cloth.
3. **Hand Washing:** If the under blanket is very dirty, it can be hand washed at 30°C. Refer to the care label for specific washing symbols.

4. **Drying:** Allow the blanket to air dry completely before re-connecting the control unit and using it again. Do not tumble dry or iron.



Image: Icons illustrating key features: removable connector for washing, hand washable, and breathable material.

7. Troubleshooting

If you encounter issues with your Beurer UB 33, please refer to the following common solutions:

- **Blanket not heating:**
  - Ensure the power plug is securely inserted into the wall socket.
  - Verify that the control unit is firmly connected to the blanket.
  - Check if the temperature setting is above '0'.
  - The Beurer Safety System (BSS) may have activated due to overheating. Unplug the blanket and allow it to cool down for at least 30 minutes before attempting to use it again.
- **Uneven heating:**
  - Ensure the blanket is laid completely flat and crease-free on the mattress. Folds or creases can affect heat distribution.
- **Control unit light not illuminating:**
  - Confirm the blanket is plugged in and switched on. If the issue persists, contact customer support.

8. Specifications

Feature	Detail
Brand	Beurer
Model Name	UB 33
Material	Fleece, Cotton (upper surface)
Colour	White

Special Feature	Breathable, Beurer Safety System (BSS), Illuminated Temperature Settings, Removable Switch
Product Dimensions	150L x 80W Centimeters
Item Weight	0.98 Grams
Temperature Settings	3
Product Care Instructions	Machine Washable (Hand wash at 30°C recommended)
UPC	013995003161

9. Warranty and Support

The Beurer UB 33 Fleece Heated Under Blanket comes with a 5-year warranty. For warranty claims, technical support, or further inquiries, please contact Beurer customer service. Manufacturer contact details: Beurer GMBH, Soflinger, Ulm, Germany, info@beurer.com, +49 (731) 3989-0.

© 2025 Beurer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000I6IY2W

More documents and user manuals: **https://manuals.plus/**