Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PlanToys 0512600

PlanToys Pound-a-Peg Toy Instruction Manual

Model: 0512600 | Brand: PlanToys

1. Introduction

The PlanToys Pound-a-Peg Toy is a classic wooden hammering toy designed to provide engaging play for toddlers. It encourages the development of fine motor skills, hand-eye coordination, and an understanding of cause and effect. Made with sustainable practices and materials, this toy offers a safe and enriching play experience.



Image: The PlanToys Pound-a-Peg Toy featuring a wooden board with colorful pegs and a small wooden hammer.

2. What's in the Box

- 1 x Wooden Board with Peg Holes
- 1 x Wooden Hammer
- 4 x Colorful Wooden Pegs

3. Setup

The PlanToys Pound-a-Peg Toy requires minimal setup and is ready for play almost immediately out of the box.

1. Unpack all components from the packaging.
2. Place the wooden board on a flat, stable surface.
3. Insert the colorful wooden pegs into the designated holes on the board. Ensure they are seated upright.
4. Place the wooden hammer within reach.

The toy is now ready for use.

4. Operating Instructions

The Pound-a-Peg Toy is designed for simple, repetitive, and engaging play.

1. Hold the wooden hammer firmly.
2. Aim the hammer at the top of one of the colorful pegs.
3. Gently tap the peg with the hammer until it is pushed through the hole and falls to the other side.
4. Repeat with the remaining pegs.
5. Once all pegs have been hammered through, simply flip the wooden board over to reset the pegs and continue playing.

This action-reaction play helps children understand basic physics and develop their motor skills.



Image: Children engaging with PlanToys, demonstrating the development of hand-eye coordination and fine motor skills.

5. Maintenance

To ensure the longevity and safety of your PlanToys Pound-a-Peg Toy, follow these maintenance guidelines:

- **Cleaning:** Wipe the toy with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners. Dry thoroughly immediately after cleaning.
- **Storage:** Store the toy in a dry place away from direct sunlight and extreme temperatures to prevent warping or damage to the wood.
- **Inspection:** Periodically inspect the toy for any signs of wear, damage, or loose parts. Discontinue use if any damage is found and contact customer support.

6. Sustainability & Materials

PlanToys is committed to sustainable play and environmental responsibility. This toy is crafted from eco-friendly materials and through responsible production processes.

- **Rubberwood:** Made from natural, organic, recycled rubberwood trees that no longer produce latex.
- **PlanWood™:** Branches and other wood waste are shredded and transformed into PlanWood™, a durable and non-toxic material.
- **Non-Toxic Finishes:** Colored with water-based dyes, plant-based ink, and non-formaldehyde glue, ensuring safety for children.



Image: Visual representation of PlanToys' commitment to using natural, safe, and eco-friendly materials in their products.

Sustainable Play Philosophy

PlanToys believes in "Better Kids for a Better World" and integrates sustainability into every aspect of their operations, from sourcing raw materials to manufacturing processes.

Your browser does not support the video tag.

Video: An official video from PlanToys detailing their commitment to sustainable practices, from rubber tree forests to their manufacturing

processes and community involvement.

7. Specifications

Product Dimensions	6.3 x 6.3 x 3.46 inches
Item Weight	1.2 pounds
Model Number	0512600
Recommended Age	24 months - 4 years
Materials	Rubberwood, PlanWood™, Water-based dyes, Non-formaldehyde glue

8. Troubleshooting

- **Pegs too loose/fall out easily:** This toy is designed for easy hammering and flipping. If pegs are excessively loose, it might be due to natural wood expansion/contraction. Ensure the toy is stored in a stable environment. This is generally not a defect but part of the toy's design for young children.
- **Pegs too tight/difficult to hammer:** If pegs are unusually tight, check for any debris in the holes. A slight variation in wood can occur. Gentle, consistent pressure should allow the pegs to pass through.
- **Wood appears discolored or damaged:** Ensure the toy is kept dry and away from prolonged moisture or direct sunlight. If significant damage occurs, discontinue use for safety.

9. Warranty & Support

PlanToys stands behind the quality of its products. For any questions, concerns, or warranty inquiries regarding your Pound-a-Peg Toy, please contact PlanToys customer support directly through their official website or the retailer where the product was purchased. Please have your model number (0512600) and purchase information ready.

© 2024 PlanToys. All rights reserved.
For more information, visit the PlanToys Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000I8SO98

More documents and user manuals: **https://manuals.plus/**