Logitech 967685-0403

Logitech diNovo Edge Keyboard User Manual

Model: 967685-0403

Introduction

Welcome to the user manual for your Logitech diNovo Edge Keyboard. This ultra-slim, high-performance keyboard is designed to provide an exceptional typing and navigation experience. Featuring a unique TouchDisc, PerfectStroke key system, and advanced Bluetooth wireless technology, the diNovo Edge is an ideal companion for your computer setup. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new keyboard.



Figure 1: The Logitech diNovo Edge Keyboard with its elegant charging base.

Setup

Package Contents

Before you begin, ensure all items are present in your package:

- Logitech diNovo Edge Keyboard
- Charging base
- AC power cord
- USB mini-receiver
- Installation CD (includes Logitech SetPoint software, comfort guidelines, help center)
- User's guide (this document)

System Requirements

To use the Logitech diNovo Edge Keyboard, your system must meet the following requirements:

- IBM or Compatible PC
- Windows XP (Service Pack 2) or Windows Vista (all editions)
- Available USB port
- CD-ROM Drive (for software installation)

Initial Setup and Charging

1. **Connect the Charging Base:** Plug the AC power cord into the charging base, then plug the other end into a wall outlet.
2. **Place Keyboard on Base:** Gently place the diNovo Edge Keyboard onto the charging base. The keyboard will begin charging. A full charge takes approximately 2 hours and provides up to 2 months of usage. A quick 5-minute charge can provide enough power for approximately one day of use.
3. **Install USB Mini-Receiver:** Insert the USB mini-receiver into an available USB port on your computer. Your computer should automatically detect the receiver.
4. **Install Software:** Insert the Installation CD into your computer's CD-ROM drive. Follow the on-screen prompts to install the Logitech SetPoint software. This software enables full functionality of the keyboard's advanced features and customization options.
5. **Power On Keyboard:** Locate the On/Off switch on the keyboard (typically on the side or back) and slide it to the 'On' position. The keyboard should automatically connect to the USB mini-receiver via Bluetooth.


Scroll Lock
Pause
F12
Insert
Print Screen
Backspace
Home
End
Delete
Page Up
Page Down
Enter
Ctrl
Logitech

Figure 2: The diNovo Edge Keyboard positioned on its charging base, which also serves as a stand.

Operating Instructions

PerfectStroke Key System

The diNovo Edge features Logitech's PerfectStroke key system, which uses a precision micro-scissors mechanism. This design distributes typing force evenly across the key surfaces, resulting in a natural, fluid, and quiet typing experience. Each key is designed to support 10 million keystrokes.

TouchDisc Navigation

The revolutionary TouchDisc located on the right side of the keyboard unifies scrolling, selection, and cursor control. It functions as a highly responsive touchpad.

- **Cursor Control:** Move your finger across the TouchDisc surface to control the mouse cursor on your screen.
- **Scrolling:** To scroll, press the dot in the center of the TouchDisc and then slide or rotate your finger around the circular area. This enables hyper-speed scrolling for quick navigation through documents and web pages.
- **Clicking:** The TouchDisc supports left and right clicks. Refer to the SetPoint software for customization of click functions.
- **Disabling TouchDisc:** The TouchDisc can be temporarily disabled by pressing the **FN** key simultaneously with the **Left Click** button on the keyboard.



Figure 3: Detailed view of the TouchDisc for navigation and the touch-sensitive volume slider.

Backlit Stealth Controls

The diNovo Edge features hidden hot keys that illuminate only when needed. These 17 one-touch access controls provide instant feedback and fade into the background when not in use.

- **Activation:** Simply touch or hover near the control area, and the relevant icons will light up.
- **Volume Control:** A 57 mm touch-sensitive volume slider provides precise, fingertip audio control with instant backlit feedback. Slide your finger along the bar to adjust volume.



Figure 4: The left side of the keyboard highlighting the backlit media and application controls.

Bluetooth Wireless Technology

The keyboard utilizes Bluetooth Wireless Technology version 2.0, ensuring a seamless and secure connection from up to 30 feet (approximately 9 meters). It supports Widcomm 5.1 Bluetooth stack for reliable performance.

Maintenance

Cleaning the Keyboard

To maintain the sleek appearance and functionality of your diNovo Edge Keyboard:

- Use a soft, lint-free cloth for cleaning.
- For stubborn smudges, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, abrasive pads, or excessive moisture, as these can damage the Plexiglas and aluminum surfaces.
- Ensure the keyboard is powered off and disconnected from the charging base before cleaning.

Battery Care

The keyboard features a built-in rechargeable 950 mA lithium-ion battery. To maximize battery life:

- Regularly place the keyboard on its charging base when not in use, especially overnight.
- Avoid completely draining the battery frequently.
- Store the keyboard in a cool, dry place if not used for extended periods.

Troubleshooting

If you encounter issues with your Logitech diNovo Edge Keyboard, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Keyboard not responding	Keyboard is off; Low battery; USB mini-receiver not connected; Bluetooth interference.	Ensure keyboard is powered on. Charge the keyboard. Verify USB mini-receiver is securely plugged in. Move closer to the receiver or remove other Bluetooth devices.
TouchDisc not working correctly	TouchDisc disabled; Software issue; Dirty surface.	Press **FN + Left Click** to re-enable. Reinstall Logitech SetPoint software. Clean the TouchDisc surface.
Backlit controls not lighting up	Low battery; Software issue.	Charge the keyboard fully. Ensure Logitech SetPoint software is installed and running.
Poor Bluetooth connection / Lag	Distance from receiver; Interference from other devices; Obstructions.	Reduce distance between keyboard and receiver (max 30 feet). Remove potential sources of interference (e.g., Wi-Fi routers, cordless phones). Ensure clear line of sight.

For more detailed troubleshooting or persistent issues, refer to the Help Center within the Logitech SetPoint software or visit the Logitech support website.

Specifications

General

- **Model:** 967685-0403
- **Color:** Black
- **Material:** Plexiglas panel with brushed aluminum palm rest
- **Style:** Modern
- **Keyboard Description:** QWERTY
- **Number of Keys:** 78
- **Special Feature:** Backlit, Rechargeable

Keyboard Details

- **Key Size:** Full-sized standard 18 x 18 mm
- **Key Travel:** 3.2 mm
- **Activation Force:** 60g
- **Keystroke Lifespan:** 10 million keystrokes per key
- **Switch Technology:** Scissor switch

Enhanced Controls

- **Touchpad:** 38 mm circular TouchDisc
- **Scrolling:** Horizontal and vertical scrolling, acceleration settings from None to 10x speed
- **One-Touch Controls:** 17 with instant backlit feedback
- **Volume Control:** 57 mm touch-sensitive slider with instant backlit feedback

Connectivity

- **Technology:** Bluetooth Wireless Technology, version 2.0
- **Range:** Up to 30 feet (approx. 9 meters)
- **Bluetooth Stack Support:** Widcomm 5.1

Power and Battery

- **Battery Type:** Built-in rechargeable 950 mA lithium-ion battery
- **Fast-Charge Time:** Approx. 5 minutes for one day usage
- **Full-Charge Time:** Approx. 2 hours for up to 2 months usage

Physical Dimensions

- **Dimensions (H x W x D):** 11 mm x 410 mm x 210 mm (0.43 x 16.14 x 8.27 inches)
- **Weight:** 940 grams (2.07 pounds)



Figure 5: The ultra-slim profile of the diNovo Edge Keyboard.

Warranty and Support

Warranty Information

Your Logitech diNovo Edge Keyboard comes with a**3-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
Legal Disclaimer: All items bought are final sale and cannot be returned. Items are promised to work properly on arrival. We only sell working goods.

Customer Support

For technical assistance, warranty claims, or additional information, please refer to the following resources:

- **Logitech SetPoint Software:** The installed software includes a comprehensive Help Center.
- **Online Support:** Visit the official Logitech support website for FAQs, drivers, and contact information.

© 2024 Logitech. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question