Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Warner Home Video B000KJT674

User Manual: A Christmas Story Blu-ray Disc

Model: B000KJT674

Introduction

This manual provides essential information for the proper use and care of your *A Christmas Story* Blu-ray Disc. Please read these instructions carefully to ensure an optimal viewing experience.



This image displays the front cover of the A Christmas Story Blu-ray Disc. The main visual features a young boy, Ralphie Parker, wearing glasses, with a collage of other movie scenes in the background, including him in a pink bunny suit, his friends, and Santa Claus. The title 'A Christmas Story' is prominently displayed with a Christmas wreath.

Setup

To enjoy your Blu-ray Disc, ensure you have the following equipment:

- A Blu-ray Disc player compatible with Blu-ray format.
- A television or display device with appropriate input connections.
- Necessary audio/video cables (e.g., HDMI cable).

Installation Steps:

1. Connect your Blu-ray Disc player to your television using an HDMI cable for optimal picture and sound quality. Refer to your player's manual for specific connection instructions.
2. Power on your television and Blu-ray Disc player.
3. Select the correct input source on your television that corresponds to your Blu-ray Disc player.

Operating Instructions

Playing the Disc:

1. Gently hold the Blu-ray Disc by its edges to avoid touching the playback surface.
2. Open the disc tray of your Blu-ray player.
3. Place the disc into the tray with the label side facing up.
4. Close the disc tray. The player should automatically load the disc and display the main menu or begin playback.
5. Use your player's remote control to navigate the disc menu. Options typically include 'Play Movie', 'Scene Selection', 'Audio Settings', and 'Subtitles'.

Audio and Subtitle Selection:

This Blu-ray Disc supports multiple audio and subtitle options:

- **Audio:** English (Original), French (Dubbed), Spanish (Dubbed)
- **Subtitles:** English, French, Spanish

These options can usually be selected from the disc's main menu or via the 'Audio' and 'Subtitle' buttons on your Blu-ray player's remote control during playback.

Maintenance

Proper care of your Blu-ray Disc will ensure its longevity and consistent performance.

Disc Handling:

- Always hold the disc by its outer edges or by inserting a finger into the center hole.
- Avoid touching the shiny playback surface to prevent fingerprints and scratches.

Cleaning:

- If the disc becomes dirty, gently wipe it with a soft, lint-free cloth.
- Wipe from the center of the disc outwards in a straight line, not in a circular motion.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the disc surface.

Storage:

- Store the disc in its original Blu-ray case when not in use to protect it from dust, scratches, and direct sunlight.
- Keep discs in a cool, dry place away from extreme temperatures and humidity.

Troubleshooting

If you encounter issues with your Blu-ray Disc, refer to the following common solutions:

Problem	Possible Cause	Solution
Disc does not play or load.	Disc is dirty or scratched; player is not compatible; incorrect input selected.	Clean the disc. Ensure your player is a Blu-ray player. Verify the correct TV input.
No audio or video.	Cables are loose; incorrect audio/video settings on player or TV.	Check all cable connections. Adjust audio/video output settings on your player and TV.
Disc skips or freezes during playback.	Disc is dirty or damaged; player lens is dirty.	Clean the disc. If the problem persists, try the disc in another player to rule out disc damage. Clean your player's lens if possible (refer to player manual).
Cannot select desired language or subtitles.	Incorrect menu navigation; player settings override disc settings.	Access the disc's menu for language/subtitle options. Check your player's default audio/subtitle settings.

Specifications

Key technical details for the *A Christmas Story* Blu-ray Disc:

Feature	Detail
Title	A Christmas Story
Format	Blu-ray
ASIN	B000KJT674
Studio	Warner Home Video
Release Date	December 5, 2006
Run Time	1 hour and 33 minutes
Aspect Ratio	1.85:1
MPAA Rating	PG (Parental Guidance Suggested)
Media Format	Closed-captioned, Color, Dolby, Dubbed, Subtitled, Widescreen
Language	English
Dubbed Languages	French, Spanish
Subtitle Languages	English, French, Spanish
Number of Discs	1
Product Dimensions	6.5 x 5.25 x 0.5 inches; 1.6 ounces

Feature	Detail
Genre	Kids & Family

Warranty and Support

This Blu-ray Disc is produced by Warner Home Video. For information regarding product defects or playback issues not resolved by troubleshooting, please refer to the warranty information provided by the retailer at the time of purchase or contact Warner Home Video customer support directly.
Please retain your proof of purchase for any warranty claims.

© 2024 Warner Home Video. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000KJT674

More documents and user manuals: **https://manuals.plus/**