Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cardinal 375

Cardinal Automatic Card Shuffler User Manual

Model: 375

1. Introduction

Thank you for purchasing the Cardinal Automatic Card Shuffler. This device is designed to efficiently shuffle one or two decks of standard playing cards, providing a fair and random shuffle for your card games. Please read this manual carefully before using the shuffler to ensure proper operation and longevity of the product.

2. Safety Information

- Keep the device away from water or other liquids to prevent electric shock or damage.
- Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.
- Keep fingers, hair, and loose clothing away from moving parts during operation.
- Use only the specified battery type (4 x AA 1.5V batteries).
- Remove batteries if the device will not be used for an extended period.
- This product is not a toy. Keep out of reach of small children.

3. Package Contents

Please check the package for the following items:

- 1 x Cardinal Automatic Card Shuffler
- Instruction Manual (this document)

Note: Playing cards and batteries are not included.

4. Setup

4.1 Battery Installation

1. Locate the battery compartment on the bottom of the shuffler.
2. Slide open the battery compartment cover.
3. Insert 4 new AA (1.5V) batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.

4. Close the battery compartment cover securely.



Figure 1: This image displays the side of the product box for the Cardinal Automatic Card Shuffler. It illustrates the shuffler in operation, handling two decks of cards. Key features such as 'Shuffles 1 or 2 Card Decks Completely' and the requirement for 'X4 1.5V AA/R6 Batteries' are visible. The UPC barcode 047754375008 is also present.

4.2 Placement

Place the card shuffler on a flat, stable surface before use.

5. Operating Instructions

5.1 Loading Cards

1. Ensure the shuffler is placed on a stable surface.
2. Divide your deck(s) of cards into two roughly equal halves.
3. Place one half of the cards into the left card tray and the other half into the right card tray. Ensure the cards are neatly stacked and fully seated in the trays.



Figure 2: This image shows two standard decks of 'Classic Games Playing Cards' in their packaging. The fanned cards on the box indicate the type of playing cards compatible with the shuffler. Please note that playing cards are not included with the shuffler.

5.2 Shuffling Process

1. Once cards are loaded into both trays, press the lever located at the front of the shuffler.
2. The motors will activate, drawing cards from both trays and mixing them into the central collection tray.
3. Continue holding the lever until all cards have been drawn from the side trays and shuffled into the center.

5.3 Removing Shuffled Cards

Once shuffling is complete, release the lever and carefully remove the shuffled deck(s) from the central collection tray.

6. Maintenance

6.1 Cleaning

- Wipe the exterior of the shuffler with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure no dust or debris accumulates in the card pathways. Use a soft brush or compressed air if necessary, with the device turned off and batteries removed.

6.2 Battery Replacement

Replace batteries when the shuffling speed decreases or the device stops functioning. Refer to Section 4.1 for battery installation instructions.

6.3 Storage

Store the shuffler in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if storing for extended periods.

7. Troubleshooting

Problem	Possible Cause	Solution
Shuffler does not turn on or operate.	Batteries are dead or incorrectly installed.	Check battery polarity or replace with new batteries.
Cards jam during shuffling.	Cards are old, bent, or sticky; too many cards loaded; foreign object in mechanism.	Use new, clean cards. Reduce the number of cards. Inspect card pathways for obstructions.
Shuffling is slow or inconsistent.	Low battery power.	Replace batteries.
Cards are not fully shuffled.	Not enough time allowed for shuffling; cards not properly loaded.	Hold the shuffle lever until all cards are processed. Ensure cards are neatly stacked in trays.

8. Specifications

- **Model:** 375
- **Brand:** Cardinal
- **Capacity:** 1 or 2 standard decks of playing cards
- **Power:** 4 x AA 1.5V batteries (not included)
- **Material:** Plastic
- **Dimensions:** Approximately 8.7 x 4.7 x 3.9 inches (22.1 x 11.9 x 9.9 cm)
- **Weight:** Approximately 12 ounces (340 grams) without batteries

9. Warranty Information

This product is covered by a limited warranty against manufacturing defects. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the packaging or contact Cardinal customer support.

10. Customer Support

If you have any questions, require assistance, or encounter issues not covered in this manual, please contact Cardinal customer support. Visit the official Cardinal website for contact details or refer to the product packaging.
Website: Cardinal Games Store on Amazon

© 2024 Cardinal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000LG25EW

More documents and user manuals: **https://manuals.plus/**