Kaito KA503

Kaito KA503 Emergency Wind-up 5-LED Flashlight with AM/FM Radio User Manual

Model: KA503

Introduction

The Kaito KA503 is a versatile emergency device combining a 5-LED flashlight with an AM/FM radio. Designed for reliability in various situations, it features a hand-crank power source, making it ideal for camping, outdoor activities, or emergency preparedness. This manual provides instructions for the proper setup, operation, and maintenance of your KA503 unit.

Product Features

- **5-LED Flashlight:** Equipped with five super bright LEDs, each rated at 15,000 MCD, for reliable illumination.
- **AM/FM Radio:** Integrated radio tuner for receiving AM and FM broadcasts.
- **Hand-Crank Power Generation:** Manual winding mechanism for self-sufficient power. One minute of cranking provides approximately 10 minutes of flashlight operation.
- **Durable Construction:** Made from high-impact plastic for rugged use.
- **Built-in Speaker:** For clear audio output from the radio.
- **Telescoping FM Antenna:** Improves radio reception.
- **USB In / DC In (4.5-6V):** External charging option.
- **Charge Out Port:** Allows for charging of other small electronic devices.

Setup

1. **Unpacking:** Carefully remove the Kaito KA503 from its packaging. Inspect the unit for any visible damage.
2. **Initial Power:** Before first use, it is recommended to hand-crank the device for 1-2 minutes to ensure a basic charge. Alternatively, connect a compatible 4.5-6V DC power adapter or USB cable to the "USB IN / DC IN" port for initial charging.

Operating Instructions

Powering the Device

The Kaito KA503 can be powered via its integrated hand-crank generator or an external power source.

- **Hand-Crank Operation:** Extend the hand-crank handle located on the side of the unit. Rotate the handle clockwise or counter-clockwise at a steady pace. Approximately one minute of continuous cranking will provide power for about 10 minutes of flashlight use.
- **External Power (USB/DC In):** Connect a compatible USB cable or DC power adapter (4.5-6V) to the "USB IN / DC IN" port on the back of the unit. This will charge the internal battery.

Flashlight Operation

1. Locate the flashlight power switch, typically on the top or side of the unit.
2. Slide the switch to the "ON" position to activate the 5-LED flashlight.
3. Slide the switch to the "OFF" position to turn off the flashlight.



Figure 1: Side view of the Kaito KA503, showing the extended hand crank and the flashlight lens.

Radio Operation

1. Extend the telescoping FM antenna for optimal reception.
2. Locate the radio power/volume knob and turn it clockwise to power on the radio and adjust the volume.
3. Use the tuning knob to select your desired AM or FM station.
4. To turn off the radio, rotate the power/volume knob counter-clockwise until it clicks off.

Charging External Devices

The KA503 features a "CHARGE OUT" port, allowing you to provide emergency power to small electronic devices.

1. Locate the "CHARGE OUT" port on the back of the unit.
2. Connect your device's charging cable to this port.
3. Begin hand-cranking the KA503 to generate power for your external device. Note that the charging output may be limited and is intended for emergency use.



Figure 2: Rear view of the Kaito KA503, highlighting the "CHARGE OUT" and "USB IN / DC IN" ports.

Maintenance

- **Cleaning:** Wipe the unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Storage:** Store the KA503 in a cool, dry place away from direct sunlight and extreme temperatures. For long-term storage, periodically hand-crank the unit for a few minutes to maintain the internal battery's health.
- **Antenna Care:** Handle the telescoping antenna gently to prevent bending or breakage.

Troubleshooting

Problem	Possible Cause	Solution
Flashlight or Radio does not turn on.	Low or depleted internal battery.	Hand-crank the unit for at least 1-2 minutes, or connect to an external power source via the USB/DC IN port.
Poor radio reception.	Antenna not extended, weak signal, or interference.	Fully extend the telescoping FM antenna. Try repositioning the unit. Tune slowly to find a clearer signal.
Hand-crank feels loose or detached.	Wear and tear or improper handling.	Ensure the crank is securely attached. If it detaches frequently, contact customer support.
External device not charging.	Insufficient power generation or incompatible device.	Ensure continuous and steady hand-cranking. Verify your device is compatible with the output specifications of the KA503.

Specifications

- **Brand:** Kaito
- **Model Number:** KA503
- **Special Feature:** Built-In Flashlight
- **Tuner Technology:** AM, FM

- **Power Source:** Manual (Hand-Crank), USB In / DC In (4.5-6V)
- **Radio Bands Supported:** AM, FM
- **Item Weight:** Approximately 12 ounces
- **Display Type:** LED (for flashlight)
- **Water Resistance Level:** Not Water Resistant

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Kaito website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2026 Kaito. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question