Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ricoh 1834544

Ricoh Type 245 (HY) Toner Cartridge User Manual

Model: 1834544

Brand: Ricoh

Product Overview

This manual provides instructions for the Ricoh Type 245 (HY) Black Toner Cartridge, model 1834544. This high-yield toner cartridge is designed for Ricoh CL4000DN printers and offers an estimated page yield of 15,000 pages.

Key Features:

- **High Yield:** Approximately 15,000 pages.
- **Color:** Black.
- **Compatibility:** Ricoh CL4000DN printers.
- Genuine Ricoh product.

Installation Guide

Unpacking the Cartridge

Carefully remove the toner cartridge from its packaging. Avoid touching the drum or electrical contacts.



Image description: A rectangular cardboard box for the Ricoh Color LP Toner Cartridge Type 245 HY. The box is primarily yellow-brown with black and red text. It displays "RICOH COLOR LP TONER CARTRIDGE TYPE 245 HY", "Color: BLACK", "Net Weight: 360g", "EDP CODE 888312", and "PRINTED WITH SOY INK". The bottom left corner shows small diagrams illustrating the installation process.

Installing the Toner Cartridge

1. Ensure your printer is powered off before beginning the installation.

2. Open the front cover or access panel of your Ricoh printer to expose the toner cartridge slots. Refer to your printer's specific user manual for exact instructions on accessing the toner compartment.
3. Gently remove the old toner cartridge by pulling it straight out.
4. Take the new Ricoh Type 245 (HY) toner cartridge and gently shake it horizontally 5-6 times to distribute the toner evenly inside.
5. Remove any protective covers or seals from the new cartridge as indicated on the packaging or the cartridge itself.
6. Align the new cartridge with the corresponding slot in the printer and slide it in until it clicks firmly into place. Do not force the cartridge.
7. Close the printer's front cover or access panel.
8. Power on your printer. The printer will typically perform a self-test and recognize the new cartridge.

Usage

Once the Ricoh Type 245 (HY) toner cartridge is correctly installed, your printer is ready for operation. The printer will automatically detect the new cartridge and adjust its settings.

Printing

Initiate print jobs from your computer or device as usual. The printer will utilize the newly installed toner for printing.

Monitoring Toner Levels

You can monitor the remaining toner level through your printer's control panel or the printer software installed on your computer. This allows you to anticipate when a replacement cartridge will be needed.

Care and Storage

Storage

Store unused toner cartridges in their original sealed packaging in a cool, dry place, away from direct sunlight and extreme temperatures.

Handling

Handle the toner cartridge carefully. Avoid dropping it or exposing it to excessive vibrations. Do not touch the green drum surface, as oils from your skin can affect print quality.

Disposal

Dispose of empty toner cartridges responsibly according to local environmental regulations. Many manufacturers and retailers offer recycling programs for used cartridges.

Common Issues

Cartridge Not Recognized

- Ensure the cartridge is fully seated in its slot. Remove and reinsert it firmly.
- Check for any protective seals or tabs that may not have been removed from the cartridge.
- Restart the printer.
- Verify that you have installed the correct cartridge model for your printer.

Poor Print Quality (Faded, Streaky, or Missing Prints)

- The toner level may be low. Check the toner level indicator.
- Gently shake the cartridge horizontally to redistribute any remaining toner.

- Perform a print head cleaning or calibration cycle through your printer's utility software (if applicable for laser printers).
- Ensure the paper type and quality are appropriate for your printer.

Toner Leaks

- If you notice toner leaks, carefully remove the cartridge.
- Inspect the cartridge for damage. If damaged, replace it.
- Clean any spilled toner inside the printer using a dry, lint-free cloth or a toner-specific vacuum cleaner. Do not use a regular vacuum cleaner.

Product Specifications

Feature	Detail
Brand	Ricoh
Model Number	1834544
Item Model Number	1834544
Color	Black
Page Yield	15,000 pages
Item Weight	15.6 ounces (442 Grams)
Product Dimensions	16.54 x 3.54 x 3.54 inches
Compatible Devices	Printer (specifically Ricoh CL4000DN)
Included Components	Toner Cartridge
Special Feature	High Yield
Manufacturer	Ricoh
ASIN	B000M18UMW



Image description: A black and white graphic displaying the "CE" conformity mark, indicating that the product complies with European health, safety, and environmental protection standards.

Warranty and Customer Support

Warranty Information

This Ricoh toner cartridge is covered by Ricoh's standard warranty. For specific warranty terms and conditions, please refer to the documentation provided with your printer or visit the official Ricoh website.

Customer Support

For technical assistance, troubleshooting, or inquiries regarding your Ricoh toner cartridge, please contact Ricoh customer support.

You can find contact information on the official Ricoh website or through your product's original documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000M18UMW

More documents and user manuals: **https://manuals.plus/**