Palmer 1000

C. Palmer Pizzelle Iron Model 1000 Instruction Manual

Brand: Palmer | Model: 1000

Introduction

The C. Palmer Pizzelle Iron Model 1000 is an electric appliance designed for baking traditional 5-inch pizzelles. This unit features two 400-watt heating elements for even cooking and produces two pizzelles simultaneously. Crafted from durable cast aluminum, it is manufactured in the USA, ensuring quality and reliability for years of use.



Image: The C. Palmer Pizzelle Iron Model 1000, showcasing its design and the delicate pizzelles it produces.

Safety Information

- Always ensure the appliance is unplugged when not in use or during cleaning.
- Do not immerse the pizzelle iron in water or any other liquid.
- Keep hands and utensils away from hot surfaces during operation to prevent burns.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- The unit does not have an on/off switch; operation is controlled by plugging and unplugging the unit.
- The handle is insulated to protect against heat, but caution should always be exercised.

Setup

1. **Unpacking:** Carefully remove the pizzelle iron from its packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wipe the baking plates with a damp cloth and dry thoroughly.
3. **Preheating:** Plug the pizzelle iron into a 120-volt wall outlet. Allow the iron to preheat for at least 15 minutes. This ensures optimal temperature for baking and helps prevent sticking.
4. **Initial Greasing:** After preheating, thoroughly and lightly brush the baking plates with salad oil or shortening. This initial greasing is crucial for the first few batches. Excess oil may drip, which is

normal.



Image: The pizzelle iron open, highlighting its design and ease of use.

Operating Instructions

1. **Prepare Batter:** Use your preferred pizzelle recipe. The consistency of the batter is key for well-formed pizzelles.
2. **Add Batter:** Place approximately two tablespoons of batter onto the center of each pizzelle mold. Avoid overfilling to prevent overflow.
3. **Close and Lock:** Gently close the lid and secure the handle with the locking clip. Apply firm, even pressure to ensure the batter spreads evenly and creates crisp pizzelles.
4. **Bake:** Bake for approximately 30-60 seconds, or until golden brown. Baking time may vary based on desired crispness and color. There is no 'doneness' indicator light; visual inspection is recommended.
5. **Remove Pizzelles:** Once baked, carefully open the iron. Use a thin, non-abrasive utensil (like a plastic spatula or a fork) to gently lift the pizzelles from the plates.
6. **Cool:** Place hot pizzelles on a wire rack to cool. They will harden and become crisp as they cool. For soft pizzelles, lay them on a flat surface. For crisp pizzelles, allow them to cool on a rack.
7. **Repeat:** Repeat the process with the remaining batter. After the initial batches, additional greasing is

usually not required due to the seasoned plates.



Image: Pouring batter into the pizzelle iron molds.

Video: Demonstration of using the Palmer Pizzelle Maker to create pizzelles.

Cleaning and Maintenance

1. **Cool Down:** Allow the pizzelle iron to cool completely before cleaning.
2. **Wipe Plates:** Use a damp cloth or paper towel to wipe down the non-stick baking plates. A small cleaning tool (often included) can be used to remove any batter residue from the intricate patterns.
3. **Stubborn Residue:** If batter sticks, do not scrape with metal utensils. Instead, grease the plates again and bake a small amount of fresh batter or a piece of bread. The fresh batter/bread will often adhere to the stuck residue, allowing for easier removal.
4. **Exterior:** Wipe the exterior with a damp cloth.
5. **Storage:** Store the pizzelle iron in a dry place. It is recommended to place a paper towel between the plates to absorb any residual oil and protect the non-stick surface. The compact design allows for easy storage.



Image: Visual guide for quick and easy pizzelle making, emphasizing the simple process.

Troubleshooting

Issue	Cause	Solution
Pizzelles stick to plates.	Insufficient preheating or improper initial greasing.	Ensure iron preheats for at least 15 minutes. Thoroughly grease plates before first use and for the first few batches.
Pizzelles are not crisp.	Not baked long enough or batter consistency.	Increase baking time slightly. Adjust batter consistency if too thick or thin. Cool on a wire rack for maximum crispness.
Batter overflows.	Too much batter added.	Reduce the amount of batter per pizzelle mold (approx. 2 tablespoons is recommended).
Unit has no on/off switch.	Standard design for this model.	Operate by plugging into and unplugging from the wall outlet.
Scratches on exterior.	Normal manufacturing process for cast aluminum.	This is cosmetic and does not affect performance.

Specifications

- **Model:** 1000
- **Brand:** Palmer
- **Wattage:** 800 Watts (2 x 400-watt heating elements)
- **Voltage:** 120 Volts
- **Material:** Cast Aluminum, Iron

- **Pizzelle Size:** 5-inch diameter, 0.27-inch thickness
- **Product Dimensions:** 18"D x 11"W x 4"H
- **Item Weight:** 6 Pounds
- **Special Features:** Lightweight, Made in America, Preset Thermostat, Insulated Handle
- **Included Components:** Pizzelle Iron



Image: Detailed view of pizzelle dimensions and electrical specifications.

Warranty and Support

The C. Palmer Pizzelle Iron Model 1000 comes with a limited warranty, including a 5-year warranty on electrical parts. For support or warranty claims, please refer to the contact information provided in your product packaging or visit the official Palmer Manufacturing website.

Video: A user demonstrating the ease of making and cleaning the pizzelle iron.

© C. Palmer Manufacturing. All rights reserved.