Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eton NELITEEXECUTIVE

Eton Elite Executive Radio Instruction Manual

Model: NELITEEXECUTIVE | Brand: Eton

Product Overview

The Eton Elite Executive radio is a versatile portable receiver designed for comprehensive listening. It receives AM, FM, Longwave, and Shortwave (SW) frequencies, including the Aircraft Band and Single Sideband (SSB) for advanced users. Its PLL synthesized digital dual conversion ensures unmatched tuning accuracy, while a synchronous tuning circuit reduces distortion and fading for crystal-clear audio.

Key features include 700 programmable stations, selectable bandwidth filters, a digital clock with an alarm and sleep timer, and a rich orange LCD display. The radio is designed for portability, coming with a vegan leather case that also serves as a stand, and offers flexible power options via an included AC adapter or AA alkaline batteries (not included).



Image: The Eton Elite Executive radio shown with its protective brown vegan leather case.

Setup

What's in the Box

- Owner's Manual

Initial Setup

1. **Power Source:** The radio can be powered by the included AC adapter or 4 AA alkaline batteries (not included). For portable use, insert batteries into the compartment on the back of the unit, ensuring correct polarity. For continuous use, connect the AC adapter to the DC IN jack on the side of the radio and plug it into a standard 110V outlet.

2. **Antenna:** Extend the telescopic antenna located on the back of the unit for optimal reception, especially for FM and Shortwave bands. For enhanced Shortwave reception, an external antenna can be connected to the dedicated port on the side of the radio.

3. **Protective Case:** Place the radio into its vegan leather case. The case is designed to protect the radio and can also be folded to act as a stand for convenient viewing and operation.



Image: The compact size of the Eton Elite Executive radio, measuring only 4.1 inches in height.

Operating Instructions

Powering On/Off

Press the **POWER** button located on the top right of the radio to turn it on or off. The display will illuminate upon power-on.

Tuning and Band Selection

- **Band Selection:** Use the dedicated buttons (FM, AM, LW/MW BAND, METER BAND, FM/AIR BAND) to select your desired frequency band.
- **Tuning:** The radio supports precise digital manual tuning using the tuning knob, automatic scanning with the **AUTO** buttons, or direct frequency entry via the keypad.
- **SSB (Single Sideband):** For amateur radio, maritime, aeronautical, and military signals, activate the SSB mode. Use the fine-tuning control for precise adjustment.

- **Bandwidth Filters:** Selectable bandwidth filters help reduce interference and improve audio clarity for different signal conditions.
- **Memory Stations:** Store up to 700 of your favorite stations for quick access. Refer to the owner's manual for detailed instructions on programming and recalling stations.

Display and Controls

The rich orange LCD display provides clear information on frequency, time, and selected modes. The digital clock features an alarm and sleep timer for personalized listening. Use the **RESET/LOCK** button to reset the radio or lock the controls to prevent accidental changes.

Audio Features

Adjust the electronic volume, treble, and bass controls to customize your listening experience. The radio supports FM stereo/mono selection for optimal audio output. Line in/out jacks allow connection to external audio devices or speakers.

Your browser does not support the video tag.

Video: An official product video showcasing the Eton Elite Executive AM/FM Shortwave Radio and its features.



Image: A close-up of the Eton Elite Executive radio's front panel, highlighting its intuitive controls and clear display.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the radio's exterior. Avoid abrasive cleaners or solvents.
- **Battery Care:** If the radio will not be used for an extended period, remove the AA batteries to prevent leakage and damage.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures. Use the provided vegan leather case for protection during storage and travel.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Batteries are dead or incorrectly inserted; AC adapter not connected properly.	Replace batteries or ensure correct polarity. Check AC adapter connection and power outlet.
Poor Reception	Antenna not fully extended; weak signal; interference.	Fully extend the telescopic antenna. Try repositioning the radio. Connect an external antenna for better reception. Adjust bandwidth filters.
Display Not Working/Partial Display	Internal display issue; low battery.	Ensure batteries are fully charged or use AC adapter. If problem persists, consult the user manual or support.
Controls Unresponsive	Controls are locked; temporary software glitch.	Press the LOCK button to unlock controls. Try resetting the radio (refer to manual for reset procedure).

Specifications

Feature	Detail
Product Dimensions	6.6"L x 1.2"W x 4.1"H
Item Weight	15.5 ounces
Model Number	NELITEEXECUTIVE
Connectivity Technology	Bluetooth
Power Source	Battery Powered
Radio Bands Supported	AM, FM, Longwave, Shortwave, Aircraft Band, SSB

Feature	Detail
Special Feature	Portable
Included Components	Owner's Manual

Warranty and Support

For detailed warranty information and support, please refer to the official Eton website or the included Owner's Manual. You can download the User Manual in PDF format here: Eton Elite Executive User Manual (PDF).

Protection plans are available for purchase separately to extend coverage beyond the standard manufacturer's warranty. Please check with your retailer for available options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question