Nespresso 3190US

Nespresso Aeroccino Automatic Milk Frother User Manual

Model: 3190US

Introduction

Welcome to the Nespresso Aeroccino Automatic Milk Frother user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. The Aeroccino is designed to create light and creamy milk froth for your coffee beverages or to heat milk for lattes and other drinks.



Image: The Nespresso Aeroccino Automatic Milk Frother, a sleek, chrome-colored cylindrical device with a black handle and base, featuring a control button on the front and a clear lid.

Important Safety Instructions

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the base or power cord in water or other liquids.
- Ensure the voltage rating on the appliance matches your local power supply.
- Keep out of reach of children.
- Do not operate with a damaged cord or plug.
- Unplug from outlet when not in use and before cleaning.
- Use only with cold, fresh milk.
- Do not fill above the maximum level indicator inside the frother.
- The frother becomes hot during operation; handle with care.

Package Contents

Upon opening the box, please ensure all the following components are present:

- Nespresso Aeroccino Milk Frother Unit
- Power Base and Cable
- Stirring Whisk (for heating milk)
- Frothing Whisk (for frothing milk)
- User Manual (this document)

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, clean the inside of the frother jug and the whisks with warm water and a mild detergent. Rinse thoroughly and dry. Do not immerse the power base in water.
3. **Place:** Place the power base on a clean, dry, and stable surface.
4. **Connect:** Plug the power cable into a suitable electrical outlet.
5. **Insert Whisk:** Choose the desired whisk (stirring for hot milk, frothing for frothed milk) and place it onto the pin at the bottom of the frother jug. The frothing whisk has a small spring.

Operating Instructions

For Hot Milk Froth:

1. Ensure the frothing whisk (with spring) is inserted into the jug.
2. Pour cold, fresh milk into the frother jug, ensuring it does not exceed the upper "Max Froth" level indicator.
3. Place the lid on the frother.
4. Place the frother jug onto the power base.
5. Press the button once. The button will illuminate red. The frother will automatically stop when the milk is frothed and heated (approximately 50 seconds).

For Cold Milk Froth:

1. Ensure the frothing whisk (with spring) is inserted into the jug.
2. Pour cold, fresh milk into the frother jug, ensuring it does not exceed the upper "Max Froth" level indicator.
3. Place the lid on the frother.
4. Place the frother jug onto the power base.
5. Press and hold the button for approximately 2 seconds until the button illuminates blue. The frother will automatically stop when the milk is frothed (approximately 60 seconds).

For Hot Milk (No Froth):

1. Remove the frothing whisk and insert the stirring whisk (without spring) into the jug.
2. Pour cold, fresh milk into the frother jug, ensuring it does not exceed the lower "Max Milk" level indicator.
3. Place the lid on the frother.
4. Place the frother jug onto the power base.

5. Press the button once. The button will illuminate red. The frother will automatically stop when the milk is heated.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your Aeroccino.

- **After Each Use:** Immediately after each use, rinse the inside of the frother jug and the whisk with cold water. This prevents milk residue from drying and sticking.
- **Hand Wash Only:** The frother jug and whisks are **hand wash only**. Do not place them in a dishwasher. Use a soft sponge or cloth and mild detergent. Avoid abrasive materials that could scratch the non-stick coating.
- **Power Base:** Wipe the power base with a damp cloth. Never immerse the power base in water or any other liquid.
- **Drying:** Ensure all parts are completely dry before storing or next use.

Troubleshooting

Problem	Possible Cause	Solution
Frother does not start.	Not plugged in; poor contact with base; jug not properly placed.	Ensure power cord is securely plugged in. Check frother jug is correctly seated on the power base.
Milk not frothing or heating properly.	Incorrect whisk used; milk type/temperature; milk level too high/low; frother dirty.	Ensure correct whisk is inserted. Use cold, fresh, full-fat milk for best froth. Do not exceed max fill lines. Clean the frother thoroughly.
Burnt smell or residue.	Milk residue left inside; frother not cleaned properly.	Clean the frother immediately after each use. Ensure no milk residue remains on the heating element or inside the jug.

Specifications

Brand:	Nespresso
Model:	3190US Aeroccino
Special Feature:	Fully Automatic, Compact Design, Quiet Function, Versatile (can heat and froth milk)
Color:	Chrome
Material:	Stainless Steel
Item Weight:	2.7 pounds
Package Dimensions:	7.9 x 6.1 x 6 inches

Warranty and Support

Nespresso products are manufactured to the highest quality standards. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Nespresso website.
For technical assistance, troubleshooting not covered in this manual, or to order accessories, please contact Nespresso Customer Service.

Nespresso Official Website: www.nespresso.com
Nespresso Store on Amazon: Visit the Nespresso Store

© 2024 Nespresso. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question