De'Longhi ESAM 3200 S

DELONGHI Magnifica Bean-to-Cup Espresso Machine

Model: ESAM 3200 S | Brand: De'Longhi

1. Introduction

The De'Longhi Magnifica ESAM3200S is a versatile bean-to-cup espresso machine designed to deliver perfect coffee beverages with ease. It offers the flexibility to use either fresh coffee beans or pre-ground coffee, ensuring a perfect result in every cup. With intuitive controls, you can select your favorite drinks with a simple touch. The machine features automatic rinsing and descaling programs for convenient maintenance, and its removable brewing unit allows for easy cleaning, contributing to a longer lifespan.



Image 1.1: Front view of the De'Longhi Magnifica ESAM3200S espresso machine in silver grey metal finish. It features a control panel with rotary knobs and buttons, a coffee spout, and a drip tray.

2. Safety Information

Please read all safety instructions carefully before using the appliance. Keep this manual for future reference.

- Always connect the appliance to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Do not touch hot surfaces. Use handles or knobs.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been

damaged in any manner.
- Use only original spare parts and accessories.

3. Setup

3.1 Unpacking and Initial Cleaning

1. Remove all packaging materials from the machine.
2. Wipe the exterior of the machine with a damp cloth.
3. Wash the water tank, drip tray, and coffee grounds container with warm water and mild detergent. Rinse thoroughly.

3.2 Filling the Water Tank

- Remove the water tank from the back of the machine.
- Fill the tank with fresh, cold tap water up to the MAX level indicator.
- Replace the water tank securely in the machine.

3.3 Filling the Bean Hopper

- Open the lid of the bean hopper located on top of the machine.
- Pour fresh coffee beans into the hopper. Do not overfill.
- Close the lid firmly.

3.4 First Use Priming

Before first use, or if the machine has not been used for a long time, it needs to be primed:

1. Ensure the water tank is filled.
2. Place a container under the steam wand.
3. Turn the steam knob to the steam position to dispense water until a continuous flow is achieved.
4. Close the steam knob. The machine is now primed.

4. Operating Instructions

4.1 Making Espresso with Coffee Beans

1. Turn on the machine using the power button. Wait for the indicator lights to stabilize.
2. Place one or two cups under the coffee spouts.
3. Adjust the coffee strength using the rotary knob (from minimum to maximum intensity).
4. Select the desired coffee volume using the other rotary knob (e.g., for espresso or double espresso).
5. Press the button for single or double espresso. The machine will grind the beans and brew the coffee.

4.2 Using Pre-Ground Coffee

- Only use one level scoop of pre-ground coffee per cup in the pre-ground coffee funnel.
- Do not add more than one scoop, as this may damage the machine.
- Follow steps 1, 2, 4 from 'Making Espresso with Coffee Beans', then add ground coffee to the dedicated funnel before pressing the brew button.

4.3 Frothing Milk with the Steam Wand

1. Fill a pitcher with cold milk (preferably semi-skimmed or skimmed).
2. Press the steam button and wait for the steam indicator light to illuminate steadily.
3. Immerse the steam wand into the milk, just below the surface.
4. Turn the steam knob to release steam. Move the pitcher up and down to create creamy foam.
5. Once desired foam is achieved, close the steam knob and clean the steam wand immediately with a damp cloth.

5. Maintenance

Regular cleaning and maintenance ensure optimal performance and longevity of your De'Longhi Magnifica.

5.1 Daily Cleaning

- Empty and rinse the drip tray and coffee grounds container daily.
- Wipe the coffee spouts and exterior of the machine with a soft, damp cloth.

5.2 Removable Brewing Unit

The brewing unit is removable for easy cleaning:

1. Turn off and unplug the machine.
2. Open the service door and remove the brewing unit by pressing the two red release buttons.
3. Rinse the brewing unit under running tap water until no coffee residue is visible.
4. Allow it to air dry completely before reinserting.

5.3 Descaling

The machine features automatic descaling programs. The descaling indicator light will illuminate when descaling is required. Follow the instructions provided in the machine's display or a separate descaling guide for the specific procedure. Use only De'Longhi descaling solution.

6. Troubleshooting

If you encounter issues with your machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Coffee is not hot enough	Cups are cold; machine not preheated	Preheat cups with hot water; allow machine to fully preheat.
No coffee dispenses	Water tank empty; brewing unit blocked	Fill water tank; clean brewing unit.
Machine is noisy	Air in the circuit; machine needs descaling	Prime the circuit by dispensing hot water; perform descaling.
Milk not frothing well	Steam wand blocked; milk not cold enough	Clean steam wand; use fresh, cold milk.

7. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	ESAM 3200 S
Color	Silver Grey Metal
Product Dimensions (L x W x H)	28.5 x 37.5 x 36 cm (approximate)
Water Tank Capacity	1.8 Liters
Power	1450 Watts
Voltage	230 Volts
Material	Stainless Steel
Item Weight	9.5 Kilograms
Energy Class	A
Automatic Shut-off	No

8. Warranty and Support

De'Longhi provides support for its products. Spare parts for the ESAM 3200 S model are available for up to 10 years from the date of manufacture.

For technical assistance, warranty claims, or to purchase spare parts, please contact De'Longhi customer service through their official website or the contact information provided with your purchase documentation. Always have your model number (ESAM 3200 S) and purchase date ready when contacting support.

© 2024 De'Longhi. All rights reserved.