Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bell+Howell 7649

Bell and Howell Sunlight Desk Lamp Model 7649 User Manual

Model: 7649 | Brand: Bell+Howell

Introduction

Thank you for choosing the Bell and Howell Sunlight Desk Lamp. This lamp is designed to provide balanced, full-spectrum lighting that simulates natural sunlight, enhancing visibility and reducing eye strain for various tasks such as reading, working, and hobbies. This manual provides essential information for the safe and efficient use of your lamp.

Safety Instructions

- Always unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Do not use the lamp near water or in excessively humid environments.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not attempt to modify or repair the lamp yourself. Contact qualified service personnel for assistance.
- Keep the lamp away from flammable materials.
- Use only the specified bulb type and wattage (27-watt fluorescent bulb).

Package Contents

- Bell and Howell Sunlight Desk Lamp (Base, Gooseneck, Lamp Head)
- 27-watt Full Spectrum Fluorescent Bulb
- User Manual

Setup

Follow these steps to assemble your Bell and Howell Sunlight Desk Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in "Package Contents" are present.
2. **Insert Bulb:** Gently insert the provided 27-watt fluorescent bulb into the lamp head socket. Ensure it is securely seated.



Image: Close-up of the lamp head showing the fluorescent bulb and the power switch.

3. **Attach Gooseneck to Base:** Securely attach the flexible gooseneck to the lamp base. Some models may require screwing the gooseneck into the base. Ensure the connection is firm.
4. **Position the Lamp:** Place the lamp on a stable, flat surface. The weighted base is designed for stability.



Image: Assembled Bell and Howell Sunlight Desk Lamp.

5. **Connect to Power:** Plug the power cord into a standard 120V AC electrical outlet.

Operating Instructions

1. **Power On/Off:** Locate the power switch on the lamp head (refer to the image in the Setup section). Flip the switch to the "ON" position to turn on the lamp, and to the "OFF" position to turn it off.
2. **Adjusting the Light:** The lamp features a flexible gooseneck. Gently bend and position the gooseneck to direct the light precisely where needed. The lamp head can also be angled for optimal illumination.
3. **Optimal Use:** For best results in reducing eye strain and enhancing color perception, position the lamp to illuminate your work area directly without creating glare on screens or reflective surfaces.

Maintenance

Cleaning

- Ensure the lamp is unplugged and cool before cleaning.
- Wipe the exterior surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.

Bulb Replacement

The lamp uses a 27-watt full-spectrum fluorescent bulb designed for long life (up to 5000 hours). When replacement is necessary:

1. **Unplug the Lamp:** Always disconnect the lamp from the power source before replacing the bulb.
2. **Allow to Cool:** If the lamp has been in use, allow the bulb to cool completely before handling.
3. **Remove Old Bulb:** Carefully remove the old fluorescent bulb from its socket.
4. **Insert New Bulb:** Insert a new 27-watt full-spectrum fluorescent bulb into the socket, ensuring it is firmly seated.
5. **Dispose Responsibly:** Dispose of old fluorescent bulbs according to local regulations, as they may contain small amounts of mercury.

Troubleshooting

Problem	Possible Cause	Solution
Lamp does not turn on.	• Power cord not plugged in. • Power switch is off. • Bulb is loose or faulty. • No power from outlet.	• Ensure power cord is securely plugged into a working outlet. • Flip the power switch to the "ON" position. • Check if the bulb is properly seated. Replace bulb if necessary. • Test the outlet with another device.
Light flickers.	• Bulb is loose or nearing end of life. • Unstable power supply.	• Ensure bulb is securely seated. Replace bulb if flickering persists. • Try plugging the lamp into a different outlet.
Lamp head is difficult to adjust.	• Gooseneck mechanism is stiff.	• Apply gentle, even pressure when adjusting. Avoid excessive force.

Specifications

Model Number	7649
Brand	Bell+Howell
Lamp Type	Desk Lamp
Bulb Type	27-watt Full Spectrum Fluorescent
Wattage	27 watts (equivalent to 150-watt incandescent)
Bulb Life	Up to 5000 hours

Color Temperature	6500K
Lumens	1300 Lumens
Color Rendering Index (CRI)	80-85
Input Voltage	120 volts AC
Product Dimensions	5"D x 5"W x 3"H (Base dimensions, overall height varies with gooseneck adjustment)
Weight	5.5 Pounds
Base Material	Metal
Finish Type	Clear
Shade Color	Grey



Image: Product dimensions diagram.

Warranty and Support

For information regarding product warranty, please refer to the documentation included with your purchase or contact Bell+Howell customer support.
Manufacturer: Bell and Howell
ASIN: B000RY1TQI
Item Model Number: 7649
Optional protection plans are available for purchase separately. These plans offer extended coverage beyond the standard manufacturer's warranty.

- 3-Year Protection Plan

- 4-Year Protection Plan
- Complete Protect (monthly plan covering multiple eligible purchases)

For further assistance or to inquire about protection plans, please visit theBell+Howell Store on Amazon or contact your retailer.

© 2023 Bell+Howell. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000RY1TQI

More documents and user manuals: **https://manuals.plus/**