Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WIK 9531MT

WIK 9531MT Express Cordless Kettle Instruction Manual

Model: 9531MT

1. Important Safety Instructions

Please read these instructions carefully before using your WIK 9531MT Express Cordless Kettle and retain them for future reference. Incorrect operation may cause damage to the appliance or injury to the user.

- Ensure the voltage indicated on the appliance corresponds with your mains voltage before connecting.
- Do not immerse the kettle, power base, cord, or plug in water or any other liquid.
- This appliance is intended for household use only. Do not use outdoors.
- Always place the kettle on a firm, flat, heat-resistant surface.
- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Keep the appliance and its cord out of reach of children.
- Do not fill above the maximum fill line or below the minimum fill line to prevent boiling dry or spillage.
- Always ensure the lid is securely closed before operating the kettle.
- Exercise caution when pouring hot water.
- Unplug the kettle from the outlet when not in use and before cleaning.

2. Product Overview

Familiarize yourself with the components of your WIK 9531MT Express Cordless Kettle.



An image showing the WIK 9531MT Express cordless kettle. It features a shiny stainless steel body, a white handle with a red power indicator light, and a white power base. The spout includes a filter.

1. **Kettle Body:** Stainless steel construction.
2. **Lid:** Removable or hinged lid for filling.
3. **Handle:** Ergonomically designed for comfortable pouring.
4. **Power Switch:** Located on the handle, activates heating.
5. **Indicator Light:** Illuminates when the kettle is heating.
6. **Water Level Indicator:** Shows the current water volume.
7. **Spout with Filter:** Prevents limescale particles from being poured into your cup.
8. **Cordless Power Base:** Allows the kettle to rotate 360 degrees and provides power.

3. Setup

Before first use, follow these steps:

1. Unpack the kettle and its power base. Remove all packaging materials.
2. Wipe the exterior of the kettle with a damp cloth. Do not use abrasive cleaners.
3. Fill the kettle with clean water to the maximum fill line.
4. Boil the water, then discard it. Repeat this process two to three times to remove any manufacturing residues.

5. Ensure the power cord is fully unwound and connected to a suitable power outlet.

4. Operating Instructions

1. **Filling the Kettle:** Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the minimum mark or above the maximum mark (1 liter). Close the lid securely.
2. **Placing on Power Base:** Place the kettle firmly onto its cordless power base.
3. **Switching On:** Press the power switch down. The indicator light will illuminate, signifying that the kettle is heating.
4. **Automatic Shut-Off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
5. **Pouring:** Carefully lift the kettle from its base and pour the hot water. Always hold the kettle by its handle.
6. **Re-boiling:** If the kettle has just boiled, allow a few moments for the internal thermostat to reset before attempting to re-boil.

5. Cleaning and Maintenance

Regular cleaning and maintenance will prolong the life of your kettle.

- **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely.
- **Exterior Cleaning:** Wipe the exterior surface with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can scratch the stainless steel finish.
- **Interior Cleaning:** The interior can be cleaned by rinsing with water. Do not use harsh chemicals.
- **Descaling:** Limescale buildup can affect performance. Descale your kettle regularly, especially in hard water areas.
  - Fill the kettle with a mixture of one part white vinegar and two parts water.
  - Boil the mixture and let it stand for at least 30 minutes, or longer for heavy scale.
  - Empty the kettle and rinse thoroughly with fresh water several times.
  - Alternatively, use a commercial descaling solution following the manufacturer's instructions.
- **Filter Cleaning:** The filter in the spout can be removed for cleaning. Rinse it under running water and brush gently if necessary. Ensure it is securely re-inserted before use.

6. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat.	Not plugged in; power switch not engaged; no power at outlet; kettle not properly seated on base.	Check power connection; press power switch down; check household fuse/circuit breaker; ensure kettle is correctly placed on base.
Kettle switches off before boiling.	Excessive limescale buildup; kettle boiled dry.	Descale the kettle; ensure kettle is filled above the minimum level.
Water tastes unusual.	New kettle residue; limescale buildup.	Perform initial cleaning and boiling cycles; descale the kettle.
Steam escaping from lid.	Lid not closed properly.	Ensure the lid is securely closed before boiling.

7. Specifications

- **Brand:** WIK
- **Model Number:** 9531MT
- **Type:** Cordless Electric Kettle

- **Capacity:** 1 Liter
- **Material:** Stainless Steel
- **Special Feature:** Cordless operation
- **Dimensions (Package):** 23.8 x 20.6 x 20.2 cm
- **Weight (Product):** 1.52 kg

8. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or contact WIK customer service. Keep your proof of purchase for any warranty claims.
For further assistance, visit the official WIK website or contact their authorized service centers.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000TJ0ZWU

More documents and user manuals: **https://manuals.plus/**