Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Universal Pictures B000U57V34

E.T.: The Extra-Terrestrial DVD User Manual

Model: B000U57V34
Brand: Universal Pictures

Product Overview

This manual provides essential information for the proper use and care of your E.T.: The Extra-Terrestrial DVD. This release is in PAL format, designed for compatible DVD players and display devices.



Image: E.T.: The Extra-Terrestrial DVD cover. The artwork depicts the iconic scene of E.T. and Elliott flying on a bicycle against a large full moon, with their fingers touching and glowing.

Setup

1. Unboxing

Carefully remove the DVD from its packaging. Inspect the disc for any visible damage or scratches before use.

2. Equipment Requirements

To play this DVD, you will need a DVD player compatible with the PAL video format. Ensure your television or display device also supports PAL.

- PAL compatible DVD player
- Television or display with PAL support
- Appropriate audio/video cables (e.g., HDMI, RCA, SCART)

3. Connecting Your DVD Player

Connect your DVD player to your television using the appropriate cables. Refer to your DVD player's manual for specific connection instructions and ensure the correct input source is selected on your TV.

Operating

1. Inserting the Disc

Open the disc tray of your DVD player. Hold the DVD by its edges and gently place it onto the disc tray with the label side facing up. Close the disc tray.

2. Playing the Movie

Turn on your DVD player and television. Select the correct input source on your television (e.g., HDMI 1, AV). The DVD menu should appear automatically. Use your DVD player's remote control to navigate the menu.

- Select **"Play Movie"** to start the main feature.
- Use **"Scene Selection"** to jump to specific chapters.
- Access **"Audio Options"** to change language tracks (English, French) or enable subtitles.
- Explore **"Special Features"** for additional content, if available on this edition.

3. Language and Subtitle Selection

This DVD supports audio in English and French. Subtitle options may vary. Navigate to the "Audio" or "Language" settings within the DVD menu to make your selection.

Maintenance

1. Disc Handling

Always hold the DVD by its outer edges or by placing a finger through the center hole. Avoid touching the playback surface to prevent fingerprints and scratches.

2. Cleaning the Disc

If the disc becomes dirty or smudged, gently wipe it with a soft, lint-free cloth. Wipe from the center of the disc outwards in a straight line. Do not wipe in a circular motion. Use a specialized DVD cleaning solution if necessary.

3. Storage

Store the DVD in its original case when not in use. Keep the case in a cool, dry place away from direct sunlight and extreme temperatures to preserve disc integrity.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Disc does not play or skips	Dirty or scratched disc; incompatible region code; DVD player malfunction	Clean the disc. Check for deep scratches. Ensure your DVD player is PAL compatible. Try the disc in another player.
No audio	Incorrect audio settings; loose cables; TV volume low	Check audio settings on the DVD menu and your DVD player. Ensure all audio cables are securely connected. Increase TV volume.
No video	Incorrect TV input; loose video cables; incompatible video format	Select the correct input source on your TV. Check video cable connections. Confirm your TV supports PAL format.

If problems persist, consult your DVD player's user manual or contact the manufacturer of your equipment.

Specifications

- **Model:** B000U57V34
- **Format:** DVD
- **Media Format:** PAL
- **Languages:** English, French
- **Director:** Steven Spielberg
- **Actors:** Henry Thomas, Drew Barrymore, Peter Coyote, Dee Wallace
- **Package Dimensions:** 7.1 x 5.42 x 0.58 inches
- **Package Weight:** 2.93 ounces

Warranty and Support

This product is a media disc. For issues related to the disc itself (e.g., manufacturing defects), please contact the retailer from whom you purchased the item.
For technical support regarding your DVD player or television, please refer to the respective manufacturer's documentation or support channels.
Return Policy: As per the buybox winner information, a 30-day return/replacement policy may apply. Please check with your specific seller for details at the time of purchase.

© 2025 Universal Pictures. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000U57V34

More documents and user manuals: **https://manuals.plus/**