Nostalgia CCP510

Nostalgia Popcorn Maker Machine - Professional Cart with 8 Oz Kettle (Model CCP510) Instruction Manual

Your guide to operating and maintaining your Nostalgia Popcorn Maker.

Introduction

Thank you for purchasing the Nostalgia Popcorn Maker Machine. This manual provides important information regarding the assembly, operation, maintenance, and safety of your new popcorn maker. Please read these instructions thoroughly before first use and retain for future reference.





Image: The Nostalgia Popcorn Maker Machine, Model CCP510, featuring a red cart design with an 8 oz kettle and clear viewing panels.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before operating this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not provided by the manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.

- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.

Parts and Assembly

Before assembly, ensure all parts are present and undamaged. Refer to the diagram below for component identification.



Image: Annotated diagram highlighting the 8 oz Stainless Steel Kettle and the 96 Cup Capacity Base of the popcorn machine.

Components:

- Popcorn Maker Unit (with 8 oz Stainless Steel Kettle)
- Cart Base with Wheels
- Utility Shelf / Pushcart Handle
- Kernel Catcher Tray

- Measuring Cup for Kernels
- Measuring Spoon for Oil
- Popcorn Scoop

Assembly Steps:

1. Carefully unpack all components.
2. Assemble the cart base according to the included diagrams (refer to original packaging for detailed cart assembly instructions).
3. Place the popcorn maker unit securely onto the assembled cart base.
4. Attach the utility shelf/pushcart handle to the side of the unit.
5. Insert the kernel catcher tray into its designated slot at the bottom of the popcorn chamber.

Operating Instructions

Before First Use:

- Wipe down all surfaces with a damp, non-abrasive cloth.
- Clean the kettle thoroughly with warm, soapy water, rinse, and dry.
- Ensure the unit is placed on a stable, level surface away from water.

Making Popcorn:

1. Ensure the kettle is properly seated and the stirring rod is free to rotate.
2. Plug the unit into a suitable electrical outlet.
3. Turn on the kettle heating switch (typically the right button). Allow the kettle to preheat for 2-3 minutes.
4. Add 8 ounces of popcorn kernels to the kettle using the provided measuring cup.
5. Add 1 tablespoon of popcorn oil (or desired amount) to the kettle using the provided measuring spoon.
6. Close the kettle lid. Popcorn will begin popping shortly.
7. Once popping slows to 1-2 kernels every few seconds, turn off the kettle heating switch.
8. Carefully tilt the kettle to empty the popped corn into the main chamber.
9. Use the interior light (typically the left button) to keep popcorn warm and for easy viewing.
10. Serve popcorn using the scoop. The utility shelf can be used for serving and seasoning.



Image: Detailed view of the popcorn maker's features, including the interior light for warming, the removable kernel catcher, the multi-functional pushcart handle/serving shelf, and the convenient base storage compartment.



Image: Various popcorn ingredients including kernels, oil, and seasoning, illustrating that the machine is compatible with all Nostalgia popcorn kits.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and longevity of your popcorn maker.

General Cleaning:

- Always unplug the unit and allow it to cool completely before cleaning.
- Remove the kernel catcher tray and empty any unpopped kernels. Wash the tray with warm, soapy water and dry thoroughly.
- Wipe down the interior and exterior surfaces of the popcorn maker with a damp, non-abrasive cloth. For stubborn residue, a mild detergent can be used.
- Clean the tempered safety glass panels with a glass cleaner or a vinegar-water solution to remove oil and residue.

Kettle Cleaning:

- The kettle can be removed for easier cleaning.
- Fill the kettle with warm, soapy water and let it soak for 10-15 minutes to loosen any burnt-on oil or popcorn residue.
- Use a non-abrasive sponge or brush to scrub the inside of the kettle and the stirring mechanism.
- Rinse thoroughly with clean water and dry completely before reattaching to the unit.

Troubleshooting

Problem	Possible Cause	Solution
Popcorn not popping or very few kernels pop.	Kettle not preheated sufficiently; insufficient oil; old or dry kernels.	Ensure kettle preheats for 2-3 minutes. Use fresh kernels and recommended oil amount.
Popcorn tastes burnt.	Kettle left on too long after popping; too much oil/butter in kettle.	Turn off kettle heat immediately after popping slows. Use recommended oil amount. Clean kettle thoroughly.
Stirring rod not rotating.	Obstruction in kettle; motor issue.	Check for obstructions and clean kettle. If problem persists, contact customer support.
Unit not turning on.	Not plugged in; power outlet issue; main switch off.	Ensure unit is properly plugged in. Check power outlet. Verify main power switch is on.

Specifications

- **Model:** CCP510
- **Brand:** Nostalgia
- **Capacity:** 8 ounces (kettle), up to 32 cups per batch
- **Material:** Stainless Steel (kettle), Tempered Safety Glass
- **Dimensions:** 24.5"L x 17.5"W x 53"H
- **Weight:** 9.9 Pounds
- **Special Features:** Interior Light, Kernel Catcher Tray, Utility Shelf, Storage Compartment

Warranty and Support

Nostalgia products are designed with quality and performance in mind. For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Nostalgia website. For technical support, replacement parts, or any inquiries, please contact Nostalgia customer service.
You can find more information and contact details on theNostalgia Brand Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question