Bomann AE 1915 CB

Bomann AE 1915 CB Juicer Instruction Manual

1. Introduction

Thank you for choosing the Bomann AE 1915 CB Juicer. This instruction manual provides essential information for the safe and efficient operation, maintenance, and care of your appliance. Please read this manual thoroughly before first use and keep it in a safe place for future reference. Proper use and care will ensure optimal performance and extend the lifespan of your juicer.

2. Safety Instructions

Always observe the following basic safety precautions when using electrical appliances:

- Read all instructions carefully before operating the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or any other liquid.
- Unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from the feed chute during operation to prevent injury and damage to the juicer. Always use the food pusher provided.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact authorized service personnel for examination, repair, or adjustment.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Place the appliance on a stable, level, and dry surface, away from the edge of the countertop.
- Do not use the appliance outdoors.
- Do not process frozen fruits or vegetables, or fruits with hard seeds/pits (e.g., peaches, apricots, mangoes) without removing them first.

3. Product Overview

Familiarize yourself with the components of your Bomann AE 1915 CB Juicer:

- Food Pusher
- Transparent Lid
- Filter Basket / Strainer
- Juice Collector / Base Unit
- Pulp Container (Built-in)
- Safety Locking Arm
- On/Off Switch with Speed Settings
- Juice Spout





Image 1: The Bomann AE 1915 CB Juicer fully assembled, showcasing its stainless steel and black design, with a glass of freshly extracted juice next to the spout. The food pusher is inserted into the feed chute, and the safety locking arm is engaged.

4. Setup

Before first use, wash all removable parts (lid, filter basket, food pusher, pulp container) in warm, soapy water, rinse thoroughly, and dry. The motor unit should only be wiped with a damp cloth.

1. Place the motor unit on a dry, stable, and level surface.
2. Insert the pulp container into its designated position on the motor unit.
3. Place the filter basket securely onto the motor unit, ensuring it is properly seated.
4. Position the transparent lid over the filter basket and motor unit, aligning the juice spout with the opening on the lid.
5. Engage the safety locking arm by lifting it and securing it into the grooves on the lid. The juicer will not operate unless the locking arm is correctly in place.
6. Place a suitable glass or container under the juice spout to collect the extracted juice.

5. Operating Instructions

Follow these steps for effective juicing:

1. **Prepare Fruits and Vegetables:** Wash all produce thoroughly. For larger items, cut them into pieces that fit easily into the feed chute. Remove any hard seeds, pits, or thick peels (e.g., pineapple, citrus fruits).
2. **Connect Power:** Plug the juicer into a grounded electrical outlet.
3. **Start Juicing:** Turn the appliance on using the On/Off switch. Your juicer may have multiple speed settings (e.g., '1' for soft fruits/vegetables, '2' for harder produce). Select the appropriate speed.
4. **Feed Produce:** Gradually feed the prepared fruits or vegetables into the feed chute. Use the food pusher to gently guide the produce down. Do not force the food pusher, as this can affect juice yield and potentially damage the motor.
5. **Collect Juice and Pulp:** Fresh juice will flow out of the juice spout into your container, while the pulp will be collected in the built-in pulp container.
6. **Finish Juicing:** Once you have finished juicing, turn the appliance off and unplug it from the power outlet.

Tips for Best Results:

- Juice fresh produce for maximum nutritional value.
- For continuous juicing, empty the pulp container and juice collector as they fill up.
- Some fruits and vegetables yield more juice than others.

6. Cleaning and Maintenance

Regular cleaning ensures hygiene and prolongs the life of your juicer. Always unplug the appliance before cleaning.

1. **Disassembly:** Unlock the safety locking arm and remove the lid, filter basket, and pulp container.
2. **Rinse Immediately:** Rinse all removable parts under running water immediately after use to prevent pulp and juice residue from drying and sticking.
3. **Wash Parts:** Wash the food pusher, lid, filter basket, and pulp container in warm, soapy water. Use a brush to clean the fine mesh of the filter basket thoroughly.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water.
5. **Dry and Store:** Dry all parts completely before reassembling or storing the juicer. Store in a clean, dry place.

7. Troubleshooting

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not start.	Appliance not plugged in. Safety locking arm not engaged.	Ensure the plug is securely in the outlet. Engage the safety locking arm correctly.
Low juice yield or excessive pulp.	Filter basket clogged. Produce fed too quickly.	Clean the filter basket. Feed produce slowly and gently.
Motor stops during operation.	Overload due to hard produce or too much produce.	Turn off and unplug. Remove excess produce. Allow motor to cool for 15-20 minutes before restarting.
Excessive vibration or noise.	Filter basket not properly seated. Appliance on an uneven surface.	Ensure the filter basket is securely in place. Place the juicer on a stable, level surface.

8. Technical Specifications

- **Model:** AE 1915 CB (619150)
- **Brand:** Bomann
- **Voltage:** 230 V, 50 Hz
- **Pulp Container Capacity:** 2 Liters
- **Special Feature:** Built-in pulp container
- **Product Weight:** Approximately 2 kg
- **Color:** Silver

9. Disposal Information

Do not dispose of this appliance with household waste. This product is subject to the provisions of European Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). Ensure proper disposal to prevent potential negative consequences for the environment and human health. Contact your local authority for information regarding the collection and recycling of electrical and electronic appliances.

10. Warranty and Support

This product is covered by a manufacturer's warranty in accordance with the legal regulations in your country of purchase. For warranty claims, technical support, or spare parts, please contact your retailer or the Bomann customer service department. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question