Magnavox DP100MW8B

Magnavox DP100MW8B Progressive Scan DVD Player User Manual

Model: DP100MW8B

1. Introduction

This manual provides essential information for the safe and efficient operation of your Magnavox DP100MW8B Progressive Scan DVD Player. Please read these instructions thoroughly before using the device and retain them for future reference.

2. Safety Information

- Do not expose the unit to rain or moisture.
- Do not block ventilation openings.
- Ensure proper power supply voltage.
- Avoid placing the unit on unstable surfaces.
- Refer all servicing to qualified service personnel.

3. Package Contents

- Magnavox DP100MW8B DVD Player
- Remote Control (requires 2 AA batteries, not included)
- Power Cable
- AV Cables (RCA or HDMI, depending on model/region)
- User Manual

4. Product Overview

4.1 Front Panel

The front panel features essential controls and the disc tray.



Image Description: A black Magnavox DP100MW8B DVD player is shown from the front. The disc tray is visible on the left, with 'DVD VIDEO' printed below it and 'MAGNAVOX' on the far left. To the right of the disc tray, there are buttons for 'OPEN/CLOSE', 'PLAY', 'STOP', and 'POWER', along with an 'IR' sensor.

- **Power Button:** Turns the unit on or off.
- **Disc Tray:** Insert DVDs or CDs here.
- **OPEN/CLOSE Button:** Opens and closes the disc tray.
- **PLAY Button:** Starts disc playback.
- **STOP Button:** Stops disc playback.
- **IR Sensor:** Receives signals from the remote control.

4.2 Rear Panel Connections

The rear panel provides various ports for connecting to your television or audio system.



Image Description: The rear panel of the Magnavox DP100MW8B DVD player is shown, highlighting various input/output ports. These include S-VIDEO OUT, COMPONENT VIDEO OUT (Cr/Pr, Y, Cb/Pb), VIDEO OUT (yellow RCA), AUDIO OUT (red and white RCA), COAXIAL, and HDMI OUT.

- **HDMI Out:** For high-definition digital audio/video connection.
- **Component Video Out (Y, Cb/Pb, Cr/Pr):** For progressive scan video output.
- **Video Out (Yellow RCA):** For standard composite video output.
- **Audio Out (Red/White RCA):** For stereo audio output.
- **Coaxial Digital Out:** For digital audio output to a compatible receiver.
- **S-Video Out:** For enhanced video output compared to composite video.

4.3 Key Features

- Compact size
- Progressive Scan for enhanced picture quality
- Parental Lock for content restriction
- Tri Lingual OSD (On-Screen Display)

5. Setup

5.1 Connecting to Power

1. Ensure the DVD player is placed on a stable, level surface.
2. Connect the power cable to the AC IN port on the rear of the DVD player.
3. Plug the other end of the power cable into a standard electrical outlet.

5.2 Connecting to a Television

Choose one of the following connection methods based on your TV's available inputs:

1. **HDMI Connection (Recommended for best quality):**
   Connect an HDMI cable from the **HDMI OUT** port on the DVD player to an **HDMI IN** port on your television.
2. **Component Video Connection:**
   Connect component video cables (Y, Cb/Pb, Cr/Pr) from the DVD player's **COMPONENT VIDEO OUT** ports to the corresponding inputs on your TV. Then, connect red and white RCA cables from the DVD player's **AUDIO OUT** ports to the TV's audio inputs.
3. **Composite Video Connection:**
   Connect a yellow RCA cable from the DVD player's **VIDEO OUT** port to the yellow video input on your TV. Then, connect red and white RCA cables from the DVD player's **AUDIO OUT** ports to the TV's audio inputs.
4. **S-Video Connection:**
   Connect an S-Video cable from the DVD player's **S-VIDEO OUT** port to the S-Video input on your TV. Then, connect red and white RCA cables from the DVD player's **AUDIO OUT** ports to the TV's audio inputs.

After connecting, select the appropriate input source on your television (e.g., HDMI 1, Component, AV) to view the DVD player's output.

6. Operating Instructions

6.1 Basic Disc Playback

1. Press the **POWER** button on the front panel or remote control to turn on the DVD player.

2. Press the **OPEN/CLOSE** button to open the disc tray.
3. Place a DVD or CD onto the disc tray with the label side facing up.
4. Press the **OPEN/CLOSE** button again to close the disc tray. The player will begin loading the disc.
5. Playback should start automatically. If not, press the **PLAY** button.

6.2 Using the Remote Control

The remote control provides full functionality for navigating menus, controlling playback, and adjusting settings. Ensure 2 AA batteries are correctly inserted.

- **Navigation Buttons:** Use arrow keys to move through menus and the **OK** button to confirm selections.
- **PLAY/PAUSE/STOP:** Standard playback controls.
- **SKIP/SEARCH:** Move between tracks/chapters or fast forward/rewind.
- **SETUP:** Access the system settings menu.
- **AUDIO/SUBTITLE:** Change audio tracks or subtitle languages during playback.

6.3 Parental Lock

The Parental Lock feature allows you to restrict playback of discs based on their rating. Refer to the on-screen display (OSD) menu for setup and password configuration.

7. Maintenance

- **Cleaning the Unit:** Use a soft, dry cloth to wipe the exterior of the unit. Do not use liquid cleaners or aerosol cleaners.
- **Cleaning Discs:** Wipe discs gently from the center outwards with a soft, lint-free cloth. Avoid touching the playback surface.
- **Storage:** Store the DVD player in a cool, dry place away from direct sunlight and extreme temperatures.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; outlet not active	Check power cable connection; try a different outlet.
No picture on TV	Incorrect TV input selected; video cables loose/incorrectly connected	Select correct TV input; check all video cable connections.
No sound	TV/receiver volume low/muted; audio cables loose/incorrectly connected	Increase volume/unmute; check all audio cable connections.
Disc will not play / "No Disc" message	Disc inserted incorrectly; disc is dirty/damaged; unsupported disc format	Reinsert disc correctly; clean disc; try a different disc.
Remote control not working	Batteries depleted/incorrectly inserted; obstruction between remote and player	Replace batteries; ensure clear line of sight to IR sensor.

9. Specifications

- **Brand:** Magnavox

- **Model Name:** DP100MW8B
- **Item Weight:** 1.8 pounds
- **Product Dimensions:** 9.7 x 8.3 x 2 inches
- **Color:** Black
- **Media Type:** DVD
- **Special Feature:** Compact
- **Resolution:** 720 x 480 pixels
- **Connector Type:** RCA or HDMI
- **Connectivity Technology:** HDMI
- **Audio Output Mode:** Surround
- **Batteries (for remote):** 2 AA batteries required

10. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Magnavox website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question