Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Reizen Beeping Foam Football

Reizen Beeping Foam Football User Manual

Model: Beeping Foam Football

Introduction

Thank you for choosing the Reizen Beeping Foam Football. This manual provides essential information for the safe and effective use of your product. Please read it thoroughly before use and retain it for future reference.



Image: The Reizen Beeping Foam Football, designed for auditory tracking. It features a durable foam construction and an integrated beeping mechanism.

Safety Information

Please observe the following safety precautions:

- Keep the product away from open flames and extreme heat.
- Do not immerse the product in water or other liquids.
- Ensure the battery compartment is securely closed during use.
- This product is not a toy for pets.
- Adult supervision is recommended for young users.

Package Contents

- 1 x Reizen Beeping Foam Football
- 1 x 9V Battery (included)
- 1 x User Manual (this document)

Setup

Battery Installation/Check

1. Locate the battery compartment on the football. This is typically secured with a small screw or latch.
2. If a screw is present, use a small screwdriver to open the compartment.
3. Insert one 9V battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment securely. If a screw was removed, fasten it back into place.

Operating Instructions

Turning On/Off

1. Locate the On/Off switch on the football. This switch is usually near the battery compartment or the beeping mechanism.
2. To activate the beeping function, slide the switch to the "On" position. You should hear a distinct beeping sound.
3. To deactivate the beeping function and conserve battery life, slide the switch to the "Off" position.

Playing with the Football

The Reizen Beeping Foam Football is designed for auditory tracking. The continuous beeping sound allows users to locate the ball by sound, making it suitable for various activities, especially for individuals with visual impairments. Throw and catch the ball as you would with a standard foam football, using the sound to guide your movements.

Maintenance

Cleaning

- Wipe the surface of the football with a damp cloth and mild soap if necessary.
- Do not use harsh chemicals or abrasive cleaners, as these may damage the foam or the electronic components.
- Ensure the football is completely dry before storing or using again.

Storage

- Store the football in a cool, dry place away from direct sunlight.
- If storing for an extended period, remove the 9V battery to prevent leakage and potential damage to the electronics.

Troubleshooting

Problem	Possible Cause	Solution
Football is not beeping.	On/Off switch is in "Off" position.	Slide the switch to the "On" position.

Problem	Possible Cause	Solution
	Battery is dead or incorrectly installed.	Replace the 9V battery or ensure it is installed with correct polarity.
Beeping sound is weak or intermittent.	Low battery.	Replace the 9V battery.
	Loose battery connection.	Open the battery compartment and ensure the battery is firmly seated.

Specifications

- **Model:** Beeping Foam Football
- **Brand:** Reizen
- **Power Source:** 1 x 9V Battery (included)
- **Features:** On/Off switch, Integrated beeping mechanism
- **Material:** Foam

Warranty Information

Reizen products are manufactured to high-quality standards. This product comes with a limited warranty against defects in materials and workmanship from the date of purchase. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, please refer to the product packaging or contact customer support.

Customer Support

If you have any questions, require assistance, or encounter issues with your Reizen Beeping Foam Football, please contact our customer support team:

- **Website:** www.reizenusa.com (Example link, actual link may vary)
- **Email:** support@reizenusa.com (Example email, actual email may vary)
- **Phone:** Please refer to the product packaging for regional contact numbers.

© 2023 Reizen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000YL9LW8

More documents and user manuals: **https://manuals.plus/**